

Acer

A1-734– acer_barricade
A1-810– mango
A1-830– ducati
A3-A20– acer_harley
A3-A20FHD– acer_harleyfhd
A3-A40– acer_jetfirefhd
AT390– T2
B1-723– oban
B1-730– vespatn
B1-780– acer_barricadewifi
B1-820– citizen
B1-850– Frenzy
B3-A30– acer_jetfirehd
DA226HQ– da6
GT-810– rolex
Iconia One 10– corona
Iconia One 7– G1-725
Iconia One 7– vespa
Iconia One 7– vespa2
Iconia One 8– vespa8
Iconia Tab 7– acer_aprilia
Iconia Tab 7– acer_apriliahd
Iconia Tab 8– ducati2fhd
Iconia Tab 8– ducati2hd
Iconia Tab 8– ducati2hd3g
Iconia TalkTab 7– acer_a1_724
Liquid E1– C10
Liquid E3– acer_e3
Liquid E3– acer_e3n
Liquid E600– e600
Liquid E700– acer_e39
Liquid Jade 2– acer_s58a
Liquid Jade S– acer_S56
Liquid Jade Z– acer_S57
Liquid Jade– acer_S55
Liquid S1– a10
Liquid S3– s3

Liquid X2– acer_S59
Liquid Z200– acer_z200
Liquid Z205– acer_z205
Liquid Z205– acer_z205p
Liquid Z320– T012
Liquid Z330– T01
Liquid Z4– acer_Z6
Liquid Z410– acer_z410
Liquid Z500– acer_Z500
Liquid Z520– acer_z520
Liquid Z530– acer_T02
Liquid Z530S– acer_t05
Liquid Z6 Plus– acer_t11
Liquid Z6– acer_t09
Liquid Z630– acer_t03
Liquid Z630S– acer_t04
Liquid Zest 4G– acer_t07
Liquid Zest Plus– acer_t08
Liquid Zest– acer_t06
Z120– Z2

Allwinner

VIEW 1070TPC– tulip-d100

Archos

101 G9– A101
101 Magnus– ac101ma
40 Power– ac40po
45c Platinum– ac45cpl
45c Titanium– ac45cti
45d Platinum– ac45dpl
50 Cobalt– ac50co
50 Diamond– ac50da
50 Saphir– ac50sa
50 Titanium 4G– ac50ti
50b Platinum– ac50bpl
50c Oxygen– a50cox
55 Cobalt Plus– ac55cop

70 Neon– ac70ne
9.4" FFF– ac94fff
Alba 10"– ac101cpl
Alba 4– ac40he
Alba 5– ac50dne
Archos 101 Copper– ac101cv
Archos 101 Helium Lite– ac101hel
Archos 101 Helium– ac101he
ARCHOS 101 Oxygen– ac101ox
Archos 101 Xenon Lite– ac101xel
Archos 101 Xenon– ac101cxe
Archos 101 Xenon– ac101xev2
Archos 101b Copper– ac101bcv
Archos 101b Oxygen– ac101box
Archos 101b Platinum– ac101bpl
Archos 101b Xenon– ac101bxev2
Archos 101c Copper– ac101ccv
Archos 101c Neon– ac101cne
Archos 101D Neon– ac101dne
Archos 101d Platinum v2 – ac101cplv2
Archos 101d Platinum v3 – ac101dplv3
Archos 101e neon– ac101ene
Archos 101e Neon– ac101enev2
Archos 101XS3– ac101xs3
ARCHOS 35b Titanium– ac35bti
Archos 40 Neon– ac40ne
Archos 40c Titanium– ac40ctiv2
Archos 45 Neon– ac45ne
Archos 45b Helium– ac45bhe
Archos 45c Helium– ac45che
Archos 50 d Helium– ac50dhe
Archos 50 Oxygen plus– ac50oxplus
Archos 50 Platinum 4G– AC50PL4G
Archos 50 Power– ac50po
ARCHOS 50c Helium– ac50che
Archos 50d Oxygen– ac50dox
Archos 50e Helium – ac50ehe
Archos 50e Neon– ac50ene

Archos 50f Helium– ac50fhe
ARCHOS 52 Platinum– ac52pl
Archos 55 Diamond Selfie– ac55diselfie
Archos 55 Helium– ac55he
Archos 59 Titanium– ac59ti
Archos 59 Xenon– ac59xe
ARCHOS 62 Xenon– ac62xe
Archos 70 Copper– ac70cv
Archos 70 Helium– ac70he
Archos 70 Oxygen– ac70ox
Archos 70 Platinum 3G– ac70pl3g
Archos 70 Platinum v2– ac70plv4
Archos 70 Platinum– ac70pl
Archos 70 platinum– ac70plv3
Archos 70 Xenon Color– ac70xec
Archos 70b Helium– ac70bhe
Archos 70b Neon– ac70bne
Archos 70b Xenon– ac70bx
Archos 70c Xenon– ac70cxe
Archos 80 Oxygen– ac80ox
Archos 80 Platinum – ac80cplv2_16G
Archos 80 Platinum v2 – ac80dplv2
Archos 80b Helium– ac80bhe
Archos 80b Helium– ac80bhev2
Archos 80b xenon– ac80bx
Archos 80c Xenon– ac80cxe
Archos 80d Xenon– ac80dxe
ARCHOS 90 Copper– ac90cv
Archos 90b Copper– ac90bcv
Archos 96 Xenon– ac96xe
Archos 97c Platinum– ac97cpl
Archos80cpl_loreal– ac80cpl
Bush 10.0 MyTablet– ac101dpl
Bush 10"– ac101dplv2
Bush 4" Android Phone– ac40cti
Bush 5 4G– ac50heplus
Bush 5 4G– ac55heplus
Bush 5 android– ac50cpl

Bush 5" Android Phone– ac50bne
Bush 5" Android– ac50cne
Bush 7.85 My Tablet– ac79bu
Bush 8"– ac80dpl
Bush Spira B1 10.1– ac101dplv3a6
BUSH SPIRA E3X 5.5– ac55di2plus
Diamond Plus– ac55diplus
Diamond S– ac50dis
Fieldbook F1– lifbf1
Fieldbook F53– lifbf53
Fieldbook K80– lifbk80
KUNO 4+– kuno4p
My Tablet 101– ac101bu
QiLive 101– aqilive101
Qilive7V2– ql70v2
Smartphone 5" Q.4094– ac50bhe

Asus

ASUS Fonepad 8– K016_4
ASUS Live– ASUS_Z00YD
ASUS Transformer Pad– K010_1
Asus Zenfone3 Ultra– ASUS_A001
ASUS ZenPad 3S 10– P027
ASUS ZenPad Z8– P008
ASUS_ Zenfone Max– ASUS_Z010_2
ASUSPRO Tablet (M1000C)– P023_M
ASUSPRO Tablet (M700C)– P01W_M
ASUSPRO Tablet (M700KL)– P002_M
ASUSPRO Tablet-M1000CL– P01T_M
Commercial tablet 10" (M1000M)– P00C_M
Commercial tablet 8" (M800M)– P00A_M
Fonepad 7 (FE170CG)– K012
Fonepad 7 (FE171CG)– K01N_1
Fonepad 7 (FE171CG)– K01N_2
Fonepad 7 (FE171MG)– K01F
Fonepad 7 (FE375CG)– K019_1
Fonepad 7 (FE375CXG)– K019_3
Fonepad 7 (FE375CXG)– K019_4

Fonepad 7 (ME175CG)– K00Z
Fonepad 7 LTE (FE375CL)– K01Q
Fonepad 7 LTE (ME372CL)– K00Y
Fonepad 7(FE375CXG)– K019_2
Fonepad 8 (FE380CG)– K016_1
Fonepad 8 (FE380CXG)– K016_2
Fonepad 8 (FE380CXG)– K016_3
Fonepad Note 6 (ME560CG)– K00G
MeMO Pad (ME103K)– K01E_1
MeMO Pad (ME103K)– K01E_2
MeMO Pad 7 (FE7010CG)– K012_2
MeMO Pad 7 (ME170C)– K017
MeMO Pad 7 (ME171C)– K01U_1
MeMO Pad 7 (ME171C)– K01U_2
MeMO Pad 7 (ME176C)– K013
MeMO Pad 7 (ME176CX)– K013_1
MeMO Pad 7 (ME572C)– K007
MeMO Pad 7 (ME70C)– K01A
MeMO Pad 7 LTE (ME375CL)– K00X
MeMO Pad 7 LTE (ME572CL)– K00R
MeMO Pad 7 LTE (ME7530CL)– K00X_1
MeMO Pad 7– K013C
MeMO Pad 8 (AST21)– K015
MeMO Pad 8 (ME181C)– K011
MeMO Pad 8 (ME181CX)– K011_1
MeMO Pad 8 (ME581C)– K01H
PadFone 2– A68
PadFone Infinity– ASUS-A80
PadFone mini– ASUS_T00E
PadFone S (PF500KL)– ASUS_T00N
PadFone X (A91)– ASUS-T00D
PadFone X mini (PF450CL)– ASUS-T00S
The new PadFone Infinity (A86)– ASUS-A86
Transformer Pad (TF103C)– K010
Transformer Pad (TF103C)– K010_3
Transformer Pad (TF103CE)– K010E
Transformer Pad (TF103CE)– K010E_1
Transformer Pad (TF103CG)– K018

Transformer Pad (TF303CL)– K014
Transformer Pad (TF303K)– K01B
Transformer Pad Infinity (TF701T)– K00C
TX201LAF– TX201LAF
X00AD_2– ASUS_X00AD_2
X00DD– ASUS_X00DD
ZenFone 2 (ZE500CL)– ASUS_Z00D
ZenFone 2 (ZE550ML)– Z008_1
ZenFone 2 (ZE551ML)– Z00A
ZenFone 2 (ZE551ML)– Z00A_1
ZenFone 2 Laser (ZE500KG)– ASUS_Z00RD_5
ZenFone 2 Laser (ZE500KG)– ASUS_Z00RD_7
ZenFone 2 Laser (ZE500KL)– ASUS_Z00E_1
ZenFone 2 Laser (ZE500KL)– ASUS_Z00E_2
ZenFone 2 Laser (ZE500KL)– ASUS_Z00E_3
ZenFone 2 Laser (ZE500KL)– ASUS_Z00E_4
ZenFone 2 Laser (ZE550KG)– ASUS_Z00W_63
ZenFone 2 Laser (ZE550KL)– ASUS_Z00L_63
ZenFone 2 Laser (ZE550KL)– ASUS_Z00L_63A
ZenFone 2 Laser (ZE550KL)– ASUS_Z00L_93
ZenFone 2 Laser (ZE550KLA)– ASUS_Z00L_63C
ZenFone 2 Laser (ZE551KL)– ASUS_Z00T
ZenFone 2 Laser (ZE600KL)– ASUS_Z00M
ZenFone 2 Laser (ZE601KL)– ASUS_Z011
ZenFone 2(ZE551ML)– Z00A_3
ZenFone 3 Deluxe (ZS550KL)– ASUS_Z01F_1
Zenfone 3 Deluxe (ZS570KL)– Z016
Zenfone 3 Deluxe (ZS570KL)– Z016_1
Zenfone 3 Laser– Z01B_1
ZenFone 3 Max (ZC520TL)– ASUS_X008
ZenFone 3 Max (ZC520TL)– ASUS_X008_1
ZenFone 3 Zoom (ZE553KL)– ASUS_Z01H_1
Zenfone 3– ASUS_Z012D
ZenFone 4 (A400CG)– ASUS_T00I
ZenFone 4 (A450CG)– ASUS_T00Q
ZenFone 5 (A500CG)– ASUS_T00F
ZenFone 5 (A500CG)– ASUS_T00F1
ZenFone 5 (A501CG)– ASUS_T00J1

ZenFone 5 (A502CG)– ASUS_T00K
ZenFone 5 LTE (A500KL)– ASUS_T00P
ZenFone 5– ASUS_T00J
ZenFone 6 (A600CG)– ASUS_T00G
ZenFone 6 (A601CG)– ASUS_Z002
ZenFone C (ZC451CG)– ASUS_Z007
Zenfone Go (ASUS_X005)– ASUS_X005
Zenfone Go (ASUS_X00BD)– ASUS_X00BD_1
Zenfone Go (ASUS_Z00SD)– ASUS_Z00SD
Zenfone Go (ASUS_Z00VD)– ASUS_Z00VD
ZenFone Go (ZB552KL)– ASUS_X007D
Zenfone Go– ASUS_L001_1
Zenfone Go– ASUS_L001_2
Zenfone Go– ASUS_X009D_2
Zenfone GO– ASUS_X013D_1
Zenfone GO– ASUS_X013D_2
Zenfone GO– ASUS_X014D_1
Zenfone GO– ASUS_X014D_2
Zenfone MAX– ASUS_Z010
Zenfone MAX– ASUS_Z010_CD
ZenFone Selfie (ZD551KL)– ASUS_Z00U_1
ZenFone Selfie (ZD551KL)– ASUS_Z00U_2
ZenFone Zoom (ZX551ML)– Z00X
ZenFone Zoom (ZX551ML)– Z00X_1
ZenFone Zoom (ZX551ML)– Z00X_2
ZenFone3– ASUS_Z017D_1
ZenPad 10 (Z300C)– P023_1
ZenPad 10 (Z300C)– P023_2
ZenPad 10 (Z300CG) – P021
ZenPad 10 (Z300CG)– P021_1
ZenPad 10 (Z300CL)– P01T_1
ZenPad 10 (Z300M)– P00C_1
ZenPad 10 (Z300M)– P00C_2
ZenPad 3 8.0– P008_1
ZenPad 3 8.0– P008_2
ZenPad 3S 10 LTE (Z500KL)– ASUS_P00I
ZenPad 7.0 (Z370C)– P01W
ZenPad 7.0 (Z370CG)– P01V_1

ZenPad 7.0 (Z370CG)– P01V_2
ZenPad 7.0 (Z370KL)– P002_2
ZenPad 7.0(Z370KL)– P002_1
Zenpad 8 LTE– P024_2
Zenpad 8 LTE– P024_3
Zenpad 8 LTE– P024_4
Zenpad 8.0 (Z380C)– P022_1
Zenpad 8.0 (Z380C)– P022_2
Zenpad 8.0 (Z380KL)– P024_1
ZenPad 8.0 (Z380M)– P00A_1
ZenPad 8.0 (Z380M)– P00A_2
ZenPad C 7.0 (Z170C)– P01Z
ZenPad C 7.0 (Z170C)– P01Z_2
ZenPad C 7.0 (Z170CG)– P01Y
ZenPad C 7.0 (Z170CG)– P01Y_2
ZenPad C 7.0 (Z170MG)– P001
ZenPad C 7.0 (Z170MG)– P001_2
ZenPad C 7.0– P01Y_S
ZenPad S 8.0 (Z580C)– P01M_2
ZenPad S 8.0 (Z580C)– P01M_4
ZenPad S 8.0 (Z580CA)– P01M_1
ZenPad S 8.0 (Z580CA)– P01M_3
ZenPad S 8.0 (Z580CA)– P01M_5
ZenPad Z10– P00I
飛馬 (T500KLC)– ASUS_X003
飛馬 (T500TLT)– ASUS_X002
飞马2 Plus(X550)– ASUS_X550

BYD

DynaVox T10– T10

INHON G3– G3

BARNES AND NOBLE

NOOK® HD– hummingbird

BLACKBERRY

DTEK50 by BlackBerry– hamburg

DTEK60 by BlackBerry– argon

PRIV by BlackBerry– venice**CJSC EXPLAY****Air**– Air**Atom**– Atom**ATV**– ATV**Bit**– Bit**Cosmic**– Cosmic**Craft**– Craft**Discovery**– Prime**Easy**– Easy**Fresh**– Fresh**Fresh**– Fresh_NF**Hit**– Hit**Indigo**– Indigo**Joy TV**– Joy_TV**Light**– Light**Onliner 4**– G4187**Onyx**– Onyx**Party**– Party**Phantom**– Phantom**Pulsar**– Pulsar**Rio Play**– RioPlay**Style**– T5246**Surfer777 3G**– Leader**Tab Mini**– TabMini**Tornado 3G**– Tornado3G**Tornado**– Tornado**Vega**– Vega**Winner 7**– T4729**Winner 8**– T4730**Winner**– T4728**CELLON****BB8252**– Bigben-TAB**CT1000**– Carrefour**Endeavour101**– Blaupunkt**ICON**– ICON

LUVO-001L– LUVO-001L

WEBPAD1002– Listo

COMPAL

BenQ F3– F3

CAT B15Q– B15Q

COOLPAD

Cool C1– cool_c1

Coolpad 3300A– 3300A

Coolpad 3320A– cp3320a

Coolpad 3503I– CP3503I

Coolpad 3600i– CP3600I

Coolpad 3622A– cp3622a

Coolpad 3623A– cp3623a

Coolpad 3700A– 3700A

Coolpad 5217– msm8610

Coolpad 5270– Coolpad5270

Coolpad 5367– Coolpad5367

Coolpad 8297L-I00– Coolpad8297L-I00

Coolpad 8298-M02– CP8298_M02

Coolpad 8676-I03– CP8676_I03

Coolpad 8712– CP8712

Coolpad 8712SV– Coolpad8712

Coolpad 8718– Coolpad8718

Coolpad 8722_S00– CP8722_S00

Coolpad 8722-U00– CP8722_U00

Coolpad 8722V– CP8722

Coolpad 8732– Coolpad8732

Coolpad 8971– 8971

Coolpad 9970L– 9970L

Coolpad A8-831– A8-831

Coolpad A8-930– A8-930

Coolpad A8-931– A8-931

Coolpad A8-932– A8-932

Coolpad A8– A8

Coolpad B770– B770

Coolpad C103– C103

Coolpad CK2-01– CK2-01
Coolpad CK3-01– CK3-01
Coolpad E561– E561
Coolpad i1-01– i1-01
Coolpad i1– i1
Coolpad i3-M1– i3-M1
Coolpad K2L_S00 – K2L_S00
Coolpad R106– cpy90_g00
Coolpad R108– R108
Coolpad SK3-U00– E561_EU
Coolpad SS1-03– SS1-03
Coolpad SS2-01– SS2-01
Coolpad Y72-921– Y72-921
Coolpad Y803-8– CPY803_8
Coolpad Y803-9– CPY803_9
Coolpad Y83_S00– CPY83_S00
Coolpad Y83_U00– CPY83_U00
Coolpad Y83-900– Y83-900
Coolpad Y83-I00– CPY83_I00
Coolpad Y90– Y90
Coolpad Y91-921– Y91
Coolpad Y92-9– Y92-9
CP5660S– 5560S
CPT1– CoolpadT1
ivvi i3-01– i3-01
ivvi i3P-02– i3P-02
Karbons Titanium S5 Plus– Karbons
VodafoneSmart4– VodafoneSmart4
VodafoneSmart4turbo– VodafoneSmart4turbo

DELL

Dell Venue 10– SO
Dell Venue 7040– EP
Venue 7– LW
Venue 7– thunderbird
Venue 7– Venue7
Venue 8– BB
Venue 8– Venue8

Venue 8– yellowtail**DIGI-IN****7DTB25**– 7DTB25**Beeline Tab**– Beeline_Tab**C08TA**– C08TA**Digital2 Plus**– Digital2Plus**DIT702201** – DIT702201**EGD078**– EGD078**EGD213**– EGD213**EGQ780**– EGQ780**ELITE10Q**– Elite10Q**ELITE8QS**– Elite8QS**ELITE9Q**– ELITE9Q**HS-10DTB12**– Hipstreet**M7s Dual Core** – NB116_NB117_NB118**MFC191**– MFC191**MID9526CM**– MID9526CM**Monster M10**– M10**MW6617**– MW6617**NS-15AT07**– NS-15AT07**NV8-HD**– NV8-HD**NX785QC**– nxm865lvd_wm**P1001**– P1001**P791**– P791**PNDPP44QC10**– PNDPP44QC10**PNDPP44QC7**– PNDPP44QC7**Q.3778**– Q3778**Sprout Channel Cubby** – Cubby**T1144**– T1144**TBDG734**– TBDG734**W6610**– Marathon**WETAB700DG**– WETAB700DG**DORO****Liberto 820**– Liberto820**Liberto 820 Mini**– 820Mini

ECS**Any 302**– TR10CS1_15**Any 302**– TR10CS2_3**i-Buddie**– TR10CD1_10**i-Buddie**– TR10CD1_11**FLY****Cirrus 2**– Cirrus_2**Cirrus 6**– Cirrus_6**Cirrus 7**– Cirrus_7**Cirrus 8**– Cirrus_8**Cirrus 9**– Cirrus_9**Fly Cirrus 3**– Cirrus_3**Fly Cirrus 4**– Cirrus_4**Fly Era Energy 1**– IQ4502_Quad**Fly Era Nano 8**– IQ4400**Fly Era Style 3**– IQ4415_Quad**Fly Evo Chic 2**– IQ459**Fly Evo Tech 3**– IQ4414_Quad**Fly FS502**– Cirrus_1**Fly IQ434**– IQ434**FLY IQ4421 Quad**– IQ4421_Quad**Fly IQ4503 Quad**– IQ4503_Quad**Fly IQ4503**– IQ4503**Fly IQ4504 Quad**– IQ4504_Quad**Fly IQ4512 Quad**– IQ4512_Quad**Fly IQ4513 Octa**– IQ4513_Octa**Fly IQ4513**– IQ4513**Fly IQ4514 Quad**– IQ4514_Quad**Fly IQ4515 Quad**– IQ4515_Quad**Fly IQ4516 Octa**– IQ4516_Octa**Fly IQ4602**– Fly_IQ4602**Fly IQ4602**– IQ4602_Quad**Fly Iris**– FLY_IQ4400**Fly Nimbus 8**– Nimbus_8**FS402**– Stratus_2

IQ4401– IQ4401
IQ4409 Quad– IQ4409_Quad
IQ4413 Quad– IQ4413_Quad
IQ4415– IQ4415
IQ4417 Quad– IQ4417_Quad
IQ4418– IQ4418
IQ4509– IQ4509
KAZAM Thunder 345 LTE– Thunder_345_LTE
KAZAM Thunder 345– Thunder_345
KAZAM Thunder 345L– Thunder_345L
KAZAM Thunder 347– Thunder_347
KAZAM Thunder 350L– Thunder_350L
KAZAM Thunder 550L– TH5L5025
KAZAM Tornado 348– Tornado_348
KAZAM Tornado 350– KAZAM_Tornado_350
KAZAM Tornado 455L– KAZAM_Tornado_455L
KAZAM Trooper 440L– Trooper_440L
KAZAM Trooper 445L– TR4L4544
KAZAM Trooper 450– KAZAM_Trooper_450
KAZAM Trooper 450L– KAZAM_Trooper_450L
KAZAM Trooper 550L– TR5L5025
KAZAM Trooper 555– TR55515
KAZAM TV 4.5– KOT49H
KAZAM TV 4.5– TV_45
Nimbus 10– Nimbus_10
Nimbus 12– Nimbus_12
Nimbus 7– Nimbus_7
R200– R200
Spark X– porridgek3
Spark– porridge
Storm– kipper
Stratus 3– Stratus_3
Stratus 4– Stratus_4
Swift 2– marmite
Swift– crackling
Tornado One– IQ4511_Octa
Trooper 650 4G– TR6L5035
Trooper 650– TR65035

FOXCONN INTERNATIONAL HOLDINGS LIMITED**F52**– F52**Life Max**– Life_Max**LS-4505**– LS-4505**NEO X MINI**– BLU_NEO_X_MINI**Telenor Smart4G**– Telenor_Smart_4G**Y5**– Y5**FUHU****nabi DreamTab HD8 Tablet**– DMTAB**nabi DreamTab HD8 Tablet**– t8400n**FUJITSU****ARROWS M01**– M01**ARROWS M305**– M305**arrows M357**– M357**ARROWS M555**– M555**ARROWS M555**– M555SB**arrows Tab M01T**– M01T**arrowsM03**– M03**F-01F**– F01F**F-01H**– F01H**F-01J**– F01J**F-02F**– F02F**F-02G**– F02G**F-02H**– F02H**F-03G**– F03G**F-03H**– F03H**F-04G**– F04G**F-04H**– F04H**F-05F**– F05F**F-05G**– F05G**F-06F**– F06F**FARTMB611Y**– FARTMB611Y**FHMD001**– FHMD001

M305– M305SB

RM02– M02

STYLISTIC M350/CA2– M350

TM20– STF

GIGABYTE

Arty A3– Arty_A3

AV10– RCT6203W46

AZDroid– AZDroid

GSmart Roma R2– Roma_R2

GX2– GBC_ares

iDeaUSA CT10– CT10

JM-250– JM-250

MD7053G– MD7053G

Mika M2– Mika_M2

Play– Play

TM785CH– tm785ch

GOOGLE

Galaxy Nexus– toro

GOOGLE ATAP

Nexus 10– manta

Nexus 4– mako

Nexus 5– hammerhead

Nexus 5X– bullhead

Nexus 6– shamu

Nexus 6P– angler

Nexus 7 (2013)– deb

Nexus 7 (2013)– flo

Nexus 9 LTE– flounder_lte

Nexus 9– flounder

Pixel C– dragon

Pixel XL– marlin

Pixel– sailfish

Project Tango Tablet Development Kit– yellowstone

HP

10 Plus– torsa
10– spruce
7 G2– redwood
7 Plus G2– deschutes
7 Voice Tab– klondike
7 VoiceTab– yukon
8 G2– maple
Pro Slate 10 EE G1– bulldog
Pro Slate 10 EE G1– hound
Pro Slate 10 EE G1– poodle
Pro Slate 10 EE G1– terrier
Pro Slate 12– dane
Pro Slate 8– malamute
Slate 10 HD– bonsai10
Slate 10 Plus– linkplus
Slate 6 Voice Tab II– avocado
Slate 6 Voice Tab– pomegranate
Slate 6 VoiceTab Plus– mekong
Slate 7 Beats Special Edition– fairfax
Slate 7 Extreme– olive
Slate 7 HD– bonsai7
Slate 7 VoiceTab Ultra– charm
Slate 8 Plus– vogue
Slate 8 Pro– dogwood
Slate8 Pro– fig
Voice Tab 7– almond

HTC

Butterfly S– dlxpul
Desire 510– htc_a11ul8x26
Desire 626– htc_a32dcgl
Desire 828– htc_a51bml_dtul
HTC 0P9C8– htc_a5dwgl
HTC 10 evo– htc_acauhl
HTC 10– htc_pmec2tuhl
HTC 10– htc_pmeuhl
HTC 10– htc_pmewhl

HTC 10– htc_pmewl
HTC 710C– htc_a5chl
HTC 8060– t6dug
HTC 8088– t6tl
HTC 809d– t6dwg
HTC 9088– dlpdtu
HTC 919d– dlpdwg
HTC Bolt– htc_acawhl
HTC Butterfly 2– htc_b2ul
HTC Butterfly 3– htc_b3tuhl
HTC Butterfly s 9060– dlpdug
HTC Butterfly– dlxub1
HTC D10i– htc_a56dj_pro_dugl
HTC D610t– htc_a3tl
HTC D816d– htc_a5dwg
HTC D816e– htc_a5dugl
HTC D816t– htc_a5tl
HTC D820 Mini– htc_a31dtul
HTC D820t– htc_a51dtul
HTC Desire 10 lifestyle – htc_a56djdugl
HTC Desire 10 lifestyle – htc_a56djuhl
HTC Desire 10 lifestyle – htc_a56djul
HTC Desire 320– htc_v01_u
HTC Desire 326G dual sim– htc_v01a_dug
HTC Desire 510– htc_a11chl
HTC Desire 510– htc_a11ul
HTC Desire 512– htc_a11aul8x26
HTC Desire 520– htc_a12ul
HTC Desire 526– htc_a13wl
HTC Desire 526– htc_a13wlpp
HTC Desire 526G+ dual sim– htc_v02_dug
HTC Desire 526GPLUS– htc_v02_u
HTC Desire 530– htc_a16ul
HTC Desire 530– htc_a16wl
HTC Desire 601– zara
HTC Desire 601– zaracl
HTC Desire 610– htc_a3qhdu
HTC Desire 610– htc_a3ul

HTC Desire 612– htc_a3qhdcl
HTC Desire 620– htc_a31ul
HTC Desire 620G dual sim– htc_a31mg_dug
HTC Desire 626– htc_a32ewl
HTC Desire 626– htc_a32ewlpp
HTC Desire 626– htc_a32ul
HTC Desire 626– htc_a32ul_emea
HTC Desire 626G+ dual sim– htc_a32mg_dug
HTC Desire 626s– htc_a32eul
HTC Desire 626s– htc_a32eul_la
HTC Desire 626s– htc_a32ewhl
HTC Desire 628 dual sim– htc_v36bml_dugl
HTC Desire 630 dual sim– htc_a16dwgl
HTC Desire 650– htc_a17uhl
HTC Desire 728– htc_a50cml_tuhl
HTC Desire 728G dual sim– htc_a50cmg_dwg
HTC Desire 816 dual sim– htc_a5dug
HTC Desire 816– htc_a5ul
HTC Desire 816G dual – htc_a5mgp_dug
HTC Desire 816G dual sim– htc_a5mg_dug
HTC Desire 820– htc_a51ul
HTC Desire 820G PLUS dual sim– htc_a50mgp_dug
HTC Desire 820q dual sim– htc_a50dtul
HTC Desire 820s dual sim– htc_a50ml
HTC Desire 820s– htc_a50ml_dtul
HTC Desire 825 dual sim– htc_a56dugl
HTC Desire 825– htc_a56uhl
HTC Desire 826 dual sim– htc_a52dtul
HTC Desire 826 dual sim– htc_a52dwgl
HTC Desire 826– htc_a52tuhl
HTC Desire 828 dual sim– htc_a51bml_dwgl
HTC Desire 828– htc_a51bml_tuhl
HTC Desire 830 dual sim– htc_a51cml_dtul
HTC Desire 830– htc_a51cml_tuhl
HTC Desire EYE– htc_eyetuhl
HTC Desire EYE– htc_eyeul
HTC Desire EYE– htc_eyeul_att
HTC Desire626s– htc_a32eulatt

HTC Desire815G– htc_a5mgp_u
HTC E9pt– htc_a55ml_dtul
HTC J Butterfly– dlxj
HTC J One– m7wlj
HTC M8si– htc_m8qltuhl
HTC M8t– htc_m8tl
HTC M9– htc_himaulatt
HTC One (E8) dual sim– htc_mecdug
HTC One (E8) dual sim– htc_mecdwg
HTC One (E8)– htc_mectl
HTC One (E8)– htc_mecul
HTC One (E8)– htc_mecwhl
HTC One (M8 EYE)– htc_melsuhl
HTC One (M8) – htc_m8dug
HTC One (M8)– htc_m8
HTC One (M8)– htc_m8dug
HTC One (M8)– htc_m8whl
HTC One (M8)– htc_m8wl
HTC One A9– htc_hiaetuhl
HTC One A9– htc_hiaeuhl
HTC One A9– htc_hiaeu
HTC One A9– htc_hiaewhl
HTC One A9s– htc_e36_ml_uhl
HTC One A9s– htc_e36_ml_ul
HTC One Dual Sim– m7cdwg
HTC One E9 dual sim– htc_a53ml_dtul
HTC One E9s dual sim– htc_a50aml
HTC One M8 eye 4G LTE 移动定制版– htc_melstuhl
HTC ONE M8s– htc_m8qlul
HTC One M9– htc_himauhl
HTC One M9– htc_himaul
HTC One M9– htc_himawhl
HTC One M9– htc_himawl
HTC One M9+ (Prime Camera Edition)– htc_hiaur2_ml_tuhl
HTC One M9+– htc_hiau_ml_tuhl
HTC One max– t6ul
HTC One max– t6whl
HTC One mini 2– htc_memul

HTC One mini– htc_m4
HTC One mini– m4
HTC One remix– htc_memwl
HTC One S9– htc_himar2uhl
HTC One X– endeavoru
HTC One X– evita
HTC One X9 dual sim– htc_e56ml_dtul
HTC One X9– htc_e56ml_tuhl
HTC One_E8– htc_mecul_emea
HTC One– m7
HTC One– m7cdtu
HTC One– m7cdug
HTC One– m7wls
HTC One– m7wlv
HTC_0PFJ50– htc_a51tuhl
HTC_D626q– htc_a32ml_dtul
HTC_D628u– htc_v36bml_uhl
HTC_D728x– htc_a50cml_dtul
HTC_M9e– htc_himaruhl
HTC_M9ew– htc_hima_ace_ml_dtul
HTC_M9px– htc_hiaur_ml_tuhl
HTC6435LVW– dlx
HTCOneMaxVZW– t6wl
HTL23– htc_b2wlj
HTV31– htc_b3uhl
HTV32– htc_pmeuhljapan

HAIER

PAD1042– PAD1042

HISENSE

AD688G– AD688G
AD689G– AD689G
B16C2G– MSM8909QC
C20S– C20S
C2LEAD688G– C2LEAD688G
CMB405– L690AE

CMB510– L696
D2-M– HS6735MT
E100TAE– E100TAE
E601M– E601M
F31E_11– HS8937QC
F5281CH– rk3288
G1– G1
G610M– G610M
H910-F01– HS8939QC
Hisense D1-M– D1_M
Hisense E50-T– HS8909QC
Hisense E602T– E602T
Hisense E613M– E613M
Hisense E620M– E602M
Hisense E621T– E621T
Hisense E622M– E622M
Hisense E625T– E625T
Hisense I632M– I632M
Hisense I632T– I632T
Hisense I639M– I639M
Hisense I639T– I639T
Hisense I639T– I639TA
Hisense I639T– I639TA1
Hisense M10-M– HS9830SP
HS- G610– HS8916QC
HS-U929– u929de
HS-U929– u929de_3
HS-U961– u961
HS-U961– u961e_1
I630U– I630U
L695– HS8929QC
L697– HS8952QC
LED32K220– mst628
MEDION E4502– E4502
NC36B1G– HS8610QC
NEWAD688G– NEWAD688G
Sero 8– rk3188
Sero7 LE– rk3026

STARSHINE 4– HS6572MT

STARTRAIL 6 4G– L681

U602– HS6580MT

U610– U610

U610– U610E_1

U688BE– MSM8212

U800– U800

U800E-1– U800E_1

u972– HS7731SP

U988– U988

U988E-1– U988E_1

U988E-2– U988E_2

VH777– VH777

VIDAA_TV– MSD6A828

VIDAA_TV– mt5890

X1E1– X1E1

HUAWEI

B199– hwB199

C8817D– hwC8817D

C8817E– hwC8817E

C8818– hwC8818

CHC-U23– hwCHC-H

Che1-CL10– Che1

Che2-L11– hwChe2

CHM-CL00– hwCHM-Q

Copper Plus– HWH1611-Q

d-01G– d-01G

d-01H– d-01H

d-02H– d-02H

DAV– HWP8max

Dive_70– Dive_70

G521-L176– HWG521-L

G6-C00– hwG6-C00

G6-L11– hwG6-L11

G6-U00– hwG6-U00

G6-U10– hwG6-U10

G6-U251– hwG6-U251
G6– hwG6-T00
G620S-L01– hwG620S-L01
G620S-L02– hwG620S-L02
G620S-L03– hwG620S-L03
G620S-UL00– hwG620S-UL00
G621-TL00M– hwG621-TL00
G628-TL00– HWG628-TL
G629-UL00– HWG629-UL
G7-L03– hwG7-L03
G7-TL00– hwG7-TL00
G735-L23– hwG735
G750-T00– hwG750-T00
G750-T01– hwG750-T01
G750-T20– hwG750-T20
GR5W– HWH1621-Q
H30-C00– hwH30-C00
H30-L02– hwH30
H30-T00– hwH30-T00
H60-J1– hwH60
H60-L21– hwH60-L21
H891L– hwH891L
H892L– hwH892L
Hol-U19– HWHol-U
Honor 4A– hnSCL-Q
honor 6x– HWBLN-H
Honor 7– HWPLK
Honor Box Pro– hwHiTV-M1
Honor Box voice– HWM311
Honor Box– m321
Honor V8– HWKNT
Honor3– hwH30-T10
Honor3– hwH30-U10
Honor3– hwhn3-u01
HUAWEI C199– hwC199
HUAWEI C199s– hwC199s
HUAWEI D2-2010– hwD2-2010
HUAWEI FRD-L02– HWFRD

Huawei G620-A2– hwG620-A2
HUAWEI G7 Plus– HWRIO
HUAWEI G7-L01– hwG7-L01
HUAWEI G7-L02– hwG7-L02
HUAWEI G7-L11– hwG7-L11
HUAWEI G7-UL20– hwG7-UL20
HUAWEI G8– hwRIO-L02
HUAWEI G8– hwRIO-L03
HUAWEI G9青春版– HWVNS-Q
HUAWEI GR3– HWTAG-L6753
HUAWEI GR5– HWKII-Q
HUAWEI GT3– HWNMO-H
HUAWEI GX8– hwRIO-L01
HUAWEI MediaPad 10 Link+– hws10231l
HUAWEI MediaPad M1 8.0– hws8301l
HUAWEI MediaPad T2 10.0 pro– HWFDR
HUAWEI MediaPad T2 7.0– hwbgo
HUAWEI MediaPad X1 7.0– hw7d501l
HUAWEI MT1-U06– hwmt1-u06
HUAWEI nova– HWCAN
HUAWEI nova– HWCAZ
HUAWEI P6– hwp6-u06
HUAWEI RIO-CL00 – hwRIO-CL00
HUAWEI ShotX– HWATH
HUAWEI Y3II– HWLUA-L6735
HUAWEI Y3II– HWLUA-U6582
HUAWEI Y3III– HWCRO-L6737M
HUAWEI Y3III– HWCRO-U6580M
HUAWEI Y5 2017– HWMYA-L6737
HUAWEI Y5 2017– HWMYA-U6580
HUAWEI Y536-A1– hwY536A1
HUAWEI Y5II– HWCUN-L6735
HUAWEI Y5II– HWCUN-U6582
HUAWEI Y6 Elite– HWLYO-L6735
HUAWEI Y6 Pro– HWTIT-AL00
HUAWEI Y6 Pro– HWTIT-L6735
HUAWEI Y6 Pro– HWTIT-L8916
HUAWEI Y6 Pro– HWTIT-U6582

HUAWEI Y6II– HWCAM-H
HWT31– hwfdra04l
Kiwi-2– HWH710VL-Q
LISZT– hwliszt
M2– HWMozart
M3– hwbeethoven
Mate 7– hwmt7
Mate 8– HWNXT
MATE 9– HWMHA
Mate 9Pro– HWLON
Mate S– HWCRR
Mate– hwmt1-t00
Mate2– hwmt2-c00
MediaPad– hwt1701
MT2-L01– hwmt2-l01
MT2-L02– hwmt2-l02
MT2-L03– hwMT2L03
MT2-L05– hwmt2-l05
P6– hwp6-c00
P6– hwp6-t00
P6S-L04– hwp6s-l04
P6S-U06– hwp6s-u06
P7 mini– hwP7Mini
P7– hwp7
P8 Lite– hwALE-Q
P8 青春版– hwALE-H
P8– HWGRA
P9 Plus– HWVIE
P9– HWEVA
PE-TL10– hwPE
SC-CL00– HWSC-CL00
SC-UL10– HWSC-UL10
Sensa LTE– HWH715BL-Q
T1 10– hwt1a21l
t1_8p0lte– hwt1821l
T1– hwt1823l
UNION– hwY538
X2– HWGemini

Y221-U03– QAY221-U
Y221-U12– HWY221-U
Y336-U02– HWY336-U
Y360-U23– HWY360-U
Y360-U93– HWY360-U6572
Y520-U33– HWY520-U
Y523-L076– HWY523
Y540-U01– HWY540-U
Y541-U02– HWY541-U
Y550-L01– hwY550-L01
Y550-L02– hwY550-L02
Y550-L03– hwY550-L03
Y560-CL00– HWY560-CL
Y560-L01– HWY560-L
Y560-U02– HWY560-U
Y6– hwSCC-Q
Y6– hwSCL-Q
Y6– hwSCLU-Q
Y625-U03– KVY625-U
Y625-U51– HWY625-U
Y635-L01– hwY635
华为**G9青春版**– HWVNS-H
华为**揽阅M2青春版7.0**– hwple703l
华为**畅享6**– HWNCE-L6750
华为**畅享6S**– HWDIG-L8940
荣耀**5X**– HNKIW-Q
荣耀**Note8**– hwedison
荣耀畅玩**4C**– hwCHM-H
荣耀畅玩**4X**– hnCHE-H
荣耀畅玩**5A**– HNCAM-H
荣耀畅玩**5A**– HNCAM-Q
荣耀畅玩**5A**– HWCAM-Q
荣耀畅玩**5C**– HNNEM-H
麦芒**4**– hwRIO-AL00
麦芒**5**– HWMLA

INTEL

Cloudpad One 6.95– one695_1_coho
Cloudpad One 7.0– one7_0_4_coho
Cloudpad One 8.0– one8_0_1_coho
SurfTab xintron i 7.0– st70408_4_coho
ViewPadi7Q– vsi7q_1_coho
ViewPadi8Q– vsi8q_1_coho

KYOCERA CORPORATION

404KC– 404KC
503KC– 503KC
BASIO– KYV32
Brigadier– E6782
DIGNO L– KYV36
DIGNO T– 302KC
DuraForce PRO– E6820
DuraForce XD– E6790
DuraForce XD– E6790TM
DuraForce– E6560
DuraForce– E6560C
DuraForce– E6560L
DuraForce– E6560T
DuraForce– E6762
DuraScout– E6782L
Hydro AIR– C6745
Hydro ICON– C6730
Hydro REACH– C6743
Hydro SHORE– C6742A
Hydro VIBE– C6725
Hydro VIEW– C6742
Hydro WAVE– C6740
Hydro WAVE– C6740N
INFOBAR A03– KYV33
KC-01– KC-01
LifeWatch Universal Gateway– CD8100
LUCE– KCP01K
miraie– KYL23
Qua phone (KYV37)– KYV37

S301– KC-S301AE
SZJ201– SZJ201
TORQUE G01– KYY24
TORQUE G02– KYV35
TORQUE(KC-S701)– KC-S701
TorqueXT– E6715
URBANO L03– KYY23
URBANO V01– KYV31
URBANO V02– KYV34
URBANO V03– KYV38

LGE

DM-01G– DM-01G
DM-02H– DM-02H
Enact– fx3q
F60– e2
F60– e2ds
F60– e2n
F60– e2nac
F60– e2nam
F60– e2nas
F60– e2nav
G Pad 10.1 LTE– e9lte
G Pad 10.1– e9wifi
G Pad 10.1– e9wifin
G Pad 7.0 LTE– e7lte
G Pad 7.0– e7wifi
G Pad 8.0– e8wifi
G Pad II 8.0– t8wifi
G PADIII 10.1– th10
G Pro2– b1
G Pro2– b1w
G Stylo– g4stylusw
G Vista– b2lds
G Vista– x10
G2 mini 4G LTE– g2mv
G2 MINI– g2m
G2 MINI– g2mds

G2 MINI– g2mss
G3 Beat– jagdsm
G3 Beat– jagn
G3 S– jag3gds
G3 S– jag3gss
G3 S– jagnm
G3 Screen– liger
G3 Stylus– b2ldsn
G3 Stylus– b2lss
G3 Stylus– b2lssn
G3 Vigor– jagc
G4 Beat– p1bssn
Gx2– b2ln
Homeboy2– t8wi7u
Ice cream Smart– vfpv
L Bello– luv80ds
L Fino– l70p
L Fino– l70pds
L Fino– l70pn
L20– luv20ds
L20– luv20ss
L20– luv20ts
L30 Sporty– luv30ds
L30 Sporty– luv30ss
L45– lo_2
L45– lo_2_ds
L50 Sporty– luv50ds
L50 Sporty– luv50ss
L50 Sporty– luv50ssn
L5000– l5000
L60– lo_1
L65– w55
L65– w55ds
L65– w55n
L70– w5
L70– w5ds
L70– w5n
L70– w5ts

L90 Dual– w7dsn
L90– w7
L90– w7ds
L90– w7n
LBello– luv80ss
LG Bello II– v10
LG Class– c100n
LG Classic– y30t
LG Classic– y30tc
LG Destiny– y50
LG F570S– yg
LG F70– f70
LG F70– f70n
LG G Flex– zee
LG G Flex2– z2
LG G Pad 8.0 LTE– e8lte
LG G Pad 8.3 Google Play Edition– palman
LG G Pad 8.3 LTE– altev
LG G Pad 8.3– awifi
LG G Pad F 8.0– t8lte
LG G Pad F7.0– e7iilte
LG G Pad II 10.1 FHD– t1wifi
LG G Pad II 10.1 FHD– t1wifin
LG G Pad II 8.3– altev2
LG G Pad III 10.1 FHD LTE– b5
LG G Pad III 8.0 FHD– b3
LG G Stylo– g4stylus
LG G Stylo– g4stylusc
LG G Stylo– g4stylusds
LG G Stylo– g4stylusdsn
LG G Stylo– g4stylusn
LG G Vista 2– p1v
LG G Vista– b2l
LG G2– g2
LG G3 A– tigers
LG G3 Cat.6– tiger6
LG G3– g3
LG G4 Beat– p1bdsn

LG G4 Stylus– mp1s3gds
LG G4 Stylus– mp1s3gss
LG G4– p1
LG G4c– c90
LG G4c– c90n
LG G4s– p1bds3g
LG G5 SE– alicee
LG G5– h1
LG Gpad X 10.1– t1lte
LG Gx– omega
LG Gx– omegar
LG Joy– y30
LG Joy– y30dsf
LG Joy– y30f
LG K10 LTE– m253
LG K10 LTE– m253n
LG K10– m209n
LG K10– m216
LG K10– m216n
LG K10– m23g
LG K3 LTE– mme0
LG K3 LTE– mme0n
LG K3– me0
LG K4 LTE– me1
LG K4 LTE– me1ds
LG K5– d3
LG K7– m13g
LG K8 LTE– mm1vn
LG K8– m1v
LG K8– mm1v
LG L80 Dual– w6ds
LG L80 Single– w6
LG Leon 4G LTE– c50
LG Leon 4G LTE– c50ds
LG Leon 4G LTE– c50n
LG Leon– my50
LG Leon– my50ds
LG M1– m1

LG M1– m1ds
LG Magna LTE– mc90
LG Magna– my90
LG Magna– my90ds
LG Optimus G Pro– geefhd
LG Optimus G Pro– geefhd4g
LG Optimus G– geehrc
LG Optimus G– geehrc4g
LG Optimus L9 II– l9ii
LG Optimus LTE3– fx1sk
LG Optimus Zone 2– w3c
LG Power– y50c
LG Prime Plus 4G – mc90ds
LG RAY– d2
LG Spirit 4G LTE– c70n
LG Spirit LTE– c70
LG Spirit– my70
LG Stylo 2– ph1
LG Stylus2 4G– ph2
LG Stylus2 Plus– ph2n
LG Stylus2– ph1n
LG U– bbg
LG Volt 4G– c70ds
LG Volt II– c90nas
LG Volt LTE– c70w
LG Volt– my70ds
LG Wine Smart– cf
LG X cam– k7
LG X cam– k7n
LG X max– mk6m
LG X power– mk6p
LG X power– mk6p55
LG X power– mk6pn
LG X screen– k5
LG X screen– k5n
LG X Style– k6b
LG Zero– c100
LG-AS876– x5

LG-D150– w35
LG-D157f– w35ds
Optimus Exceed 2– w5c
Optimus F6– f6
Optimus GK– gvfhd
Optimus L40– w3
Optimus L40– w3ds
Optimus L40– w3ts
Optimus Vu2– vu2kt
Optimus Vu2– vu2sk
Optimus Vu2– vu2u
Premier– m209
Qua phone PX– JSG
Spray– e2jps
Stylo 2 V– mph1
TBD– aka
V10– pplus
V20– elsa
VU3– vu3
Wine Smart 3G– vfp3g
Wine Smart– vfp
X Mach– sjr
X power– k6p
Y25– y25
Y25– y25c
Zone3– e1q

LAVA INTERNATIONAL

Pixel V1– PixelV1_sprout
Pixel V1– PixelV1G_sprout

LENOVO MOBILE

32A3 40A3 43A3 49A3– uzi
A3000– A3000
B6000-F– B6000
B8000-F– B8000

E4506– E4506

E5005– B5060

E5504– B5530

E731x– LIFETAB_E731X

K1– K1

LaVieTab PC-TE508BAW– TE508BAW

LaVieTab PC-TE508S1W/LaVieTab PC-TE508S1L– PC-TE508S1_nec

LaVieTab PC-TE510S1L– PC-TE510S1_nec

Lenovo A10-70LC– A10-70LC

Lenovo A1000m– scx35_sp7731gea_taichi

Lenovo A1010– A1010a20

Lenovo A2010-a– A2010-a

Lenovo A2010I36– A2010I36

Lenovo A2016a40– A2016a40

Lenovo A2016b30– A2016b30

Lenovo A2016b31– A2016b31

Lenovo A2020a40– angus3A4

Lenovo A2020a40– angus3A41

Lenovo A2580– A2580

Lenovo A2800– A2800-d

Lenovo A2860– A2860

Lenovo A319– A319

Lenovo A31910t30– angus3T3

Lenovo A320t– A320t

Lenovo A328– A328

Lenovo A328t– A328t

Lenovo A3300-GV– A3300-GV

Lenovo A3300– A3300-H

Lenovo A3300– A3300-HV

Lenovo A3300– A3300-T

Lenovo A338t– A338t

Lenovo A3500-F– A3500F

Lenovo A3500-H– A3500H

Lenovo A3500– A3500

Lenovo A3500– A3500HV

Lenovo A358t– A358t

Lenovo A3600-D– A3600-d

Lenovo A3600u– A3600u

Lenovo A360t– A360t
Lenovo A368t– A368t
Lenovo A3800-D– A3800-d
Lenovo A380t– A380t
Lenovo A3860– A3580
Lenovo A3860– A3860
Lenovo A3900– pxa1L88H2
Lenovo A399– Aiken
Lenovo A5000– A5000
Lenovo A536– A536
Lenovo A5500-F– A5500-F
Lenovo A5500-H– A5500-H
Lenovo A5500-HV– A5500-HV
Lenovo A5500– A5500
Lenovo A5800-D– A5800-D
Lenovo A588t– LenovoA588t
Lenovo A60+– Android
Lenovo A6000-I– Kraft-A6000-I
Lenovo A6000– Kraft-A6000
Lenovo A6010– A6010
Lenovo A606– A606
Lenovo A616– A616
Lenovo A6600 Plus– A6600a40
Lenovo A6600– A6600d40
Lenovo A6800– A6800
Lenovo A688t– A688t
Lenovo A690e– A690e
Lenovo A7-30GC– A7-30GC
Lenovo A7-30H– A7-30H
Lenovo A7000 Plus– A7000plus
Lenovo A7000– A7000-a
Lenovo A7600-F– A7600-F
Lenovo A7600-H– A7600-H
Lenovo A7600-HV– A7600-HV
Lenovo A7600– A7600
Lenovo A7600– aiocmcc_ttp
Lenovo A7600– aiocu_wtftp
Lenovo A768t– airplayt

Lenovo A7700– A7700
Lenovo A8-50– A8-50L
Lenovo A8-50– A8-50LC
Lenovo A805e– airplayep
Lenovo A806– A806
Lenovo A808t-i– A808t-i
Lenovo A808t– A808t
Lenovo A816– airplayw
Lenovo A828– A858
Lenovo A858t– A858t
Lenovo A916– A916
Lenovo A936– A936
Lenovo A938t– A938t
Lenovo B8080– B8080
Lenovo K10e70– K10e70
Lenovo K3 Note– aio_3m_otfp_m
Lenovo K3 Note– aio_otfp
Lenovo K3 Note– K50a40
Lenovo K30-E– Kraft-E
Lenovo K30-T– Kraft-T
Lenovo K30-TM– Kraft-TM
Lenovo K30-W– Kraft-W
Lenovo K32– K32c36
Lenovo K32c30– K32c30
Lenovo K5 Note– A7020a40
Lenovo K5 Note– A7020a48
Lenovo K5 Note– k52_e78
Lenovo K5 Note– k52_t58
Lenovo K5 Plus– A6020a46
Lenovo K5– A6020a40
Lenovo K5– A6020a41
Lenovo K5– A6020I36
Lenovo K5– A6020I37
Lenovo K50-T5– aio_otfp_m
Lenovo K50– aio_3m_otfp
Lenovo K50– K50-t5
Lenovo K52t38– k52_t38
Lenovo K80M– K80M

Lenovo K910– kiton
Lenovo K910e– kitone
Lenovo K910L– K910L
Lenovo K920/VIBE Z2 Pro– kingdomt
Lenovo K920/VIBE Z2– kingdom_row
Lenovo P1– P1a42
Lenovo P1– passion
Lenovo P1– passionc5
Lenovo P2– kuntao
Lenovo P2– P2a42
Lenovo P70– P70-A
Lenovo P70– P70-t
Lenovo P780– P780
Lenovo P90– P90
Lenovo PB1-750M/Lenovo PHAB– PB1-750M
Lenovo PB1-770M/Lenovo PHAB Plus– PB1-770M
Lenovo PB1-770N– PB1-770N
Lenovo PB2 plus– PB2-670M
Lenovo PB2-650Y– PB2
Lenovo PHAB 2 Plus– PB2-670Y
Lenovo PHAB2 Pro– PB2PRO
Lenovo S1– S1a40
Lenovo S1La40– S1La40
Lenovo S580– S580
Lenovo S60– sisleylr
Lenovo S60– sisleylt
Lenovo S60– sisleylw
Lenovo S650_ROW– S650_ROW
Lenovo S650– S650
Lenovo S658t– S658t
Lenovo S660– S660
Lenovo S820– S820
Lenovo S850– S850
Lenovo S850t– S850t
Lenovo S856– shellamx
Lenovo S856– shellr
Lenovo S856– shellr_s
Lenovo S856– shellw

Lenovo S858t– Selected
Lenovo S860– S860
Lenovo S860e– shelle
Lenovo S898t+– S898tp
Lenovo S90-A– sisleyr
Lenovo S90-T– sisleyt
Lenovo S90-U– sisleyw
Lenovo S90– sisleye
Lenovo S920– S920
Lenovo S920– S920_ROW
Lenovo S930_ROW– S930_ROW
Lenovo S930– S930
Lenovo S938t– S938t
Lenovo S939– S939
Lenovo S960– S960
Lenovo TAB 10– TB-X103F
Lenovo TAB 2 A10– A10-70F
Lenovo TAB 2 A10– A10-70L
Lenovo TAB 2 A7-10F– Tab2A7-10F
Lenovo TAB 2 A7-20F– Tab2A7-20F
Lenovo TAB 2 A7-30F– A7-30F
Lenovo TAB 2 A7-30HC– A7-30HC
Lenovo TAB 2 A7-30TC– A7-30TC
Lenovo TAB 2 A8-50F– A8-50F
Lenovo TAB 3 850F– TB3-850F
Lenovo TAB 3 850M– TB3-850M
Lenovo TAB A10-80HC– A10_80HC
Lenovo TAB S8-50F– S8-50F
Lenovo TAB S8-50L– S8-50L
Lenovo TAB S8-50LC– S8-50LC
Lenovo TAB3 7 Plus– TB-7703F
Lenovo TAB3 7 Plus– TB-7703X
Lenovo TAB3 730F– TB3-730F
Lenovo TAB3 730M– TB3-730M
Lenovo TAB3 730X– TB3-730X
Lenovo TAB3 X70L– TB3-X70L
Lenovo TB2-X30F– TB2-X30F
Lenovo TB2-X30L– TB2-X30L

Lenovo TB2-X30M– TB2-X30M
Lenovo TB3 8 Plus– TB-8703F
Lenovo TB3 8 Plus– TB-8703X
Lenovo TB3-601LV– 601LV
Lenovo TB3-602LV– 602LV
Lenovo TB3-710F– TB3-710F
Lenovo TB3-710I– TB3-710I
Lenovo TB3-X70F– TB3-X70F
Lenovo VIBE K10– K10a40
Lenovo VIBE K6 Note– K53b37
Lenovo VIBE K6 Power– K33a42
Lenovo VIBE K6– K33a48
Lenovo VIBE K6– K33b36
Lenovo VIBE K6– K33b37
Lenovo VIBE X3 Lite– A7010a48
Lenovo VIBE X3 Lite– k5fp
Lenovo VIBE X3 Lite– k5fp_m
Lenovo X2 Pro– s7
Lenovo X2-CU/VIBE X2– X2-CU
Lenovo X2-TO/VIBE X2– X2-TO
Lenovo X2-TR/VIBE X2– X2-TR
Lenovo X2– X2-AP
Lenovo X2– X2-EU
Lenovo X3a40– x3_row
Lenovo X3c50– X3c50
Lenovo X3c70– X3c70
Lenovo YOGA A12– YOGA-A12
Lenovo YOGA BOOK– yeti
Lenovo Yoga TAB3 Plus– YT-X703F
Lenovo Yoga TAB3 Plus– YT-X703L
Lenovo Yoga TAB3 Plus– YT-X703X
Lenovo YOGA Tablet Pro-1050L/Yoga Tablet 2– YT2
Lenovo YT3-850F/Lenovo YOGATab3– YT3-850F
Lenovo YT3-850L/Lenovo YOGATab3– YT3-850L
Lenovo YT3-850M/Lenovo YOGATab3– YT3-850M
Lenovo YT3-X50F/Yoga3 Tablet– YT3-X50F
Lenovo YT3-X50L/Yoga3 Tablet– YT3-X50L
Lenovo YT3-X50M/Yoga3 Tablet– YT3-X50M

Lenovo YT3-X90X/YOGA3 Tablet Pro– YT3
Lenovo Z2 Plus– z2_plus_hw
Lenovo Z2– z2r
Lenovo Z2– z2t
Lenovo Z2w– z2w
Lenovo Z90/VIBE Shot– zoom_fdd
Lenovo Z90/VIBE Shot– zoom_tdd
Lenovo Z90a40/VIBE Shot– zoom_row
Lenovo– PB1-770P
Lenovo S960– S960_ROW
Lenovo VIBE K6 Note– K53a48
LIFETAB E723X– LIFETAB_E723X
LIFETAB E732X– LIFETAB_E732X
LIFETAB E732X– LIFETAB_E733X
LIFETAB P1034X– lifetab_p1034x
LIFETAB P733x– lifetab_p733x
LIFETAB P831X– lifetab_p831x
LIFETAB P891X– lifetab_p891x
LIFETAB S1032X– S1032X
LIFETAB S1033X– LIFETAB_S1033X
LIFETAB S1034X– lifetab_s1034x
LIFETAB S785X– LIFETAB_S785X
LIFETAB S786x– LIFETAB_S786X
LIFETAB S831X– LIFETAB_S831X
LIFETAB_S1036X– lifetab_s1036x
MEDION E5004– E5004
Moto E3 Power– taido_row
Moto E3– taidos_row
Motorola M– XT1663
Motorola Moto M– kungfu_m
NEC PC-TE507FAW– TE507FAW
NEC PC-TS508FAM– PC-TS508FAM
P1032X– P1032X
P1035X– P1035X
P1050X– P1050X
P5004– P5004
P5005– P5005
P5015– P5015

P780– P780_ROW
P850X– P850X
PC-508T1W– 508T1W
PC-708T1W– 708T1W
S1035X– S1035X
S5000– S5000
S5004– S5004
S5504– B5531
S7322– LIFETAB_S732X
S820– S820_ROW
S90-L– sisleyr_amx
Softbank 501LV– 501LV
X6001– X6001
Z2 Pro– z2_row
Z2– z2_plus
ZUK Z1– k9
ZUK Z1– Z1

LONGCHEER

Aquaris A4.5– Aquaris_A45_sprout
General Mobile 4G– gm4gtkc_s_sprout
GM5 Plus d– gm5plus_sprout
GM5 Plus Turkcell– gm5plustkc_s_sprout
GM5 Plus– gm5plus_s_sprout
H220– ctih220_sprout
i-mobile IQ II– imobileiq2_sprout

MEDIATEK

A10– A10_sprout
Canvas A1– AQ4501_sprout
Canvas A1– AQ4502_sprout
Dream Uno– Mi-498_sprout
Nexian journey one– Mi438S_sprout
One X– A65_sprout
One– H940_sprout
Pakistan– A1_sprout

Roar A50– Roar_A50_sprout

Sparkle V– Sparkle_V_sprout

UNO– UNO_sprout

MICROMAX

A56– A56

A75– A75

A88– A88

BOLT– A069

BOLT– A34

Bolt– D304

Bolt– D333

Bolt– Q303

Bolt– Q326

BOLT– Q332

BOLT– Q338

Bolt– Q341

Bolt– Q346

Bolt– Q381

Bolt– Q383

CANVAS 2 COLOURS– A120

Canvas 5 Lite– Q463

Canvas 5– E481

Canvas 6 Pro– E484

Canvas 6– E485

Canvas AMAZE– Q395

CANVAS DOODLE 3– MicromaxA102

CANVAS ENGAGE– A091

CANVAS ENTICE– A105

Canvas Evok– E483

Canvas Fire 4G – Q462

Canvas Fire 5– Q386

Canvas FIRE4G– Q411

CANVAS GOLD– A300

Canvas Juice 3+– Q394

Canvas Juice 4– Q382

Canvas Juice3– Q392

CANVAS KNIGHT– A350

Canvas Mega 2– Q426
Canvas Mega– E353
Canvas Mega– Q417
Canvas Pace 4G– Q416
Canvas Pace Mini– Q401
Canvas Play 4G– Q412
Canvas Play4G – Q469
CANVAS POWER– A96
Canvas Selfie 4– Q349
Canvas Spark 2 Plus– Q350
Canvas Spark 3– Q380N
Canvas Spark 3– Q385
Canvas SPARK2– Q334
Canvas tab– P290
Canvas tab– P680
Canvas Tab– P681
Canvas Tab– P701
Canvas Tab– P702
Canvas Tab– P810
CANVAS UNITE 2– A106
Canvas Unite 4 Pro– Q465
Canvas Unite 4– Q427
Canvas Xpress 4g– Q413
Doodle 4– Q491
Nitro 3– E352
Q327– Q327
YUNICORN– YUNICORN
YUNIQUE– YU4711
Yureka Note– YU6000
YUREKAS– YUREKAS
Yutopia– YUTOPIA

MOBIWIRE

Ahiga– Ahiga
Cygnus mini– Cygnus_mini
Pegasus– Pegasus
Star Trail 5– STARTRAIL5

Star Trail 6– STARTRAIL6

Telenor Smart– Telenor_Smart

Telenor SmartPlus– Telenor_SmartPlus

V.35– up11_h1_vsn

VSN V.45– up06_h26_v45

MOTOROLA

DROID MAXX 2– lux

Droid MAXX– obake-maxx

Droid Mini– obakem

DROID RAZR HD– vanquish

DROID RAZR HD– vanquish_u

DROID RAZR i– smi

DROID RAZR M– scorpion_mini

DROID RAZR– cdma_spyder

Droid RAZR– umts_spyder

DROID Turbo 2– kinzie

Droid Turbo– quark

Droid Ultra– obake

DROID4– cdma_maserati

Electrify M– solstice

Moto E (1st Gen)– condor_cdma

Moto E (1st Gen)– condor_udstv

Moto E (1st Gen)– condor_umts

Moto E (1st Gen)– condor_umtsds

Moto E (2nd Gen)– otus

Moto E (2nd Gen)– otus_ds

Moto E with 4G LTE (2nd Gen)– surnia_cdma

Moto E with 4G LTE (2nd Gen)– surnia_uds

Moto E with 4G LTE (2nd Gen)– surnia_udstv

Moto E with 4G LTE (2nd Gen)– surnia_umts

Moto G (1st Gen)– falcon_cdma

Moto G (1st Gen)– falcon_umts

Moto G (1st Gen)– falcon_umtsds

Moto G (2nd Gen)– titan_udstv

Moto G (2nd Gen)– titan_umts

Moto G (2nd Gen)– titan_umtsds

Moto G (3rd Gen)– osprey_cdma

Moto G (3rd Gen)– osprey_u2
Moto G (3rd Gen)– osprey_ud2
Moto G (3rd Gen)– osprey_uds
Moto G (3rd Gen)– osprey_udstv
Moto G (3rd Gen)– osprey_umts
Moto G (4) Play– harpia_n
Moto G Turbo Edition– merlin
Moto G with 4G LTE (1st Gen)– peregrine
Moto G with 4G LTE (2nd Gen)– thea
Moto G with 4G LTE (2nd Gen)– thea_ds
Moto G with 4G LTE (2nd Gen)– thea_umtsds
Moto G(4) Plus– athene_f
Moto G(4)– athene
Moto G(4)– athene_t
Moto G4 Play– harpia
Moto G4 Play– harpia_t
Moto MAXX– quark_umts
Moto X (1st Gen)– ghost
Moto X (2nd Gen)– victara
Moto X Force– kinzie_uds
Moto X Play– lux_uds
Moto X Pro (China)– shamu_t
Moto X Pure Edition– clark
Moto X Style– clark_ds
Moto Z Play Droid– addison
Moto Z– griffin
Motorola Atrix HD– qinara
Motorola RAZR M– smq
RAZR D1– hawk35_umts
RAZR D3– hawk40_umts
XT905– smq_u

NVIDIA

TegraNote– tegranote7c
TegraNote– tegranote
SHIELD Tablet– shieldtablet

ONEPLUS**OnePlus X**– OnePlus**OnePlus3**– OnePlus3**OPPO****A1601**– A1601**A33f**– A33**A37f**– A37f**A57t**– A57**CPH1701**– CPH1701**OPPO A37**– A37**OPPO R9**– R9**OPPO R9s Plus**– CPH1611**OPPO R9s Plus**– R9sPlus**R9sk**– R9sk**X9009**– X9009**PANASONIC CORPORATION****Altus 18**– Altus18**Altus 24**– Altus24**CEH1**– CEH1**CER2**– CER2**Eco11 v2**– Eco11v2**Eco9 v2**– Ecov2**ELUGA U**– ELUGA_U**ELUGA U2**– ELUGA_U2**FZ-B2**– fz_b2bb**HDPSEB v2**– HDPSEBv2**LUMIX CM1**– DMC-CM1**Panasonic ELUGA A**– ELUGA_A**Panasonic ELUGA I**– ELUGA_I**Panasonic ELUGA L 4G**– ELUGA_L_4G**Panasonic ELUGA S Mini**– ELUGA_S_Mini**Panasonic ELUGA S**– ELUGA_S**Panasonic Eluga Z**– ELUGA_Z**Panasonic P11**– P11**Panasonic P41 HD**– P41HD

Panasonic P41– P41

Panasonic P61– P61

Panasonic T11– T11

Panasonic T40– T40

Panasonic T41– T41

Panasonic T9– T9

UN-W700– F1

VHS v2– VHS

PANTECH

IM-100K– ef71k

IM-100S– ef71s

IM-A850K– ef49k

IM-A850L– ef50l

IM-A850S– ef48s

IM-A860K– ef51k

IM-A860L– ef51l

IM-A860S– ef51s

IM-A870K– ef52k

IM-A870L– ef52l

IM-A870S– ef52s

IM-A880S– EF56S

IM-A910K– ef63k

IM-A910L– ef63l

IM-A910S– ef63s

IM-A920S– ef65s

IM-A940K– ef65dk

VEGA Secret Note– EF59K

VEGA Secret Note– EF59L

VEGA Secret Note– EF59S

VEGA Secret UP– ef60s

VEGA Secret UP– ef61k

VEGA Secret UP– ef62l

PEGATRON

101P51C– 101P51C

101P51D– 101P51D

800P31C– 800P31C
800P71D– 800P71D
A1603– A1603
A35– A35
A5 Easy– A5_Easy
A5 Lite – A5_Lite
A5 Quad Plus– A5_Quad_Plus
A5 Ready– A5_Ready
A6 Duo– A6_Duo
A6 Lite– A6_Lite
A7 Lite– A7_Lite
A7100 X3– A7100_X3
A7101_X3_mini– A7101_X3_mini
A713_Vivo_Pro– A713_Vivo_Pro
A714 Vivo Play– A714_Vivo_Play
A715_Inspire_One– A715_Inspire_One
A716 Inspire Life– A716_Inspire_Life
A726 Infinity Lite– A726_Infinity_Lite
A727_Infinity_Pro– A727_Infinity_Pro
A728_XP2– A728_XP2
A737_XploraZ– A737_XploraZ
A770_XL7– A770_XL7
Agora 6 Plus– Kogan_Agora_6Plus
Akta A4– Akta_A4
Amazing A8– D78
Amazing X3– TX3
American Girl Tablet– NBTY07SMKG
Aqua 5.5 VR– Aqua_5_5_VR
Aqua Aura 2GB– Aqua_Aura_2GB
Aqua Ring– Aqua_Ring
AQUOS P1– P1X
AT1001– AT1001
AT701– AT701
Aura Power– Aura_Power
AX501Q– AX501Q
Bay– Bay
Beeline_Tab IS– Beeline_Tab_IS
Bolt– Bolt

C6 Duo– C6_Duo
C6 Quad 4G– C6_Quad_4G
C7– C2107
CatS50c– CatS50c
Classic_Pro– Classic_Pro
Classic– Classic
CLP293– CLP293
CMP791– CMP791
CMP793– CMP793
CMP797– CMP797
CMP798– CMP798
CS1 8.0– cs180
Cynus E7– Cynus_E7
Cynus F10– Cynus_F10
Cynus F9 4G– Cynus_F9_4G
Cynus_E8– Cynus_E8
D455– D455
D504– D504
Discovery II Mini– Discovery_II_Mini
Druid_L10– Druid_L10
DW-21(A)– DA-21
E2 Jump– ALLVIEW_E2_Jump
E3 Jump– E3_Jump
E3 Living– E3_Living
E3 Sign– E3_Sign
E4 Lite– E4_Lite
E4– E4
e6_plus– e6
e6_plus– e6_plus
E8– GBL5805QM
EL-20-3710– TCV5
Elite– Elite
Eluga A2– Eluga_A2
Eluga Arc 2– Eluga_Arc_2
Eluga Arc– ELUGA_Arc
Eluga I2– ELUGA_I2
ELUGA I3 Mega– Eluga_I3_Mega
Eluga I3– Eluga_I3

Eluga Icon 2– ELUGA_Icon2
Eluga Klik – Eluga_Klik
Eluga Mark 2 – Eluga_Mark_2
ELUGA Prim – ELUGA_Prim
Eluga Pulse X – ELUGA_Pulse_X
Eluga Ray – ELUGA_Ray
Eluga Ray X – ELUGA_Ray_X
Eluga Tapp– Eluga_TAPP
ELUGA Turbo – ELUGA_Turbo
Eluga_Note– ELUGA_Note
ENERGY X1– ENERGY_X1
ENERGY X2– ENERGY_X2
Epic P7– Epic_P7
F103 Pro– GIONEE_GBL7360
F552– F552
FB100– FB100
FGAD– FGAD
Fisher Price Learning Tablet– NBFP07PMKG
Flare 5– X630
Flare A1– FlareA1
Flare J3 Plus– H620
Flare J3– FlareJ3
Flare J3– H680
Flare J7– Flare_J7
Flare S5 Lite DTV– FlareS5LiteDTV
Flare S5 Plus– Flare_S5_Plus
Flare X– Flare_X
Fluo XL Premium Edition– MFC510FR1
Fluo XL– MFC191FR2
Fluo– MFC145FR1
FT7– FT7_tw
FZ-A2A– fz_a2a
FZ-B2D– fz_b2d
FZ-N1– FZ-N1
FZ-N1– FZ-N1F
FZ-N1– FZ-N1VU
FZ-N1– FZ-N1VUCF
FZ-N1– FZ-N1VUF

FZ-X1– FZ-N1VUC
FZ-X1– FZ-X1
FZ-X1– FZ-X1VU
FZ-X1– FZ-X1VUC
G4– G4
G5– G5
G6– G6
Graphos A10– Graphos_A10
GTB1050– GTB1050
GTB850– GTB850
HY1-5085– HY1_5085
i2 PRO– i2_PRO
ICRAIG_CLP_291– ICRAIG_CLP_291
ICRAIG_CMP_771– ICRAIG_CMP_771
ICRAIG_CMP_773– ICRAIG_CMP_773
ICRAIG_CMP770– ICRAIG_CMP770
InFocus Epic 1– JGZ
InFocus M2– LSO
InFocus M2+– LSC
InFocus M210– M210
InFocus M260– ZL2
InFocus M320– M320
InFocus M320e– M320e
InFocus M350 – G30
InFocus M350 – G3E
InFocus M370– FOT
InFocus M370i– FAT
InFocus M377– FO7
InFocus M415– ZL3
InFocus M430– HGO
InFocus M460– G3T
InFocus M510t– TID
InFocus M530– G20
InFocus M550 3D– ZD1
InFocus M550– ZZ1
InFocus M680 – G42
InFocus M808– ZM1
InFocus M810– VNA

InFocus M812– VN2
InFocus M812i– V2I
Inspire– VisionTouchInspire
INTEX AQUA AMAZE+– INTEX_AQUA_AMAZE_PLUS
Intex Aqua Power 4G– Intex_Aqua_Power_4G
Intex Aqua Pride– AquaPride
Intex Aqua View– AquaView
Iris– Iris
J5– J5
J7 PRO– J7_PRO
J7– J7
Jax X– Jax_X
jax_S– Jax_S
Jax_X_TM– JAX
JazzX JS7 PRO– JS7_PRO
JS10– JAZZX_JS10
K5– K5
Klic– SA
L575– L575
Le 2– le_s2
Le 2– le_s2_ww
Le Pro3– le_zl1
Le S3– le_s2_na
Le X509– X3_HK
Le1– Le1
Letv x600– x600
LexiTab 10"– mfc511
LexiTab 7" – MFC146ES
LexiTab 7"– MFC146DE
LexiTab 7"– MFC146EN
LexiTab 7"– MFC146FR
Life– VisionTouchLife
LS-4006– LS-4006
LS-5004– LS-5004
LS-5020– LS-5020
LT650– LT650
LT680– QMobile_LT680
LT700 PRO– LT700_PRO

LT700– GBL7325QM
LT750– LT750
M2_3G– G10
M330– D77
M3mini– GiONEE_WBL7315
M5 mini– GiONEE_WBW5616
M505– M505_4G
M511– TID_CHT
M511– TID_TWN
M512– MC2_CN
M518– MC2_APT
M5Pro– Evolio_M5Pro
M6 Lite– GIONEE_WBL7361
M6 Lite– M6_Lite
M6 mirror– GIONEE_WBL7372
M6– BBL7551QM
M6– Evolio_M6
M8– Evolio_M8
Marshall London– KB-1501
Max3 LTE– Max3_LTE
Meitu M4– M4
Meitu M6 – M6
Meitu V4– V4
Meitu V4s– V4s
Mika M3– Mika_M3
Mio Phone– MioPhone2016
MTC SMART Run– SMART_Run
MX50– mx50
my85 DTV– MyPhone_my85_DTV
N6– N6
n7– n7
NOIR A3– A3
NOIR A6– A6
Obi MV1– yam
Omega HD 3S– H115
Omega HD3– H110
P10– P10
P10S– P10S

P10SE– P10SE
P3S– GiONEE_WBW5613
P4 eMagic– P4_eMagic
P41 eMagic– P41_eMagic
P4S– P4S
P5 eMagic– P5_eMagic
P5 Energy– P5_Energy
P5 Lite– P5_Lite
P5 mini– GiONEE_WBW5617
P5_Pro– P5_Pro
P55 Novo– P55_Novo
P55 Novo– P55_Novo_4G
P5L– GiONEE_WBL7352
P5Life– P5Life
P5W– GiONEE_WBW5615
P6 eMagic– P6_eMagic
P6 Energy Lite– P6_Energy_Lite
P6 Energy– P6_Energy
P6 Lite– P6_lite
P6 Plus– P6_plus
P6 Pro– P6_Pro
P6 Qmax– P6_Qmax
P66– P66
P7 Max– GIONEE_WBL5708
P7 PRO_TM– P7_PRO
P7– GIONEE_WBL7365
P71– P71
P75– P75
P77– P77
P8 eMagic– P8_eMagic
P8 Energy mini– P8_Energy_mini
P8 Energy Pro– P8_Energy_PRO
P8 Energy– P8_Energy
P8 Life– P8_Life
P85– P85
P88 – P88
P8W– GIONEE_WBW5620
P9 Energy Lite– P9_Energy_Lite

P9 Energy mini– P9_Energy_mini
P9 Energy– P9_Energy
P9C– P9C
Philips S308– Philips_S308
Philips S309– Philips
Philips S326– S326
Philips S337– S337_AG
Philips S337– S337_BG
Philips S337– scx35_sp7731gea_hd
Philips V387– V387
Philips X586– Philips_X586
Philips X588– X588_RU
Philips X818– X818_EE
Philips X818– X818_RU
Philips Xenium V377– Philips_V377
Philips S398– Philips_S398
Pluri M7– Pluri_M7
Pluri Q8– Pluri_Q8
POC2– CBL7509MM
Power Five– PowerFive
Power Four– PowerFour
Power Ice– BBL7353RV
Power Rage– PowerRage
PowerIceMax– PowerIceMax
PowerRageEvo– PowerRageEvo
Preo P2– Preo_P2
Prime L– PrimeL
Primo GH5 mini– Primo_GH5_mini
Primo GH5– WBW5615WA
Primo NX3– Primo_NX3
Primo NX4 mini– Primo_NX4_mini
Primo NX4– Primo_NX4
Primo R4 Plus– Primo_R4_Plus
Primo R4– Primo_R4
Primo RM2 mini– WBW5616WA
Primo RX5– Primo_RX5
Primo S5– Primo_S5
Primo X4– WALTON_Primo_X4

Primo ZX2 Lite– BBL7505WA
Primo ZX2 mini– Primo_ZX2_mini
Primo ZX2– GBL5805WA
Primo_RM3– Primo_RM3
PRO1– Benten_PRO1
Qmobile E1– QMobile_E1
Qmobile i6 Metal HD– i6_Metal_HD
Qmobile i6 Metal ONE– i6_Metal_ONE
R50A– R50A
R7s Plus– R7sPlus
R7sf– R7sm
R7sfg– R7sf
Remix Mini– rm1g
Robin– ether
S plus– GiONEE_WBL7511
S1 PRO– S1_PRO
S2 Plus– S2_Plus
S2 Pro– S2_Pro
S30– CatS30
s4_pro– s4_pro
S4– QMobile_S4
s4– s4
S40– CatS40
S6 PLUS– QMobile_S6_PLUS
S6– QMobileS6
S6Plus– S6Plus
S6s– GIONEE_WBL7519
S6S– QMobile_S6S
SHARP A1– TSL
SHARP Z2– TSP
SIRIN LABS SOLARIN– solarin
Smart Dual– Beeline
Smart503– MC2
Smartfive– KONROW_Smartfive
Spin Max– H650
Sprint– Sprint
STARTRAIL 8– STARTRAIL
STUDIO 7.0 LTE– blu_s0010tw

STUDIO 7.0 LTE– blu_s0010uu
T30– T30
T44 Lite– T44-Lite
T44– T44
T452– T452
T503– T503
Tasty– Tasty
TC69CA2– TC69CA2_1
TC70RA1– TC70RA1_2
TC80RA1– TC80RA1_3
TC80RA6– TC80RA6_1
TC97RA1– TC97RA1_1
TEI11011– TEI11011MST
TF10EA2– TF10EA2_2
TF10EA2– TF10EA2_4
TF10EA2– TF10EA2_5
TG-L800S– PHX
TG-L900S– JGR
TH-49DX400C– DX00C
TH-55DR600C– TH55DR600C
TH-55DX700C– TH_55DX700C
TH-65DR800C– TH-65DR800C
TI10RA1– TI10RA1_1
Titanium Vista 4G– TitaniumVista4G
TL10RA2– TL10RA2_1
TL10RA3– TL10RA3_1
Touch HD– Touch_HD
TP10RA1– TP10RA1_1
TR10CD3– TR10CD3_1
TR10CD3– TR10CD3_2
TR10RS1– TR10RS1_11
TR10RS1– TR10RS1_19
U50– U50
U70– U70
Ultra Charm– Ultra_Charm
Ultra Dream– Ultra_Dream
Ultra Energy Lite– Ultra_Energy_Lite
Ultra Energy Plus– Ultra_Energy_Plus

Ultra Latitude– Ultra_Latitude
Ultra Storm– Ultra_Storm
Ultra Style– Ultra_Style
USS– grizzlies_telefi4wm
V Tab 7010– VTab7010
V TAB 8010– V_TAB_8010
V1 Viper E– V1_Viper_E
V1 Viper I4G– V1_Viper_I4G
V1 Viper I4G– V1_Viper_I4G_PL
V1 Viper L– V1_Viper_L
V1 Viper S4G– V1_Viper_S4G
V100– QTab_V100
V2 Viper E– V2_Viper_E
V2 Viper I– V2_Viper_I
V2 Viper I4G– V2_Viper_I4G
V2 Viper S– V2_Viper_S
V2 Viper X plus– V2_Viper_X_plus
V2 Viper X– V2_Viper_X
V2 Viper Xe– V2_Viper_Xe
V2 Viper– V2_Viper
V55C– V55C
VA-10J– VA-10J
VIA_S17– VIA_S17
VIA_S18– VIA_S18
Viva 1001G– Viva_1001G
Viva H10 LTE– Allview_VivaH10LTE_KK
Viva H1001 LTE– Viva_H1001_LTE
Viva H7 LTE– Allview_VivaH7LTE_KK
Viva H8 Life– H8_Life
Viva H8 LTE– Allview_VivaH8LTE_KK
Viva H801 LTE– Viva_H801_LTE
Viva H801– Viva_H801
Viva i10HD– Viva_i10HD
Viva i701G– Viva_H701_LTE
Viva i701G– Viva_i701G
Viva i7G– Viva_i7G
vivo PD1612– PD1612
vivo V1– V1

vivo V1Max– Y37
vivo V3– PD1524
vivo V3Lite– V3Lite
vivo V3M A – PD1524B
vivo V3Max + A – PD1523B
vivo V3Max A – PD1523
vivo V3Max– V3Max
vivo V5Plus– V5Plus
vivo X5– X5
vivo X5M– PD1401CL
vivo X5Max S– bbk6752_lwt_kk
vivo X5Pro D– bbk6752_lwt_l
vivo X5Pro V– PD1421V
vivo X6A– PD1415A
vivo X6D– PD1415D
vivo X6Plus A– PD1515A
vivo X6Plus D– PD1501D
vivo X6S A– PD1415BA
vivo X6SPlusA– PD1515BA
vivo X7– PD1602
vivo X7Plus– PD1603
vivo Xplay5A– PD1522A
vivo Y11– Y11
vivo Y15– Y15
vivo Y15S– Y15S
vivo Y21– Y21
vivo Y22– Y22
vivo Y27– Y27
vivo Y28– Y28
vivo Y31– PD1505
vivo Y31– Y31
vivo Y31i– Y31i
vivo Y31L– Y31L
vivo Y33– bbk6735_65c_l
vivo Y35– PD1502L
vivo Y35A– PD1502A
vivo Y51A– PD1510
vivo Y937– PD1503

VPA051– VPA051
W70– W70
W80– WBW5615QM
Wave– Hurricane
Wink City S– Wink_City_S
Wink Share SE– Wink_Share_SE
X2 Soul Lite– X2_Soul_Lite
X2 Soul Mini– X2_Soul_Mini
X2 Soul PRO– X2_Soul_PRO
X2 Soul Style– X2_Soul_Style
X2 Soul Style+– X2_Soul_Style_Plus
X2 Soul Xtreme– X2_Soul_Xtreme
X3 Soul Lite– X3_Soul_Lite
X3 Soul mini– X3_Soul_mini
X3 Soul Plus– X3_Soul_PLUS
X3 Soul Pro– X3_Soul_PRO
X3 Soul Style– X3_Soul_Style
X32– X32
X3Soul– X3_Soul
X55– X55
X66– X66
X700 PRO II– X700_PRO_II
X700 PRO Lite– X700_PRO_Lite
X700 PRO– X700_PRO
X75– WBW5613QM
Xavy_L8– Xavy_L8
Xavy_T7– Xavy_T7
XSLATE_D10– XSLATE_D10
Xylo X A6– Xylo_X
Xylo_X_TM– Xylo
Z10– Z10
Z12 PRO– Z12_PRO
Z12– CBL7521QM
Z14– Z14
Z600– Z600
Z9 Plus– WBL7511QM
Zun X– Zun_X
ZUN XO A6– Zun_XO

ZUN XO– ZUN_XO

Zun XS– Zun_XS

ZX70– zx70

POSITIVO

8MA-A– ochoMA_A_3G

AB10PGN– AB10PGN

First– S410

Positivo BGH 7Di-A– Y210

Positivo BGH Y230– T760

Positivo BGH Y400– Y400

Positivo Next– X500

Positivo OCTA– OCTA

Positivo One– S420

Positivo S380– S380

Positivo S450– S450

Positivo S550– S550

Positivo Selfie– S455

Positivo T1060– t1060

Positivo T750– t750

Positivo Twist 4G– S520_4G

Positivo Twist– S520

Positivo X400– X400

Positivo Ypy AB10H– YPY_AB10H

Positivo Ypy AB10i– Ypy_AB10i

Positivo Ypy AB7F– YPY_AB7F

Quantum FLY– Q7

Quantum Go– Q1

Quantum Go– Q2

Quantum Muv– Q3

quattro– X435

S440– S440

S480– S480

Y1000– Y1000

QUALCOMM INC

General Mobile 4G– gm4g_s_sprout

General Mobile 4G Dual– gm4g_sprout**RAGENTEK****Infinix**– Infinix_X510_sprout**SHARP****306SH**– SG306SH**401SH**– SG401SH**507SH**– eve_sprout**AQUOS Compact SH-02H**– SH-02H**AQUOS CRYSTAL 2**– SG403SH**AQUOS CRYSTAL X**– SG402SH**AQUOS EVER SH-02J**– SH-02J**AQUOS EVER SH-04G**– SH-04G**AQUOS K SHF31**– SHF31**AQUOS K SHF32**– SHF32**AQUOS K SHF33**– SHF33**AQUOS L SHV37**– FSP_u**AQUOS mini SH-M03**– SH-M03**AQUOS PAD SH-05G**– SH-05G**AQUOS PAD SH-06F**– SH-06F**AQUOS PHONE ZETA SH-01F**– SH-01F**AQUOS SERIE mini SHV31**– SHV31**AQUOS SERIE mini SHV33**– SHV33**AQUOS SERIE SHL25**– SHL25**AQUOS SERIE SHV32**– SHV32**AQUOS SERIE SHV34**– SHV34**AQUOS SH-M01**– SH-M01**AQUOS SH-M02-EVA20**– SH-M02-EVA20**AQUOS SH-M02**– SH-M02**AQUOS SH-RM02**– SH-RM02**AQUOS U SHV35**– SHV35**AQUOS U SHV37**– FSP**AQUOS Xx 3**– SG506SH**AQUOS Xx 304SH**– SG304SH**AQUOS Xx**– SG404SH**AQUOS Xx2 mini**– SG503SH**AQUOS Xx2**– SG502SH

AQUOS ZETA SH-01G– SH-01G
AQUOS ZETA SH-01H– SH-01H
AQUOS ZETA SH-03G– SH-03G
AQUOS ZETA SH-04F– SH-04F
AQUOS ZETA SH-04H– SH-04H
AQUOS ケータイ SH-06G– SH-06G
BASIO2 SHV36– SHV36
Disney Mobile on docomo DM-01H– DM-01H
Disney Mobile on docomo SH-02G– SH-02G
LCD-UF30A– lcd_uf30a
LCD-xxBEL6A– lcd_xxbel6a
LCD-xxBEL8A– lcd_xxbel8a
LCD-xxCAE5A– lcd_xxcae5a
Media Tablet– EB-L76G-B
SH-M04– SH-M04
SH825wi– SH825Wi
SHARP C1– MS1
SoftBank 305SH– SG305SH
Star Wars mobile– SW001SH
シンプルスマホ 3– SG509SH

SK TELESYS

Infinity– Infinity
Infinite– MID1324
Cynus T6– Cynus_T6
CUBE– myphone_cube
SK-S170– K4

SAMSUNG

Galaxy A3 (2017)– a3y17lte
Galaxy A3– a33g
Galaxy A3– a3lte
Galaxy A3– a3ltechn
Galaxy A3– a3ltectc
Galaxy A3– a3ltedd
Galaxy A3– a3lteslk
Galaxy A3– a3ltezh
Galaxy A3– a3ltezt

Galaxy A3– a3ulte
Galaxy A3(2016)– a3xelte
Galaxy A3(2016)– a3xeltekx
Galaxy A5– a53g
Galaxy A5– a5lte
Galaxy A5– a5ltechn
Galaxy A5– a5ltectc
Galaxy A5– a5ltezh
Galaxy A5– a5ltezt
Galaxy A5– a5ulte
Galaxy A5– a5ultebmc
Galaxy A5– a5ultektt
Galaxy A5– a5ultelgt
Galaxy A5– a5ulteskt
Galaxy A5(2016)– a5xelte
Galaxy A5(2016)– a5xeltecmcc
Galaxy A5(2016)– a5xeltektt
Galaxy A5(2016)– a5xeltelgt
Galaxy A5(2016)– a5xelteskt
Galaxy A5(2016)– a5xltechn
Galaxy A5x(2016)– a5xeltextc
Galaxy A7– a73g
Galaxy A7– a7alte
Galaxy A7– a7lte
Galaxy A7– a7ltechn
Galaxy A7– a7ltectc
Galaxy A7– a7ltekttt
Galaxy A7– a7ltelgt
Galaxy A7– a7lteskt
Galaxy A7(2016)– a7xelte
Galaxy A7(2016)– a7xeltecmcc
Galaxy A7(2016)– a7xeltektt
Galaxy A7(2016)– a7xeltelgt
Galaxy A7(2016)– a7xelteskt
Galaxy A7(2016)– a7xeltextc
Galaxy A7(2016)– a7xltechn
Galaxy A8– a8elte
Galaxy A8– a8elteskt

Galaxy A8– a8hplte
Galaxy A8– a8ltechn
Galaxy A8– SCV32
Galaxy A8(2016)– a8xelte
Galaxy A8(2016)– a8xelteskt
Galaxy A9 Pro– a9xproltechn
Galaxy A9 Pro– a9xproltesea
Galaxy A9(2016)– a9xltechn
Galaxy Ace 4– vivaltods5m
Galaxy Ace Style– heatnfc3g
Galaxy Ace Style– heatqlte
Galaxy Ace– heatlte
Galaxy Ace2– GT-I8160
Galaxy Ace3– logan
Galaxy Ace4 Lite– vivalto3g
Galaxy Ace4 Lite– vivalto3mveml3g
Galaxy Ace4 Lite– vivalto3mveml3gsea
Galaxy Ace4 Neo– vivalto3mve3gltn
Galaxy Ace4– vivalto5mve3g
Galaxy Ace4– vivaltolte
Galaxy Ace4– vivaltonfc3g
Galaxy Active neo– SC-01H
Galaxy Alpha– slte
Galaxy Alpha– slteatt
Galaxy Alpha– sltecan
Galaxy Alpha– sltechn
Galaxy Alpha– sltekt
Galaxy Alpha– sltelgt
Galaxy Alpha– slteskt
Galaxy Avant– afyonltetmo
Galaxy C5– c5ltechn
Galaxy C5– c5pltechn
Galaxy C7– c7ltechn
Galaxy C9 Pro– c9ltechn
Galaxy Core Lite– victorlte
Galaxy Core Max Duos– kleoslte
Galaxy Core Prime – coreprimeltevzw
Galaxy Core Prime– core33g

Galaxy Core Prime– coreprimelte
Galaxy Core Prime– coreprimelteaio
Galaxy Core Prime– coreprimeltelra
Galaxy Core Prime– coreprimeltespr
Galaxy Core Prime– coreprimeltetfnvzw
Galaxy Core Prime– coreprimeve3g
Galaxy Core Prime– coreprimevelte
Galaxy Core Prime– cprimeltemtr
Galaxy Core Prime– cprimeltetmo
Galaxy Core Prime– rossalte
Galaxy Core Prime– rossaltectc
Galaxy Core Prime– rossaltexsa
Galaxy Core– afyonltecan
Galaxy Core– afyonlteMetroPCS
Galaxy Core2– kanas
Galaxy Core2– kanas3g
Galaxy Core2– kanas3gcmcc
Galaxy Core2– kanas3gctc
Galaxy Core2– kanas3gnfc
Galaxy E5– e53g
Galaxy E5– e5lte
Galaxy E5– e5ltetfnvzw
Galaxy E5– e5ltetw
Galaxy E7– e73g
Galaxy E7– e7ltechn
Galaxy E7– e7ltectc
Galaxy E7– e7ltehktw
Galaxy Express2– wilcoxlte
Galaxy Folder– novel3gskt
Galaxy Folder– novelltekt
Galaxy Folder– novelltekx
Galaxy Folder– novelltelgt
Galaxy Folder– novellteskt
Galaxy Folder2– eliteltechn
Galaxy Go Prime– grandprimelteatt
Galaxy Golden 2– pateklte
Galaxy Grand Max– grandmax3g
Galaxy Grand Max– grandmaxltechn

Galaxy Grand Neo Plus– grandneove3g
Galaxy Grand Prime– fortuna3g
Galaxy Grand Prime– fortuna3gdtv
Galaxy Grand Prime– fortunalte
Galaxy Grand Prime– fortunaltectc
Galaxy Grand Prime– fortunaltezh
Galaxy Grand Prime– fortunaltezt
Galaxy Grand Prime– fortunave3g
Galaxy Grand Prime– gprimelteacg
Galaxy Grand Prime– gprimeltecan
Galaxy Grand Prime– gprimeltemtr
Galaxy Grand Prime– gprimeltespr
Galaxy Grand Prime– gprimeltetfnvzw
Galaxy Grand Prime– gprimeltetmo
Galaxy Grand Prime– gprimelteusc
Galaxy Grand Prime– grandprimelte
Galaxy Grand Prime– grandprimelte aio
Galaxy Grand Prime– grandprimeve3g
Galaxy Grand Prime– grandprimeve3gdtv
Galaxy Grand Prime– grandprimevelte
Galaxy Grand Prime– grandprimevelteln
Galaxy Grand Prime– grandprimeveltezt
Galaxy Grand-Max– grandmaxltekx
Galaxy Grand2– ms013g
Galaxy Grand2– ms013gdtv
Galaxy Grand2– ms01lte
Galaxy Grand2– ms01ltekt
Galaxy Grand2– ms01lteigt
Galaxy Grand2– ms01lteskt
Galaxy J– hltejs01tw
Galaxy J1 Ace– j1acelte
Galaxy J1 Ace– j1acelteln
Galaxy J1 Ace– j1acevelte
Galaxy J1 Ace– j1pop3g
Galaxy J1 Mini Prime– j1minive3g
Galaxy J1 Mini Prime– j1minive3gxtc
Galaxy J1 Mini Prime– j1minivelte
Galaxy J1 Mini– j1mini3g

Galaxy J1 Mini– j1mini3gdx
Galaxy J1 Mini– j1mini3gxw
Galaxy J1 Mini– j1minilte
Galaxy J1– j13g
Galaxy J1– j13gtfnvzw
Galaxy J1– j1lte
Galaxy J1– j1nlte
Galaxy J1– j1qltevzw
Galaxy J1– j1xlteaio
Galaxy J1– j1xlteatt
Galaxy J1– j1xltecan
Galaxy J1– j1xqltespr
Galaxy J1– j1xqltetfnvzw
Galaxy J1(2016)– j1x3g
Galaxy J1(2016)– j1xlte
Galaxy J2– j23g
Galaxy J2– j2lte
Galaxy J2– j2ltedtv
Galaxy J2(2016)– j2xlte
Galaxy J2(2016)– j2xlteins
Galaxy J3 Pop– j3popltespr
Galaxy J3 Pro– j3xproltechn
Galaxy J3 Pro– j3xproltectc
Galaxy J3– j3ltectc
Galaxy J3– j3ltespr
Galaxy J3– j3x3g
Galaxy J3(2016)– j3ltekx
Galaxy J3(2016)– j3ltetfnvzw
Galaxy J3(2016)– j3ltetw
Galaxy J3(2016)– j3lteusc
Galaxy J3(2016)– j3ltevzw
Galaxy J3(2016)– j3ltexsa
Galaxy J3(2016)– j3xlte
Galaxy J3(2016)– j3xlteaio
Galaxy J3(2016)– j3xlteatt
Galaxy J3(2016)– j3xltebmc
Galaxy J3(2016)– j3xnlte
Galaxy J5 Prime– on5xelte

Galaxy J5 Prime– on5xelteins
Galaxy J5 Prime– on5xltechn
Galaxy J5– j53g
Galaxy J5– j5lte
Galaxy J5– j5ltechn
Galaxy J5– j5ltekx
Galaxy J5– j5nlte
Galaxy J5– j5ylte
Galaxy J5(2016)– j5x3g
Galaxy J5(2016)– j5xltecmcc
Galaxy J5(2016)– j5xnlte
Galaxy J5(2016)– j5xnltekt
Galaxy J5(2016)– j5xnltelgt
Galaxy J5(2016)– j5xnlteskt
Galaxy J7 Prime– on7xelte
Galaxy J7 Prime– on7xltechn
Galaxy J7– j75ltekt
Galaxy J7– j7e3g
Galaxy J7– j7elte
Galaxy J7– j7ltechn
Galaxy J7(2016)– j7eltemtr
Galaxy J7(2016)– j7eltetmo
Galaxy J7(2016)– j7ltespr
Galaxy J7(2016)– j7xelte
Galaxy J7(2016)– j7xeltecmcc
Galaxy J7(2016)– j7xeltekt
Galaxy J7(2016)– j7xltectc
Galaxy K Zoom– m2a3g
Galaxy K Zoom– m2alte
Galaxy K Zoom– m2altecan
Galaxy K Zoom– m2altelgt
Galaxy Mega 2– mega23g
Galaxy Mega 6.3– melius3g
Galaxy Mega 6.3– meliuslte
Galaxy Mega 6.3– meliuslteatt
Galaxy Mega 6.3– meliusltecan
Galaxy Mega 6.3– meliusltekt
Galaxy Mega 6.3– meliusltelgt

Galaxy Mega 6.3– meliuslteMetroPCS
Galaxy Mega 6.3– meliuslteskt
Galaxy Mega 6.3– meliusltespr
Galaxy Mega 6.3– meliuslteusc
Galaxy Mega2– mega2lte
Galaxy Mega2– mega2lteatt
Galaxy Mega2– vasta3g
Galaxy Mega2– vastalte
Galaxy Mega2– vastaltezh
Galaxy Nexus– maguro
Galaxy Nexus– toroplus
Galaxy Note 10.1 2014 Edition– lt033g
Galaxy Note 10.1 2014 Edition– lt03lte
Galaxy Note 10.1 2014 Edition– lt03ltetmo
Galaxy Note 10.1 2014 Edition– lt03ltevzw
Galaxy Note 10.1 2014 Edition– lt03wifi
Galaxy Note 10.1 2014 Edition– lt03wifikx
Galaxy Note 10.1 2014 Edition– lt03wifiue
Galaxy Note 10.1– lt03ltekt
Galaxy Note 10.1– lt03ltelgt
Galaxy Note 10.1– lt03lteskt
Galaxy Note 10.1– p4notelte
Galaxy Note 10.1– p4noteltekt
Galaxy Note 10.1– p4noteltelgt
Galaxy Note 10.1– p4notelteskt
Galaxy Note 10.1– p4noteltevzw
Galaxy Note 10.1– p4noterf
Galaxy Note 10.1– p4noterfkt
Galaxy Note 10.1– p4notewifi
Galaxy Note 10.1– p4notewifiany
Galaxy Note 10.1– p4notewifiww
Galaxy Note 8– konalteatt
Galaxy Note 8.0– kona3g
Galaxy Note 8.0– konalte
Galaxy Note 8.0– konaltecán
Galaxy Note 8.0– konawifi
Galaxy Note 8.0– konawifiany
Galaxy Note Edge– SC-01G

Galaxy Note Edge– SCL24
Galaxy Note Edge– tbeltekt
Galaxy Note Edge– tbeltelgt
Galaxy Note Edge– tbelteskt
Galaxy Note Edge– tblte
Galaxy Note Edge– tblteatt
Galaxy Note Edge– tbltecan
Galaxy Note Edge– tbltechn
Galaxy Note Edge– tbltespr
Galaxy Note Edge– tbltetmo
Galaxy Note Edge– tblteusc
Galaxy Note Edge– tbltevw
Galaxy Note II– t0lteatt
Galaxy Note Pro 12.2 – viennialteatt
Galaxy Note Pro 12.2– v1a3g
Galaxy Note Pro 12.2– v1awifi
Galaxy Note Pro 12.2– v1awifikx
Galaxy Note Pro 12.2– viennialte
Galaxy Note Pro 12.2– viennialtekx
Galaxy Note Pro 12.2– viennialtevw
Galaxy Note– GT-N7000
Galaxy Note2– t03g
Galaxy Note2– t0lte
Galaxy Note2– t0ltecan
Galaxy Note2– t0ltekt
Galaxy Note2– t0telgt
Galaxy Note2– t0lteskt
Galaxy Note2– t0ltespr
Galaxy Note2– t0ltetmo
Galaxy Note2– t0lteusc
Galaxy Note2– t0ltevw
Galaxy Note3 Neo– frescoltekt
Galaxy Note3 Neo– frescoltelgt
Galaxy Note3 Neo– frescolteskt
Galaxy Note3 Neo– hl3g
Galaxy Note3 Neo– hllte
Galaxy Note3– ha3g
Galaxy Note3– hlte

Galaxy Note3– hlteatt
Galaxy Note3– hltecan
Galaxy Note3– hltektt
Galaxy Note3– hltelgt
Galaxy Note3– hlteskt
Galaxy Note3– hltesp
Galaxy Note3– hltetmo
Galaxy Note3– hlteusc
Galaxy Note3– hltevw
Galaxy Note3– htdlte
Galaxy Note3– SC-01F
Galaxy Note3– SC-02F
Galaxy Note3– SCL22
Galaxy Note4– tre3caltekt
Galaxy Note4– tre3caltelgt
Galaxy Note4– tre3calteskt
Galaxy Note4– tre3g
Galaxy Note4– trelte
Galaxy Note4– treltektt
Galaxy Note4– treltelgt
Galaxy Note4– trelteskt
Galaxy Note4– trhplte
Galaxy Note4– trlte
Galaxy Note4– trlteatt
Galaxy Note4– trltecan
Galaxy Note4– trltechn
Galaxy Note4– trltechnzh
Galaxy Note4– trltespr
Galaxy Note4– trltetmo
Galaxy Note4– trlteusc
Galaxy Note4– trltevw
Galaxy Note5– noblelte
Galaxy Note5– noblelteacg
Galaxy Note5– noblelteatt
Galaxy Note5– nobleltebmc
Galaxy Note5– nobleltechn
Galaxy Note5– nobleltecmcc
Galaxy Note5– nobleltehk

Galaxy Note5– nobleltektt
Galaxy Note5– nobleltelgt
Galaxy Note5– nobleltelra
Galaxy Note5– noblelteskt
Galaxy Note5– nobleltespr
Galaxy Note5– nobleltetmo
Galaxy Note5– noblelteusc
Galaxy Note5– nobleltevzw
Galaxy Note7– gracelte
Galaxy Note7– graceltektt
Galaxy Note7– graceltelgt
Galaxy Note7– gracelteskt
Galaxy Note7– graceqlteacg
Galaxy Note7– graceqlteatt
Galaxy Note7– graceqltebmc
Galaxy Note7– graceqltechn
Galaxy Note7– graceqltelra
Galaxy Note7– graceqltespr
Galaxy Note7– graceqltetfnvzw
Galaxy Note7– graceqltetmo
Galaxy Note7– graceqlteusc
Galaxy Note7– graceqltevzw
Galaxy On5– o5lte
Galaxy On5– o5ltechn
Galaxy On5– o5prolte
Galaxy On5– on5ltemtr
Galaxy On5– on5ltetfntmo
Galaxy On5– on5ltetmo
Galaxy On5(2016)– on5xfltechn
Galaxy On5(2016)– on5xlltechn
Galaxy On7 Pro– o7prolte
Galaxy On7– o7lte
Galaxy On7– o7ltechn
Galaxy On7– on7elte
Galaxy On7– on7nlteskt
Galaxy On7(2016)– on7xeltektt
Galaxy On7(2016)– on7xeltelgt
Galaxy On7(2016)– on7xelteskt

Galaxy On8– j7xlte
Galaxy Pocket Neo– corsicave3g
Galaxy Pocket Neo– corsicaveds3gvj
Galaxy Pocket Neo– d2aio
Galaxy Pocket2– pocket23g
Galaxy Pocket2– pocket2ss3g
Galaxy Pop– superiorlteskt
Galaxy Round– flteskt
Galaxy S Duos3– vivalto3gvn
Galaxy S2 Plus– GT-I9100G
Galaxy S2– GT-I9100
Galaxy S2– GT-I9103
Galaxy S3 Mini– golden
Galaxy S3 Mini– goldenlteatt
Galaxy S3 Mini– goldenltebmc
Galaxy S3 Mini– goldenltevzw
Galaxy S3 Neo– s3ve3g
Galaxy S3 Neo– s3ve3gdd
Galaxy S3 Neo– s3ve3gds
Galaxy S3 Neo– s3ve3gdsdd
Galaxy S3– c1ktt
Galaxy S3– c1lgt
Galaxy S3– c1skt
Galaxy S3– d2att
Galaxy S3– d2can
Galaxy S3– d2cri
Galaxy S3– d2lterefreshspr
Galaxy S3– d2mtr
Galaxy S3– d2spi
Galaxy S3– d2spr
Galaxy S3– d2tmo
Galaxy S3– d2usc
Galaxy S3– d2vmu
Galaxy S3– d2vzw
Galaxy S3– m0
Galaxy S3– m3
Galaxy S4 Active– jactivelte
Galaxy S4 Active– jactivelteatt

Galaxy S4 Active– jactivelteskt
Galaxy S4 Duos– ja3gchnduos
Galaxy S4 Google Play Edition– jgedlte
Galaxy S4 LTE-A– ks01lteskt
Galaxy S4 Mini – serranoltekt
Galaxy S4 Mini – serranovolteatt
Galaxy S4 Mini– serrano3g
Galaxy S4 Mini– serranods
Galaxy S4 Mini– serranolte
Galaxy S4 Mini– serranoltebmc
Galaxy S4 Mini– serranoltelra
Galaxy S4 Mini– serranoltespr
Galaxy S4 Mini– serranolteusc
Galaxy S4 Mini– serranoltevw
Galaxy S4 Mini– serranove3g
Galaxy S4 Mini– serranovelte
Galaxy S4 Zoom– mproject3g
Galaxy S4 Zoom– mprojectlteatt
Galaxy S4 Zoom– mprojectqlte
Galaxy S4– ja3g
Galaxy S4– ja3gduosctc
Galaxy S4– jaltekt
Galaxy S4– jaltelgt
Galaxy S4– jaltetkt
Galaxy S4– jflte
Galaxy S4– jflteaio
Galaxy S4– jflteatt
Galaxy S4– jfltecan
Galaxy S4– jfltecri
Galaxy S4– jfltecsp
Galaxy S4– jfltelra
Galaxy S4– jflterefreshspr
Galaxy S4– jfltespr
Galaxy S4– jfltetmo
Galaxy S4– jflteusc
Galaxy S4– jfltevw
Galaxy S4– jfltevwpp
Galaxy S4– jftdd

Galaxy S4– jfvelte
Galaxy S4– jsglte
Galaxy S4– ks01lte
Galaxy S4– ks01ltekt
Galaxy S4– ks01ltektg
Galaxy S4– SC-04E
Galaxy S5 Active– kactivektekx
Galaxy S5 Active– klteactive
Galaxy S5 Active– klteattactive
Galaxy S5 Active– kltecanactive
Galaxy S5 Active– SC-02G
Galaxy S5 Google Play Edition– kgedlte
Galaxy S5 K Sport– kltesprsports
Galaxy S5 LTE-A– kccat6
Galaxy S5 Mini– kmini3g
Galaxy S5 Mini– kminilte
Galaxy S5 mini– kminilteatt
Galaxy S5 Mini– kminilteusc
Galaxy S5 mini– kminiwifi
Galaxy S5 Neo– s5neolte
Galaxy S5 Neo– s5neoltecan
Galaxy S5– k3g
Galaxy S5– klte
Galaxy S5– klteacg
Galaxy S5– klteaio
Galaxy S5– klteatt
Galaxy S5– kltecan
Galaxy S5– klteudoszn
Galaxy S5– kltekt
Galaxy S5– kltektg
Galaxy S5– kltelra
Galaxy S5– klteMetroPCS
Galaxy S5– klteskt
Galaxy S5– kltespr
Galaxy S5– kltefnvzw
Galaxy S5– kltetmo
Galaxy S5– klteusc
Galaxy S5– kltevw

Galaxy S5– kwifi
Galaxy S5– lentisltekt
Galaxy S5– lentisltelgt
Galaxy S5– lentislteskt
Galaxy S5– SC-04F
Galaxy S5– SCL23
Galaxy S6 Active– marinelteatt
Galaxy S6 Edge– 404SC
Galaxy S6 Edge– SC-04G
Galaxy S6 Edge– SCV31
Galaxy S6 Edge– zerolte
Galaxy S6 Edge– zerolteacg
Galaxy S6 Edge– zerolteatt
Galaxy S6 Edge– zeroltebmc
Galaxy S6 Edge– zeroltechn
Galaxy S6 Edge– zeroltekt
Galaxy S6 Edge– zeroltelgt
Galaxy S6 Edge– zeroltelra
Galaxy S6 Edge– zerolteskt
Galaxy S6 Edge– zeroltespr
Galaxy S6 Edge– zeroltetmo
Galaxy S6 Edge– zerolteusc
Galaxy S6 Edge– zeroltevw
Galaxy S6 Edge+– zenlte
Galaxy S6 Edge+– zenlteatt
Galaxy S6 Edge+– zenltebmc
Galaxy S6 Edge+– zenltechn
Galaxy S6 Edge+– zenltekt
Galaxy S6 Edge+– zenltekx
Galaxy S6 Edge+– zenltelgt
Galaxy S6 Edge+– zenlteskt
Galaxy S6 Edge+– zenltespr
Galaxy S6 Edge+– zenltetmo
Galaxy S6 Edge+– zenltevw
Galaxy S6– SC-05G
Galaxy S6– zeroflte
Galaxy S6– zeroflteacg
Galaxy S6– zeroflteaio

Galaxy S6– zeroflteatt
Galaxy S6– zerofltebmc
Galaxy S6– zerofltechn
Galaxy S6– zerofltectc
Galaxy S6– zerofltekt
Galaxy S6– zerofltelgt
Galaxy S6– zerofltelra
Galaxy S6– zerofltemtr
Galaxy S6– zeroflteskt
Galaxy S6– zerofltespr
Galaxy S6– zerofltetfnvzw
Galaxy S6– zerofltetmo
Galaxy S6– zeroflteusc
Galaxy S6– zerofltevzw
Galaxy S7 – herolte
Galaxy S7 – heroltebmc
Galaxy S7 – heroltekt
Galaxy S7 – heroltelgt
Galaxy S7 – herolteskt
Galaxy S7 – heroqlteatt
Galaxy S7 – heroqltespr
Galaxy S7 – heroqltetmo
Galaxy S7 Active– poseidonlteatt
Galaxy S7 Edge– hero2lte
Galaxy S7 Edge– hero2ltebmc
Galaxy S7 Edge– hero2ltekt
Galaxy S7 Edge– hero2ltelgt
Galaxy S7 Edge– hero2lteskt
Galaxy S7 Edge– hero2qlteatt
Galaxy S7 Edge– hero2qltecctvzw
Galaxy S7 Edge– hero2qltechn
Galaxy S7 Edge– hero2qltespr
Galaxy S7 Edge– hero2qltetmo
Galaxy S7 Edge– hero2qlteue
Galaxy S7 Edge– hero2qlteusc
Galaxy S7 Edge– hero2qltevzw
Galaxy S7 Edge– SC-02H
Galaxy S7 Edge– SCV33

Galaxy S7– heroqlteacg
Galaxy S7– heroqlteaio
Galaxy S7– heroqltecctvzw
Galaxy S7– heroqltechn
Galaxy S7– heroqltelra
Galaxy S7– heroqltemtr
Galaxy S7– heroqltetfnvzw
Galaxy S7– heroqlteue
Galaxy S7– heroqlteusc
Galaxy S7– heroqltevwz
Galaxy Star2 Plus– higgs2g
Galaxy Tab 3V 7.0– goyave3g5M
Galaxy Tab 4 8.0– milletwifikx
Galaxy Tab A 10.1– gtanotexlwifikx
Galaxy Tab A 10.1– gtaxllte
Galaxy Tab A 10.1– gtaxlltechn
Galaxy Tab A 10.1– gtaxlltekx
Galaxy Tab A 10.1– gtaxlwifi
Galaxy Tab A 10.1– gtaxlwifichn
Galaxy Tab A 10.1(2016)– gtanotexllte
Galaxy Tab A 7.0– gtexslte
Galaxy Tab A 7.0– gtexslteswa
Galaxy Tab A 7.0– gtexswifi
Galaxy Tab A 8.0– gt58lte
Galaxy Tab A 8.0– gt58ltechn
Galaxy Tab A 8.0– gt58ltetmo
Galaxy Tab A 8.0– gt58wifi
Galaxy Tab A 8.0– gt58wifichn
Galaxy Tab A 8.0– gt5note8lte
Galaxy Tab A 8.0– gt5note8ltechn
Galaxy Tab A 8.0– gt5note8wifi
Galaxy Tab A 8.0– gt5note8wifichn
Galaxy Tab A 9.7– gt510lte
Galaxy Tab A 9.7– gt510ltechn
Galaxy Tab A 9.7– gt510wifi
Galaxy Tab A 9.7– gt510wifichn
Galaxy Tab A 9.7– gt5note10lte
Galaxy Tab A 9.7– gt5note10ltechn

Galaxy Tab A 9.7– gt5note10ltehktw
Galaxy Tab A 9.7– gt5note10ltekt
Galaxy Tab A 9.7– gt5note10telgt
Galaxy Tab A 9.7– gt5note10teskt
Galaxy Tab A 9.7– gt5note10wifi
Galaxy Tab A S 8.0– gt58ltebmc
Galaxy Tab E 8.0– gteslteatt
Galaxy Tab E 8.0– gtesltebmc
Galaxy Tab E 8.0– gtesltelgt
Galaxy Tab E 8.0– gteslteskt
Galaxy Tab E 8.0– gtesltetmo
Galaxy Tab E 8.0– gtesltetw
Galaxy Tab E 8.0– gtesltevzw
Galaxy Tab E 8.0– gtesqltespr
Galaxy Tab E 8.0– gtesqlteusc
Galaxy Tab E 9.6– gtel3g
Galaxy Tab E 9.6– gtelltevw
Galaxy Tab E 9.6– gtelwifi
Galaxy Tab E 9.6– gtelwifichn
Galaxy Tab E 9.6– gtelwifue
Galaxy Tab Pro 10.1 Chef Collection– picassowificc
Galaxy Tab Pro 10.1– picassolte
Galaxy Tab Pro 10.1– picassowifi
Galaxy Tab Pro 12.2– v2lte
Galaxy Tab Pro 12.2– v2wifi
Galaxy Tab Pro 8.4– mondrianlte
Galaxy Tab Pro 8.4– mondrianwifi
Galaxy Tab Pro 8.4– mondrianwifikx
Galaxy Tab Pro 8.4– mondrianwifue
Galaxy Tab S 8.4– klimtlte
Galaxy Tab S 8.4– klimtltevw
Galaxy Tab S 8.4– SC-03G
Galaxy Tab S2 8.0– gts28lte
Galaxy Tab S2 8.0– gts28ltechn
Galaxy Tab S2 8.0– gts28tekx
Galaxy Tab S2 8.0– gts28velte
Galaxy Tab S2 8.0– gts28veltechn
Galaxy Tab S2 8.0– gts28vewifi

Galaxy Tab S2 8.0– gts28vewifichn
Galaxy Tab S2 8.0– gts28wifi
Galaxy Tab S2 8.0– gts28wifichn
Galaxy Tab S2 9.7– gts210lte
Galaxy Tab S2 9.7– gts210lteatt
Galaxy Tab S2 9.7– gts210ltecan
Galaxy Tab S2 9.7– gts210ltekx
Galaxy Tab S2 9.7– gts210ltespr
Galaxy Tab S2 9.7– gts210ltetmo
Galaxy Tab S2 9.7– gts210lteusc
Galaxy Tab S2 9.7– gts210ltevzw
Galaxy Tab S2 9.7– gts210velte
Galaxy Tab S2 9.7– gts210velteatt
Galaxy Tab S2 9.7– gts210veltecan
Galaxy Tab S2 9.7– gts210veltechn
Galaxy Tab S2 9.7– gts210veltetmo
Galaxy Tab S2 9.7– gts210vewifi
Galaxy Tab S2 9.7– gts210vewifichn
Galaxy Tab S2 9.7– gts210wifi
Galaxy Tab2 10.1 – espresso10wifi
Galaxy Tab3 10.1– santos103g
Galaxy Tab3 10.1– santos10lte
Galaxy Tab3 10.1– santos10wifi
Galaxy Tab3 7.0 – lt02lteatt
Galaxy Tab3 7.0 – lt02ltespr
Galaxy Tab3 7.0– lt02lte
Galaxy Tab3 7.0– lt02ltetmo
Galaxy Tab3 8.0– lt013g
Galaxy Tab3 8.0– lt01lte
Galaxy Tab3 8.0– lt01wifi
Galaxy Tab3 Lite 7.0– goyave3g
Galaxy Tab3 Lite 7.0– goyavewifi
Galaxy TAB3 Lite– goyairis3g
Galaxy Tab3 Lite– goyawifi
Galaxy Tab3V 7.0– goyave3gsea
Galaxy Tab3V 7.0– goyavewifixtc
Galaxy Tab4 – matissewifigoog
Galaxy Tab4 10.0– matisse3g

Galaxy Tab4 10.0– matisselte
Galaxy Tab4 10.0– matisselteatt
Galaxy Tab4 10.0– matisselteusc
Galaxy Tab4 10.0– matisseltevzw
Galaxy Tab4 10.1– matisse10wifikx
Galaxy Tab4 10.1– matissewewifi
Galaxy Tab4 10.1– matissewifi
Galaxy Tab4 10.1– matissewifikx
Galaxy Tab4 10.1– matissewifiue
Galaxy Tab4 7.0– 403SC
Galaxy Tab4 7.0– degas2wifi
Galaxy Tab4 7.0– degas3g
Galaxy Tab4 7.0– degaslte
Galaxy Tab4 7.0– degasltespr
Galaxy Tab4 7.0– degasltevzw
Galaxy Tab4 7.0– degasvelte
Galaxy Tab4 7.0– degaswifi
Galaxy Tab4 7.0– degaswifidtv
Galaxy Tab4 7.0– degaswifioopenbnn
Galaxy Tab4 7.0– degaswifiue
Galaxy Tab4 8.0– millet3g
Galaxy Tab4 8.0– milletlte
Galaxy Tab4 8.0– milletlteatt
Galaxy Tab4 8.0– milletltekt
Galaxy Tab4 8.0– milletltelgt
Galaxy Tab4 8.0– milletltetmo
Galaxy Tab4 8.0– milletltevzw
Galaxy Tab4 8.0– milletwifi
Galaxy Tab4 8.0– milletwifiue
Galaxy Tab4 Active– rubenslte
Galaxy Tab4 Active– rubensltekx
Galaxy Tab4 Active– rubenswifi
Galaxy Tab4 Nook 10.1– matissewifioopenbnn
Galaxy TabA Plus 10.1– gtanotexlltekx
Galaxy TabA Plus 10.1– gtaxlqltespr
Galaxy TabS 10.5 – chagallwifikx
Galaxy TabS 10.5– chagallhktekt
Galaxy TabS 10.5– chagallhltelgt

Galaxy TabS 10.5– chagallhteskt
Galaxy TabS 10.5– chagalllte
Galaxy TabS 10.5– chagalllteatt
Galaxy TabS 10.5– chagallltecan
Galaxy TabS 10.5– chagallltespr
Galaxy TabS 10.5– chagallltetmo
Galaxy TabS 10.5– chagalllteusc
Galaxy TabS 10.5– chagallltevzw
Galaxy TabS 10.5– chagallwifi
Galaxy TabS 10.5– SCT21
Galaxy TabS 8.4– klimtlteatt
Galaxy TabS 8.4– klimtltecan
Galaxy TabS 8.4– klimtwifi
Galaxy TabS 8.4– klimtwifikx
Galaxy TabS2 9.7– gts210veltevw
Galaxy Win2– coreprimeltdtv
Galaxy Xcover3– xcover3lte
Galaxy Xcover3– xcover3velte
Galaxy Young2 Pro– young2ve3g
Galaxy Young2– young23g
Galaxy Young2– young23gdtv
Galaxy Young2– young2ds2g
Galaxy Young2– young2nfc3g
Garda– gardalteMetroPCS
Grand Prime Plus– grandpplte
Grand Prime Plus– grandppltdtv
Samsung Galaxy S4– jflteMetroPCS
SHW-M480S– p4noterfskt
SM-G9198– philippeltechn
W2016– royceltectc
W2017– veyronltectc

SONY

SONY ERICSSON

Xperia A2– SO-04F
Xperia A4– SO-04G
Xperia C3 Dual– D2502

Xperia C3– D2533
Xperia C5 Ultra Dual– E5533
Xperia C5 Ultra Dual– E5563
Xperia C5 Ultra– E5506
Xperia C5 Ultra– E5553
Xperia E1 dual– D2104
Xperia E1 dual– D2105
Xperia E1 dual– D2114
Xperia E1– D2004
Xperia E1– D2005
Xperia E3 Dual– D2212
Xperia E3– D2202
Xperia E3– D2203
Xperia E3– D2206
Xperia E3– D2243
Xperia E4g Dual– E2033
Xperia E4g Dual– E2043
Xperia E4g– E2053
Xperia E5– F3311
Xperia E5– F3313
Xperia J1 Compact– D5788
Xperia M– C1904
Xperia M– C1905
Xperia M2 Aqua– D2403
Xperia M2 Aqua– D2406
Xperia M2 Dual– D2302
Xperia M2– D2303
Xperia M2– D2305
Xperia M2– D2306
Xperia M5 Dual– E5633
Xperia M5 Dual– E5643
Xperia M5 Dual– E5663
Xperia M5– E5603
Xperia M5– E5606
Xperia M5– E5653
Xperia T2 Ultra dual– D5322
Xperia T2 Ultra– D5303
Xperia T2 Ultra– D5306

Xperia T2 Ultra– D5316
Xperia T2 Ultra– D5316N
Xperia T3– D5102
Xperia T3– D5103
Xperia T3– D5106
Xperia Tablet Z– SGP311
Xperia Tablet Z– SGP312
Xperia Tablet Z– SGP321
Xperia Tablet Z– SGP351
Xperia X Compact– F5321
Xperia X Compact– SO-02J
Xperia X Performance– 502SO
Xperia X Performance– F8131
Xperia X Performance– F8132
Xperia X Performance– SO-04H
Xperia X Performance– SOV33
Xperia X– F5121
Xperia X– F5122
Xperia X– suzu
Xperia XA Ultra– F3211
Xperia XA Ultra– F3212
Xperia XA Ultra– F3213
Xperia XA Ultra– F3215
Xperia XA Ultra– F3216
Xperia XA– F3111
Xperia XA– F3112
Xperia XA– F3113
Xperia XA– F3115
Xperia XA– F3116
Xperia XZ– 601SO
Xperia XZ– F8331
Xperia XZ– F8332
Xperia XZ– SO-01J
Xperia XZ– SOV34
Xperia Z Ultra– C6802
Xperia Z Ultra– C6806
Xperia Z Ultra– C6833
Xperia Z Ultra– C6843

Xperia Z Ultra– SGP412
Xperia Z Ultra– SOL24
Xperia Z Ultra– XL39h
Xperia Z– C6602
Xperia Z– C6603
Xperia Z– C6616
Xperia Z– L36h
Xperia Z– SO-02E
Xperia Z1 Compact– D5503
Xperia Z1– C6902
Xperia Z1– C6903
Xperia Z1– C6906
Xperia Z1– C6916
Xperia Z1– C6943
Xperia Z1– L39h
Xperia Z1– SO-01F
Xperia Z1– SOL23
Xperia Z1f– SO-02F
Xperia Z2 Tablet– SGP511
Xperia Z2 Tablet– SGP512
Xperia Z2 Tablet– SGP521
Xperia Z2 Tablet– SGP551
Xperia Z2 Tablet– SGP561
Xperia Z2 Tablet– SO-05F
Xperia Z2 Tablet– SOT21
Xperia Z2– D6502
Xperia Z2– D6503
Xperia Z2– D6543
Xperia Z2– SO-03F
Xperia Z2a– D6563
Xperia Z3 Compact– D5803
Xperia Z3 Compact– D5833
Xperia Z3 Compact– SO-02G
Xperia Z3 Dual– D6633
Xperia Z3 Dual– D6683
Xperia Z3 Tablet Compact– SGP611
Xperia Z3 Tablet Compact– SGP612
Xperia Z3 Tablet Compact– SGP621

Xperia Z3 Tablet Compact– SGP641
Xperia Z3– 401SO
Xperia Z3– D6603
Xperia Z3– D6616
Xperia Z3– D6643
Xperia Z3– D6646
Xperia Z3– D6653
Xperia Z3– SO-01G
Xperia Z3– SOL26
Xperia Z3+ – E6553
Xperia Z3+ Dual – E6533
Xperia Z3v– D6708
Xperia Z4 Tablet– SGP712
Xperia Z4 Tablet– SGP771
Xperia Z4 Tablet– SO-05G
Xperia Z4 Tablet– SOT31
Xperia Z4– 402SO
Xperia Z4– SO-03G
Xperia Z4– SOV31
Xperia Z4v– E6508
Xperia Z5 Compact– E5803
Xperia Z5 Compact– E5823
Xperia Z5 Compact– SO-02H
Xperia Z5 dual– E6633
Xperia Z5 dual– E6683
Xperia Z5 Premium Dual– E6833
Xperia Z5 Premium Dual– E6883
Xperia Z5 Premium– E6853
Xperia Z5 Premium– SO-03H
Xperia Z5– 501SO
Xperia Z5– E6603
Xperia Z5– E6653
Xperia Z5– SO-01H
Xperia Z5– SOV32
Xperia ZL– C6502
Xperia ZL– C6503
Xperia ZL– C6506
Xperia ZL2– SOL25

Xperia ZR– C5502
Xperia ZR– C5503
Xperia™ C4 Dual– E5333
Xperia™ C4 Dual– E5343
Xperia™ C4 Dual– E5363
Xperia™ C4– E5303
Xperia™ C4– E5306
Xperia™ C4– E5353
Xperia™ E4 Dual– E2115
Xperia™ E4 Dual– E2124
Xperia™ E4– E2104
Xperia™ E4– E2105
Xperia™ E4g– E2003
Xperia™ E4g– E2006
Xperia™ M4 Aqua Dual– E2312
Xperia™ M4 Aqua Dual– E2333
Xperia™ M4 Aqua Dual– E2363
Xperia™ M4 Aqua– E2303
Xperia™ M4 Aqua– E2306
Xperia™ M4 Aqua– E2353

SPICE

Stellar Mi-438– Spice
Stellar Mi-506– SpiceMi506

SYMPHONY TELECA

1100– 1100
1105– 1105
1107– 1107
1206– 1206
3000– 3000
3005– 3005
3006– Mirror3
3007– 3007
3008– 3008
4U– 4U
825A– 825A

A11f– A11
A16C3H– A16C3H
A26C4H– A26C4H
A31– A31t
A31c– A31c
A31u– A31u
A33t– A33t
A33w– A33w
a4– a4
A5– A5
A500– Polaroid_Phone
A51– A51
A51kc– A51kc
A52– A52
A53fw– A53
A71– A71
A76Plus– A76Plus
A9x/PTAB935x– A9xPTAB935x
AD6B1H– AD6B1H
Air-Lynx ALS14000– granite
Air– Mobicel_Air
Algiz RT7– algizRT7
ANDY 5EI– AM5E3I047
ANS Trailblazer– rugged-smartphone
AP54– ts18_ap54_kliver
AQT100– NKJ_AQT100
Aquaris E10 3G– Aquaris_E10_3G
Aquaris E10– Aquaris_E10
Aquaris E4– Aquaris_E4
Aquaris E4.5– Aquaris_E45
Aquaris E5 FHD– Aquaris_E5_FHD
Aquaris E5 HD– Aquaris_E5_HD
Aquaris E5– Aquaris_E5
Aquaris E6– Aquaris_E6
Aquaris M10 FHD– Aquaris_M10_FHD
Aquaris M10– Aquaris_M10
Aquaris M4.5– Aquaris_M45
Aquaris M5– Aquaris_M5

Aquaris M5.5– Aquaris_M55
Aquaris U Plus– tenshi
Aquaris U– chaozu
Aquaris X5 Plus– Aquaris_X5_Plus
Aquaris X5– Aquaris_X5
B-KOOL– V2502AN01D
B15Q– CatB15Q
B16C2H– B16C2H
Beeline Pro 2– Beeline_Pro_2
Beeline Pro 4– Beeline_Pro_4
Beeline Pro5– Beeline_Pro_5
Beeline Smart 3– Beeline_Smart3
Beeline Smart 6– Beeline_Smart_6
Beeline Tab 2– Tab_2
Beeline Tab Fast 2 – z701
Beeline Tab Pro– BeelineTabPro
Beeline_Smart_8– Beeline_Smart_8
Beeline_Tab_Fast– Beeline_Tab_Fast
BIRDY– BIRDY
Blackphone 2– BP2
BLOOM– s4700
BLU LIFE XL– BLU_LIFE_XL
BLU TOUCHBOOK M7– BLU_TOUCHBOOK_M7
BM180– BM180
Bolt– A066
Bolt– A067
Bolt– A79
Bolt– A82
Bolt– AD3520
Bolt– AD4500
Bolt– D200
Bolt– D303
Bolt– D320
Bolt– D321
Boost Pulse Jive– Jive
Bphone– Bphone
bq Edison 3 3G– Edison_3_3G
C46B2H– C46B2H

Calltab 7”– Calltab7inch
Calltabll 10.1– E1031H2C
Candy– Candy
Canvas 4+– A315
Canvas Blaze– Q400
Canvas Doodle4– Q391
Canvas Fire– A093
Canvas Fire– A104
Canvas Fire3– A096
Canvas Fire4– A107
Canvas HD Plus– A190
Canvas Hue 2– A316
Canvas Hue– AQ5000
Canvas Juice2– AQ5001
Canvas Knight Cameo– A290
Canvas Knight2– KNIGHT2
Canvas L– A108
Canvas Magnus– A117
Canvas Nitro2– E311
Canvas Pep– Q370
Canvas Pep– Q371
Canvas Pep– Q375
Canvas Play– Q355
Canvas Selfie Lens– Q345
Canvas Selfie– A255
Canvas Spark– Q380
Canvas tab– P470
Canvas Tab– P480
Canvas tab– P666
Canvas Tab– P690
Canvas Tab– P70221
Canvas Tabby– P469
Canvas Turbo– A250
Canvas Xpress– A99
CDP7TAB4C8– CDP7TAB4C8
CEDTAB70616W8– CEDTAB70616W8
CETAB10KML9– CETAB10KML9
CETAB7ML9– CETAB7ML9

CHERRY– CHERRY
Clempad 6.0 XL– Clempad_6_XL
Clempad 6.0– Clempad_6
Clempad Call– CLEMPADCALL
Clempad_6_S– Clempad_6_S
Clemphone– ClemPhone
Condor T705– TGW710G
Condor TGW102L– TGW102L
Condor TGW801G– TGW801G
Condor TGW801L– TGW801L
Connect 451– Connect451
Connect 504– Q9
Connect502– Connect502
Connect502– MT502
Connect551– Connect551
COSMO– COSMO
CPH1605– CPH1605
CT1030– CT1030
CT1050– TVE9603
CT50– CT50L0N-CS15S
CT50– CT50L0N-CS16S
CT50– CT50LFN-CS16S
CT50– CT50LUN-CS15S
CT50– CT50LUN-CS16S
CT825– fiber-a31stm
Cubby– SproutChannelCubby
D75E– 75E-L0N
Danamic Now– DynamicNow
DASH X LTE– DASH_X_LTE
DASH X PLUS LTE– BLU_DASH_X_PLUS_LTE
Dash X– BLU_DASH_X
DASH X2– BLU_DASH_X2
DINOSAUR– x5623_h6013_cubot
Discovery Air– Discovery_Air
Dolphin CT50– CT50L0N-CS13S
Dolphin CT50– CT50LFN-CS13S
Dolphin CT50– CT50LUN-CS13S
DP10APro-SLA1– DP10APro

DP7CPro-SGA1– DP7CPro-SGA1
DroiPad 7C Pro– DP7CPRO
DroiPad 8II– DP8D
Droipad10– DP10A
DT101Bv51– DT101Bv51
Dual 8– FMT-NT8A42-01
E407– E407
E451– E451
E505 Plus– E505plus
E506plus– E506plus
E553– E553
E8– GiONEE_GN9008
ECHO– CUBOT_ECHO
ECHO– ECHO
Eclipse G500M– Eclipse_G500M
EDA50– eda50-111
Edison 3– Edison_3
Edison_3_mini– Edison_3_mini
EF400– EF400
EF500– EF500
EGQ178– EGQ178
EGQ223– EGQ223
EGQ347– EGQ347
EGQ367– EGQ367
EGQ377– EGQ377
EM9– EM9
Emerson EM756– EM756
Endurance– ForwardEndurance
Energy X 2– BLU_Energy_X_2
Energy X LTE– BLU_Energy_X_LTE
ENERGY XL– BLU_ENERGY_XL
ENERGY_DIAMOND_MINI– ENERGY_DIAMOND_MINI
EPIK Learning Tab 8"– ELT0801
EPIK_ELTO703– ELT0703
Era 4G– era_4G
ET5X– ET50E
ET5X– ET50T
ET5X– ET55E

ET5X– ET55T
Etab5– Etab5
Euroleague I7a– Euroleague
F100A– GIONEE_GBL7358
F103– GiONEE_GBL7319
F103S– GiONEE_F103S
F105– GiONEE_GBL7335
F1f– F1f
F301– F301
F303– F303
Fast– Fast
FEVER– FEVER
FEVER– I5460
FEVER– L5460AP25E
FL7008– FL7008
Flag Mill v2– MG101A2T_BT
Flag Mill v2– MG101A2T_BT_A50
Flag Mill v2– MG101A2T_BT_W32
Flair P3– P3
Flair S1– S1
Flash– FMT-NM7058-02
FMT-NM7054-01– FMT-NM7054-01
FMT-NM7054-03– FMT-NM7054-03
FMT-NM7058-03– FMT-NM7058-03
ForwardZero– ForwardZero
ForwardZero– V6L
FP2– FP2
FREDDY– T3903BN
FREDDY– V3903BN
FreeTAB 10.1 Silver– silver
FreeTAB 8015 IPS X4 LTE– reverie
FRIO– FRIO
FunTab 3– Funtab3
FWSP-S1000– FWSP-S1000-HW
FWTA-T1000– FWTA-T1000
G31s– G31s
G320– G320
G36C1H– G36C1H

G40– G40
G50– HM-G551-FL
G700– G700
GN152– GiONEE_CBL7320
GN3001– GiONEE_GBL7523
GN3002– GIONEE_GBL7356
GN3002L– GIONEE_GBL7356L
GN3003– GIONEE_GBL7359
GN3003L– GIONEE_GBL7359L
GN5001S– GiONEE_BBL7332
GN5002– GiONEE_GBL7333
GN8001– GiONEE_BBL7505
GN9000– S5_5
GN9006– GN9006
GN9007– GiONEE_CBL7503
GN9010L– GiONEE_CBL7513
GOA– s3511
Grace X3– PSP3455DUO
Grace X5– PSP5470DUO
Grace X7– PSP7505DUO
Griffe G5 Plus– PAM524
GTB103B– Stealth_GTB103M
GV7790– GV7790
H300– H300
H400– H400
H58– H58
Haier– W627
Haier– W861
HERO X– HERO_X
Hero X– STK_Hero_X
HIGHWAY 4G– s9321
HIGHWAY PURE– I9010
HIGHWAY STAR– I5560ae
Hive V 3G– mg978
Hive V 3G– mr978
HM-I557-FL– HM-I557-FL
HM-N501-FL– HM-N501-FL
Honeywell CN51– CN51_NC0

Honeywell CN51– CN51_NCF
Honeywell CN51– CN51_NCU
Honeywell CN51– CN51_QC0
Honeywell CN51– CN51_QCF
Honeywell CN51– CN51_QCU
Honeywell CT50– CT50L0N-CS12S
Honeywell CT50– CT50LUN-CS12S
HOT 2– Infinix_X510
HOT 4 PRO– X556
HOT 4– X557
HOT NOTE– Infinix-X551
HS-7DTB29-8GB– HS-7DTB29-8GB
HS-9DTB37– HS_9DTB37
hudl 2– HTF8A4
HW-I509-W– HM-I509-W
Hyasong T1– HyasongT1
i-mobile i-STYLE 812 4G– i_style_812_4G
i20– i20
I4G– I4G
i50– i50
I50– i50_b1b8
Icon– Mobicel_Icon
ILIUM L1000– Ilium_L1000
Ilium L1050– Ilium_L1050
Ilium L1100– ILIUM_L1100
Ilium L1200– Ilium_L1200
ILIUM L200– ILIUM_L200
Ilium L610– Ilium_L610
ILIUM L820– Ilium_L820
ILIUM L900– Ilium_L900
ILIUM L950– Ilium_L950
Ilium LT500– Ilium_LT500
Ilium LT510– Ilium_LT510
ilium Pad E7– ilium_Pad_E7
ilium PAD i7– Ilium_PAD_i7
Ilium Pad L8X– Ilium_Pad_L8X
Ilium Pad T7X– Ilium_Pad_T7X
ILIUM S670– Ilium_S670

ILIUM X110– ILIUM_X110
Ilium X200– Ilium_X200
Ilium X210– Ilium_X210
Ilium X500B– Ilium_X500B
Ilium X510– Ilium_X510
Ilium X710– Ilium_X710
Ilium_L1100– Ilium_L1100
Ilium_S106– Ilium_S106
Ilium_S130– Ilium_S130
Ilium_S520– Ilium_S520
IM5– IM5
IMO S– IMO_S
Infinity_i– TELENOR_Infinity_i
Infinity-10.1-v2– Infinity-101-v2
Infinity-10.1-v3– Infinity_101_v3
Infinix HOT 3 – INFINIX-X554
Infinix HOT 3 LTE– INFINIX-X553
Infinix HOT 3 LTE– INFINIX-X553-A1
Infinix HOT 4 Lite– X557-Lite
Infinix NOTE 3 Pro– X601-3G
Infinix NOTE 3 Pro– X601-LTE
Infinix NOTE 3– X601
Infinix X505– X505
INFINIX-X521– Infinix-X521-3G
Infinix-X521G1– Infinix-X521-Pro
Infinix-X521S– Infinix-X521
INFINIX-X551– INFINIX-X551
Infinix-X552-F1– INFINIX-X552-95M
INFINIX-X552– INFINIX-X552
INFINIX-X600– INFINIX-X600
INFINIX-X600– INFINIX-X600-5M
INFINIX-X600– INFINIX-X600-H533-5M
Ipanema– C001
Iris 505– iris505
iris atom– A1
iris Fuel F2– IFF2
iRULU V3– iRULU_V3
iRULU V3– iRULU_V3i

IRULU X11– iRULU-X11
IRULU X9– X9
iRULU_V4– iRULU
it1408– itel_it1408
it1408– itel_it1408C
it1505– itel_it1505
it1506– itel_it1506
it1507– itel_it1507
it1507– itel_it1507C
it1512– it1512
it1550– itel_it1550
it1551– itel_it1551
it1551– itel_it1551C
it1702– itel_it1702
itel it1355M– itel_it1355M
itel it1655– itel_it1655
itel it1655S– itel_it1655S
itel it1703– itel_it1703
itel-it1520– itel-it1520
itel-it1553– itel-it1553
JERRY– V2802AN
JIMMY– s4300ae
K-KOOL– T2800AN
K-KOOL– V2800AN
Key'TAB 1001– MB979T9
KITE– I4020
Konnect_350– Konnect_350
L20– L20
L21– L21
L50– M916-D500-PAK
L52– Haier_L52
lamda– Turbo-X_lamda
Lava A72– A72
Lava A89– A89
Lava A97– A97
Lava V2 3GB– V23GB
Lava X12– X12
Lava X17– X17

Lava X28– X28
Lava X38 2GB– X382GB
Lava X38– X38
Lava X41– X41
Lava X50– X50
Lava X81– X81
Le Max– max1_in
Le Max2– le_x2
Le Max2– le_x2_na
LE32U5000A– LE32U5000A
LE40U5000A– LE40U5000A
LE43U5000A– LE43U5000A
LE49U5000A– LE49U5000A
LENNY– s5201ap
LENNY2– s5030
LENNY2– S5030AP12H
LENNY3 MAX– V3802AN
LENNY3– V3702AN
LEX L10g– lexl10g
LEX L10ig– lexl10ig
Liberto 822 / 8030– DSB0010
Life Mark– BLU_LIFE_MARK
LIFE ONE X– BLU_LIFE_ONE_X
LIFE– Life
Lithium Ion– Turbo-X_e3
Llium L910– llium_L910
llium Pad L8– llium_Pad_L8
LS-4008– LS-4008
LS-5018– HL-L51P
LS-5506– LS-5506
LT-8001– LT-8001
M-MP7NB3G – 7_Plus_HD3G
M11H/Q1100– M11H
M2– M2
M2mini– GiONEE_WBW5612
M3– GiONEE_M3
M3– M3
M3S– GiONEE_M3S

M3s– M3s
M5– MINT-M5
M500– NGM_M500
M502– M502
M5L– M5
M6 Plus– GIONEE_BBL7516A
M6– GiONEE_BBL7515A
M631Y– M631Y
M7 Sapphire– M7
M7808– M7808
M8– Aquaris_M8
MACARON– l8401_international
MANITO– CUBOT_MANITO
Matrix– Matrix
MAX– x6069_cubot_5365u
MC36– cardhu
MC40– MC40
MD-01P– MD-01P
MegaFon Login 3– MFLogin3
METRO2– METRO2
MFLogin3T– MFLogin3T
MFLoginPh– MFLoginPh
Micromax Bolt– A064
Micromax Bolt– A065
Micromax Bolt– A082
Mini Mill v2– MG070A2T_BT
MM50– EE773X_4G
MM50– EE773X_WiFi
Mobicel GEM– GEM
Mobicel ICE– ICE
Mobicel– Sonic
Mobicel– Venus
Moova Shuffle– MoovaShuffle
Moova Soul– Moova-Soul
Motion E1.1– MotionE11
MS45– MS45
MS45S– MS45S
Ms5– MTL-MS5

MS50_4G– MS50_4G
MS50– MS50
MS50M– MS50M
MS55– MS55
Ms6– MS6
MS60– MS60
MS70– MS70
MTC 982o– MTC_982O
MTN Steppa 2 LTE – Steppa2
MTN-8978P– MTN-8978P
MultiPad Wize 3037 3G– PMT3038_3G
Multipad Wize 3757 3G– PMT3777_3G
MultiPhone 5453 DUO– PSP5453DUO
MultiPhone 5455 DUO– PSP5455DUO
MultiPhone 5504 DUO– PSP5504DUO
MultiPhone 5505 DUO– PSP5505DUO
Multiphone 5508 DUO– PSP5508DUO
MultiPhone 5517 DUO– PSP5517DUO
Muze A3– PSP3452DUO
MXG308– MXG308
MXG408– MXG408
My First Clempad 6.0– MFC_6
mymaga CLASS Plus 2– MG101A4T
N1– IUNI_N1
N1– N1
N1– Nokia_N1
N3– N3
NEO ENERGY MINI– BLU_NEO_ENERGY_MINI
NEO X – BLU_NEO_X
NEO X PLUS– BLU_NEO_X_PLUS
NEO XL– BLU_NEO_XL
NEO– NEO
netsurferDUAL 7– FMT-NM7116-01
NGM Youcolor E400– E400
NGM Youcolor E450– E450
NGM Youcolor E501– E501
NGM Youcolor E505– E505
NGM Youcolor E506– E506

NGM Youcolor E507– E507
Nitro 4G– E455
Nook Tablet 7”– st16c7bnn
NOTE S– CUBOT_CHEETAH_2
NOTE S– CUBOT_NOTE_S
NX16A10132S– NX16A10132S
NX16A11264– NX16A11264
NXA101LTE116– NXA101LTE116
NXA116QC164– NXA116QC164
NXA8LTE116– NXA8LTE116
NXA8QC116– NXA8QC116
OnePlus One– A0001
OnePlus2– OnePlus2
ONYX– ONYX
OPPO 1201– 1201
OPPO A11w– A11w
OPPO R9 Plus A– R9PlusA
OWN I62S– OWN-I62S
P10/Q10/PTAB1040/PTAB1041– pq10-Polaroid
P4– P4
P4903JP– P4903JP
P503– NGM_P503
P508– P508
P509– NGM_P509
P550– NGM_P550
P551– NGM_P551
P552– NGM_P552
P6 PRO– P6_PRO
P6– P6
P7– P7
P7/Q7/PTAB740/PTAB741– pq7-Polaroid
P901– P901
P909– P909
PAD_1042– PAD_1042
Pavapro10– Pavapro10bk
PavaPro7bk– Pavapro7bk
PeopleNet ConnectedTablet– MS5
PGN404– PGN404

PGN409– PGN409
PGN410– PGN410
PGN507– PGN507
PGN509– PGN509
PGN511– PGN511
PGN513– PGN513
PGN514– PGN514
PGN515– PGN515
PGN516– PGN516
PGN517– PGN517
PGN518– PGN518
PGN521– PGN521
PGN522– PGN522
PGN523– PGN523
PGN605– PGN605
PGN606– PGN606
PGN607– PGN607
PGN608– PGN608
PGN609– PGN609
PGN610– PGN610
PGN611– PGN611
PGN612– PGN612
Phantom 5– Phantom5
PHANTOM-Z-mini– PTM-Z-mini
Phantom6 plus– Phantom6-Plus
Phantom6– Phantom6
PhonePad 7 II– PP7E-DLA1
Platium vp.1– VerssedVP1
Platium vp.2 – VerssedVP2
PLAY– PLAY
PLUM– PLUM
Plume P6 Pro LTE– PGN528
PMT3031_3G– PMT3011_3G
PMT3047_3G– PMT3047_3G
PMT3208_3G– PN80A03G
PMT3351_3G– PN10A01G
PMT3437_3G– JP70A1W
PMT3607_4G– WT70A1L

PMT3608_4G– LS80A1L
PMT3797_3G– JU70A1G
PMT5002_Wi– PMT5002_Wi
PMT5011_3G– PMT5001_3G
PMT5018_3G– PMT5008_3G
PMT7008_4G– PMT7008_4G
PNDPP44Q7GPBLK– PNDPP44Q7GPBLK
Polaroid L10/P1000– L10
Polaroid L9– L9
Polaroid M11– M11
Polaroid P1000– P1000
Polaroid P700/A700– P700
Polaroid P900– P900
Polaroid P902/A900– P902
Polaroid Power P600– P600
Polaroid Snap S50– S50
Polaroid Snap S55– S55
Polaroid Snap S60– S60
Pollux– TC70
Pollux– TC75
Prestige Elite10QI– Elite10QI
Prestige Elite10QL– Elite10QL
Prestige Elite10QS– Elite10QS
Prestige Elite11Q– Elite11Q
Prestige Elite13Q– Elite13Q
Prestige Elite8QI– Elite8QI
Prestige Elite8QL– Elite8QL
Prestige Elite9QL– Elite9QL
Prestige Prime10ES– Prime10ES
Prestige Prime11E– Prime11E
Prestigio Grace 3118 3G– JU80A2G
Prestigio Grace– PSP7557
Prestigio MultiPad Wize 3018– PMT3018_WI
Prestigio Wize 3147 3G– LS70A2G
Prestigio WIZE A3– PSP3453DUO
Pro 3– Pro_3
PRO5043– PRO5043
PRO5044PEE01– Polaroid_PRO5044PEE01

PRO5544PEE01– PRO5544PEE01
PRO5584PHE01– PRO5584PHE01
PSP3404DUO– PSP3404DUO
PSP3405DUO– PSP3405DUO
PSP3423DUO– GF40B1G
PSP3450DUO– PSP3450DUO
PSP3456DUO– PSP3456DUO
PSP3457DUO– KT45B01G
PSP3459DUO– TE45B3G
PSP3502DUO– PSP3502DUO
PSP3504DUO– PSP3504DUO
PSP3517DUO– TE50B2G
PSP3531DUO– DW53B01G
PSP5454DUO– PSP5454DUO
PSP5507DUO– PSP5507DUO
PSP5512DUO– TE50B3G
PSP5516DUO– DW50A03G
PSP5519DUO– TE50B4L
PSP5531– DW53B4G
PSP5550DUO– PSP5550DUO
PSP5551DUO– DW55B02L
PSP7511DUO– DW50B5G
PSP7530DUO– DW53B3G
PTSGOB8– PTSGOB8
PULP 4G– I5421
PULP FAB 4G– I5261
PULP FAB– S5260
PULP– S5420
PURE XL– BLU_PURE_XL
Q-Touch– Q-Touch
Q.4514– Q4514
Q4S6IN4G– Q4S6IN4G
Q4T10IN– Q4T10IN
Q4T7IN– Q4T7IN
Q4T7IN3G– Q4T7IN3G
Q4T8IN– Q4T8IN
Q5– Q5
Q5S55IN4G– Q5S55IN4G

Q5S5IN4G– Q5S5IN4G
Q6S5IN4G– Q6S5IN4G
Q6T10IN– Q6T10IN
Q6T10IN4G– Q6T10IN4G
Q6T7IN– Q6T7IN
Q7S55IN4G– Q7S55IN4G
Q7S5IN4G– Q7S5IN4G
Q7S5IN4GP– Q7S5IN4GP
Q7T10INP– Q7T10INP
R1011w– R1011
R7 Plusf– R7Plusm
R7– R7
R7005– R3
R7c– R7c
R7kc– R7kc
R7kf– R7f
R7Plust– R7Plus
R7st– R7s
R8106– R5
R8200– R1C
R8201– R1x
R827– R827
RACE Blot2– Infinix_X454
RACE Bolt 3– X455
RAINBOW 4G– I5503
Rainbow II 3G 8"– mr801
RAINBOW JAM– s5250
RAINBOW JAM– s5254
RAINBOW JAM– S5254AP24K
RAINBOW LITE 4G– L5221
RAINBOW LITE 4G– L5221AE23G
RAINBOW LITE 4G– L5225AC
RAINBOW LITE 4G– L5227AC
RAINBOW LITE 4G– L5251
RAINBOW LITE– s5222
RAINBOW UP 4G– I5401
RAINBOW UP– s5400
Rainbow– RAINBOW

RAINBOW– s5501
RainbowIII3G– RainbowIII3G
RealPad MA7BX2– RealPad_MA7BX2_1
Retro– Retro
RIDGE – s5513ap
RIDGE 4G– I5510
RIDGE FAB 4G– I5320
ROBBY– V3750AN
ROBBY– V3750AN24K
Rubik10.1"II– H1021H4C1_I
RubikII 10"– q102
Ruby– ForwardRuby
S2– WBL7519SY
S3015– S3015
S3T10IN3G– S3T10IN3G
S3T7IN3G– S3T7IN3G
S4S5IN4G– S4S5IN4G
S4S6IN3G– S4S6IN3G
S4T10IN3G– S4T10IN3G
S4T7IN3G– S4T7IN3G
S5.1– GN9005
S5.1– S5_1
S50– CatS50
S5S5IN4G– S5S5IN4G
S6 Pro– GIONEE_GBL7529
S8– GIONEE_WBL7517
Samba– Samba
Selecline-854599– 854599
Selfie 2– Q340
Selfie 3– Q348
SELFY 4G– I4801
SELFY– SELFY
SENSEIT_A109– SENSEIT_A109
SF550– SF550
Shaker-Slim– Shaker-Slim
ShakerBeat– ShakerBeat
SHIFT– SHIFT
SIGMA 5– SIGMA-5

Skill– Skill

Slate 8 Tablet– NKS_AQT80

Sliver 5– Q450

Smart 505– Smart505

Smart 63– SMART63

SMART Sprint– SMARTSprint

Smart Tab 1004XS– SmartTab_1004_XS

Smart' Tab 1006– M16Q1A

Smartab SRF79– SRF79

Smartab ST10– ST10

Smartab ST7– ST7

Smartfren Andromax AD681H– AD681H

Smartfren Andromax AD682H– AD682H

Smartfren Andromax AD9A1H– AD9A1H

Smartfren AndromaxNC36B1H– NC36B1H

Smartphone JS LS-5010– LS-5010

SmartTab_8004– T814

SOHO– SOHO

SP4– SP4

sp401– sp401

ST1003S– T1882R

StarQ_Q5002– StarQ_Q5002

Status– Status

STJR700– STJR700

Storm 2e Plus– Storm_2e_Plus

Storm 3– W230

STR-9.6-Tablet– STR_96_Tablet

Streamachine– X13

StrikaPlay– StrikaPlay

Studio 5.5 HD– S150

Studio C HD– BLU_STUDIO_C_HD

Studio G HD– STUDIO_G_HD

STUDIO G PLUS– Studio_G_Plus

STUDIO M HD– BLU_STUDIO_M_HD

STUDIO ONE PLUS– BLU_STUDIO_ONE_PLUS

Studio One– BLU_STUDIO_ONE

STUDIO SELFIE 2– BLU_STUDIO_SELFIE_2

Studio Selfie LTE– BLU_STUDIO_SELFIE_LTE

Studio X Mini– BLU_STUDIO_X_MINI
STUDIO XL LTE– BLU_STUDIO_XL_LTE
SUGAR F7 mini– p7203
SUNNY– T2504AN
SUNNY– V2502AN
SUNNY– V2504AN
SUNSET– s4011
SUNSET2– s4050ap
SURF 2– INFINIX_X511
SurfTab breeze 9.6 quad – SurfTab
SurfTab breeze 9.6 quad 3G – ST9641602
SUTDIO ENERGY 2– BLU_STUDIO_ENERGY_2
Swift– Swift
SYMPHONY i10– i10
SYMPHONY R100– R100
SYMPHONY R20– R20
SYMPHONY V75– V75
Symphony_P7– Symphony_P7
SYNC 5C– STK_Sync_5c
Sync 5e– STK_Sync_5e
T2702– T2702
T72HMs 3G– T72HM3G
TAB-A02– TAB-A02
TAB-A03– TAB-A03
Tab64– AprixTab64
TC55– TC55
TC70x– TC70x
TC75x– TC75x
TC75xDF– TC75xDF
TC8000– TC8000
TECNO N5S– N5S
TECNO W5 Lite– W5Lite
TECNO W5– TECNO-W5
TECNO-A7S– TECNO-A7S
TECNO-C5– TECNO-C5
TECNO-C7– TECNO-C7
TECNO-C8– TECNO-C8
TECNO-C9– TECNO-C9

TECNO-J5– TECNO-J5
TECNO-J8– TECNO-J8
TECNO-L5– TECNO-L5
TECNO-L8Plus– TECNO-L8
TECNO-M6S– g335_b1
TECNO-N2S– TECNO_N2S
TECNO-N6– TECNO-N6
TECNO-N6S– TECNO-N6S
TECNO-N8– TECNO-N8
TECNO-N8S– TECNO-N8S
TECNO-PHANTOM5– TECNO-PHANTOM5
TECNO-W2– TECNO_W2
TECNO-W3– TECNO-W3
TECNO-W3LTE– TECNO-W3LTE
TECNO-W4– TECNO_W4
TECNO-Y3+– TECNO-Y2
TECNO-Y3S– TECNO-Y3S
TECNO-Y4– TECNO-Y4
TECNO-Y5– TECNO-Y5
TECNO-Y6– TECNO-Y6
TFX711G– TFX711G
TFX712G– TFX712G
TFX713L– TFX713L
TFX714L– TFX714L
TM101A530L– TM101A530L
TM106A510L– TM106A510L
TM700A520L– TM700A
TM785M3– TM785M3
TM800A510L– TM800A
TM800A550L– TM800A550L
TMK27A2– TMK27A2
TOMMY– P4901AC
tphone– rimo01a
TR10CS1– TR10CS1_12
TR10RS1– TR10RS1_2
Trendy– TREDNY
Trinity T101– Trinity_T101
Trinity T900– Trinity_T900

Trio 7.85 vQ– Trio-785-vQ
Trio MINI– Trio-MINI
TRIO-7.85– astar-y3
Trio-Stealth G4 7– Trio-Stealth-G4-7
Trio-Stealth-G4-101– Trio-Stealth-G4-101
Trio-Stealth-G4-7.85– Trio-Stealth-G4-785
TRIP– TRIP
Turbo-X s2– s2
Turbo-X_epsilon– Turbo-X_epsilon
Turbo-X_pi_4G– Turbo-X_pi_4G
TZ55– TZ55
U FEEL FAB– V3991AN
U FEEL GO– P4661AN
U FEEL LITE– P4601AN
U FEEL PRIME– p7201
U FEEL– P6601AE
U FEEL– P6609BC
U FEEL– P6609BCD
U3– U3
ULTRA– Ultra
Unite3– Q372
V TAB 8029– V_TAB_8029
V100– V100
V2s– V2s
V3– V3
V45M– V45M
V4S– V4S
V85– V85
VERSSSED platinum vp.2.1– VERSSSEDvp2-1
Verssed Platinum VP3.0– VERSSSED_Vp3
VIA_T41– VIA_T41
ViewPad IR7Q– IR7Q
Viewsonic – ViewPad_IR10Q
Viewsonic – ViewPad_IR8Q
VIVO 5– BLU_VIVO_5
VIVO XL– BLU_VIVO_XL
Voyage V6– HM-V6
W032I_C3– w032i_c3

W717– W717
W900S– GiONEE_BFL7506A
W909– GiONEE_BFL7512B
WAX– s8515
Wooze I 5– Wooze_I5
Wooze I 5.5 Gris– Wooze_I55
Woozel45– Woozel45
WT6000– WT6000
X10– X10A
X100– ILIUM_X100
X11– X11
X18– X18
X3_PRO_SLIM– X3_PRO_SLIM
X3– X3
X400– Ilium_X400
X4503– X4503
X46– LX46
X47– X47
X5_PRO– X5_PRO
X50 Plus– X50_Plus
X9000– X9000
X9006– X9006
X9007– X9007
X9070– X9070
X9076– X9076
X9077– FIND7
X9077– X9077
X9079– X9079
Xino Z46 X4+– xino_z46
XOLO era 4K– XOLO_era_4K
Xolo Era X– era_X
XOLO One HD– XOLO_One_HD
Xpress 2– E313
Y88X Plus– Y88X_PLUS
YotaPhone2– yotaphone2
YUPHORIA– YUPHORIA
Yureka– YUREKA
Zero Spin– Zero_Spin

ZVII– ZVII

Zyro– zyro

TCT MOBILE LIMITED (ALCATEL)

4060W– Pixi445

5023F– Pixi4PlusPower

5027B– Pixi445SPR

5042T– ALTO45TMO

5051X– POP45

5054W– Pop355

5056G– POP455C

5065N– Pop35

5070D– P3-5_4G

5080F– shine_lite

5098O– Pixi4-6_4G_CKT

6037Y– Eclipse

6039A– idol347

6042D– CROSSAPAC

6043A– DIABLOXPLUS

6044D– I1-5_4G

6055B– idol4

7040T– Yaris5TMO

7045Y– RIO5

7070Q– POP4-6_4G

8030B– HERO2

8030B– HERO2PLUS

8050D– Pixi4-6_3G

8055– Pixi3-7

8063– Pixi4-7_WIFI

8070– Pixi3-8_WIFI

8079– Pixi3-10_WiFi

9001D– Pixi4-6_4G

9002A– Pixi3-7_3G

9003A– Pixi4-7_3G

9005X– PIXO8_3G

9006W– Pixi2-7_4G_TMO

9007X– Pixi3-7_4G_EE
9010X– Pixi3-10_3G
9015B– Pixi4-7_4G_Bell
9015B– Pixi4-7_4G_NA
9015Q– PIXI4-7_4G
9015W– Pixi4-7_4G_TMO
9020A– tint8_att
9021A– Pop2-8_4G_Telus
9025Q– POP4-7_4G
9030G– POP4-10_4G
A450TL– ALTO45_TF
A460T– PIXI3_4TF
A464BG– Pixi3-35TF
A520L– Alto4EVDO
A521L– Alto4NA
A622GL– Pixi3554GEVDO
A846L– Alto5TF
ALCATEL 4015T– Yaris35_GSM
ALCATEL A564R– Yaris5NA
ALCATEL ONE TOUCH 4037N– SOUL4NA
ALCATEL ONE TOUCH 6040D– DIABLOX
ALCATEL ONE TOUCH 7040E– YARISXL
ALCATEL ONE TOUCH 7047D– YARIS_55
ALCATEL ONE TOUCH 8020D– SCRIBEPRO
ALCATEL ONETOUCH Flash Plus– CROSS2
ALCATEL ONETOUCH IDOL 3 (5.5)– idol3
ALCATEL ONETOUCH PIXI 3 (3.5)– PIXI3_35
ALCATEL ONETOUCH PIXI 3 (4.5)– PIXI3_45_4G
ALCATEL ONETOUCH POP 3 (5.5)– PIXI3-55
ALCATEL ONETOUCH POP 3 (5)– PIXI3-5
ALCATEL ONETOUCH Victory– 7046T
alcatel PIXI 4 (5.5)– PIXI4_55_3G
ALCATEL PIXI 4 (5)– PIXI4_5_4G
Alcatel_4060A– Pop445
Alcatel_5098O– Pixi4-64GMEX
Alcatel_7049D– Lion-5
ALCATEL_ONE_TOUCH_P310X– POP7
ALCATEL_ONE_TOUCH_P320X– POP8

Alcatel9007T– Pixi3_7_4G
AM-H100– EOS_lte
D820X– HERO8
FL03– FLASH3
Go PLAY– alto5_sporty
Hero2C– Hero2C
I-L1– mercury
I216A– PIXI7
I221– PIXI8
Idol2 MINI S– MIATA_lte
Mirage– feijao
n1 max– m823_cmcc
No– Pixi445Cricket
NOS Roya– Alto45
Nura2– m823_orange
ONE TOUCH 6012X– California
ONETOUCH PIXI 3 (8) – pixi384g
ONETOUCH PIXI3(7)– pixi37
Orange Dive 50– pixi3_45_4g_orange
Orange Nura– M812
Orange_Sego– Orange_Sego
Orange- Rise31– Pixi4-4
P350X– POP8_LTE
P360X– POP10
PIXI 4 (5) – Pixi4-5
PIXI3(4.5)– Pixi3-45
PIXI3(4)– Pixi3-4
PIXI4 (3.5)– PIXI4-35
Pixi4-4 3G Telus– PIXI4_4TF
PIXI™4– Pixi445CAN
Pixo 7– PIXO7
POP 2 (5)– alto5
POP 2 (5)– alto5_premium
POP 4S– shine_plus
POP2 (4.5)– alto45_latam_b28
POP2 (4)– alto4
POP2 (4)– alto4_8g
SOL PRIME– idol4s

Soul 3.5– SOUL35
Soul 4– SOUL4
Soul 4.5– SOUL45_GSM
TCL 302U– Festa5_CU
TCL 750– x1_plus
TCL 950– idol4s_cn
TCL D40 DUAL– D40
TCL i708U– EOS_MACAN
TCL i718M– EOS_Plus
TCL i718M– EOS2
TCL P301M– TCL_P301M
TCL P316L– Festa5_CT
TCL P331M– TCL_P331M
TCL P332U– TCL_P332U
TCL P360W– Focus5_CU
TCL P500M– Festa_L
TCL P520L– Bora5_CT
TCL P618L– HUMMER5_CT
TCL P689L– POLO55
TCL P728M– CROSS_LTE
TCL T500L– evoque_cn
TCL_P561U– Fit55_CU
Telekom_Puls– T-Tab
VF-1296– voda_tab
VF-1397– Vodafone_Tab_speed_6
VF-1497– Vodafone_Tab_Prime
VF685– VF685
VF695– VF695
VFD1100– Tab7
Vodacom Kicka VE– VFD100
Vodafone 785– Vodafone_785
Vodafone 895– VF-895N
Vodafone 985N– Vodafone985N
Vodafone Smart mini 7– VFD300
Vodafone Smart platinum 7– VFD900
Vodafone Smart Tab 4– Vodafone_Smart_Tab_4
Vodafone Smart turbo 7– VFD500
Vodafone Smart turbo 7– VFD501

Vodafone Smart ultra 7– VFD700

Vodafone Tab Prime 7– VFD1400

Vodafone_Smart_Tab_3G– Vodafone_Smart_Tab_3G

Vodafone_Smart_Tab_4G– Vodafone_Smart_Tab_4G

TOSHIBA CORPORATION

A204– tos14ast10

VERTU

Aster T– alexa

Signature Touch– odin

Signature Touch– titan

VESTEL

Farabi– frb3g

Venus V3 5020– Arya

Venus V3 5040– Venus_V3_5040

Venus V3 5070– Venus_V3_5070

Venus V3 5570– Venus_V3_5570

VSP250g– VSP250g

VSP250s– VSP250s

VSP355g– g55

VSP355s– s55

VT10E– VT10E

VT785P2– VT785P2

VIVO

vivo 1601– 1601

vivo X5Pro– X5Pro

vivo X9– PD1616

vivo X9i– PD1624

vivo X9Plus– PD1619

vivo Xplay6– PD1610

vivo Y21L– Y21L

vivo Y51– Y51

vivo Y55– 1603

vivo Y55A – PD1613

vivo Y66– PD1621

WIND RIVER**10 Viking II Pro**– RCT6603W87M7**10 Viking II**– RCT6603W47M7**10 Viking Pro**– RCT6303W87DK**10 Viking Pro**– RCT6303W87M**10 Viking Pro**– RCT6303W87M7**11 Maven Pro**– RCT6213W87DK**7 Mercury**– RCT6673W23M**7 Mercury**– RCT6673W43M**A10A**– A10A**A205**– tos15ast20**A37fw-International**– A37fs**A40C**– A40C**AS01M**– AS01M**AX1010**– Bmobile_AX1010**AX1020**– Bmobile_AX1020**AX1030**– Bmobile_AX1030**AX1035**– Bmobile_AX1035**AX1055**– Bmobile_AX1055**AX1060**– AX1060**AX1065**– Bmobile_AX1065**AX660**– Bmobile**AX685**– Bmobile_AX685**AX810**– Bmobile_AX810**azumi_A50LT**– A50LT**C15100i**– C15100i**C15100m**– Pixi3-7_KD**C7**– PGN_506**Cell C Evolve**– CELLC_Evolve**Cell C Nitro**– CELLC_Nitro**CellC_Extreme**– CELLC_Extreme**CF10**– CF10**Condor A9**– PGN_507**Condor C6+**– PGN_508**Connect503**– L-ite502**CT726**– CT726**CT826**– CT826

DG-Q08M– DG-Q08M
DL 3406– G02DL
DL_3903– Tablet_DL_3903
DL1008M– mid1008l_emmc
DL3920– Tablet_DL_3920
Ellipsis 10– QTAIR7
Ellipsis 7 (QMV7A)– QMV7A
Ellipsis 8– QTAQZ3
Enjoy TE1– TE1
EVC10Q– EVIANT_EVT10Q
EVC8Q– EVIANT_EVC8Q
FLOW– Kruger_Matz_FLOW
FNB– SP5045V
FREETEL Priori3S– FTU152A
FREETEL Samurai Rei– FTJ161B
FTJ152C– FTJ152C
FTJ161A– FTJ161A
FTU152D– FTU152D
Fun +– FTU161G
Gigaset ME– ME
Hurricane Blast– Blast
Hurricane Charge– Charge
i-Player_KIDS– Tablet_DL_3910
K-Touch920– KTOUCH920
K3– K3
Kiwami– FTJ152D
Kruger_Matz_FLOW2– Kruger_Matz_FLOW2
L-EMENT350– L-EMENT350
L-EMENT400– LEMENT400
L-EMENT500– L-EMENT500L
L-EMENT550– L-EMENT550
L-EMENTTAB1042– LEMENTTAB1042BTK
L-ITE 502 PLUS– L-ITE502PLUS
L-ITE402– L-ITE402
L-ITE552– L-ITE552
L-IXIR TAB 701 3G– TAB701
L35– L35
L55– L55

L930i– L930i
LEMENTTAB901– LEMENTTAB901
LS-4503– LS-4503
LS-5009– LS-5009
M1092R– M1092R
M2s– M2s
ME Pro– MEpro
ME Pure– MEpure
Metal Tablet– Metal_Tablet_10
MID 107– MID107
MT-734G– MT-734G
OBJ SJ1.5– SJ1-5
OPPO A39tm– A39
PD1304DL– PD1304DL
PD1419V– PD1419V
Primo– PRIMO
Priori 3– FTJ152A
Priori3S– FTJ152B
Pro10 Edition II– RCT6203W46L
QTAQZ3KID– QTAQZ3KID
RC501L– RC501L
RCT6223W97– RCT6223W97
RCT6283W27– RCT6283W27
RCT6603W47– RCT6603W47DK
RCT6673W-V1– RCT6673W-V1
RX300– X300
S4040– S4040
Smart HD– Smart_HD
SMART_Sprint_4G– SMART_Sprint_4G
Solely Tab S7– HV1A
Spectralink 8744– thor_6dq
T10+– T10plus
T7– T7
Techno L6– TECNO-L6
TH805– TH805
TM772– TM772
Touch 2C– Touch2c
V.40– Nextel

V.45– VSN
VAX114– VAX114
WoongjinThinkbig– BP-1001
X5Max– X5Max
ZA-407– ZA-407
Zero 2– Infinix_X509

XIAOMI

HM 1SC– armani
HM 1SLTETD – HM2014501
HM 1STD– HM2014011
HM 2A– lte26007
HM 2LTE-BR– HM2014819
HM 2LTE-CMCC– HM2014813
HM 2LTE-CT– HM2014812
HM 2LTE-CU– HM2014811
HM 2LTE-IN– HM2014818
HM 2LTE-SA– HM2014817
HM NOTE 1LTETD– dior
HM NOTE 1S CT– gucci
HM NOTE 1TD– lcsh92_wet_tdd
HM NOTE 1W– lcsh92_wet_jb9
HM Note 2– hermes
Hong Mi– HM2013022
MI 2– aries
MI 2A– taurus
Mi 3– pisces
Mi 4c– libra
Mi 4i– ferrari
MI 4LTE– cancro
MI 4s– aqua
Mi 5– gemini
MI 5s Plus– natrium
Mi 5s– capricorn
MI MAX– helium
MI MAX– hydrogen
MI NOTE Pro– leo

Mi Note– virgo
Mi Note2– scorio
MI PAD– mocha
MIPAD2– latte
MIX– lithium
Redmi 3– ido
Redmi 3S– land
Redmi 4 Pro– markw
Redmi 4– prada
Redmi Note 3– hennessy
Redmi Note 3– kate
Redmi Note 3– kenzo
Redmi Note 4– nikel
Redmi– HM2013023

ZTE

402ZT– ZTE-402ZT
A1P– ailsa
A1R– billy
A2– A2
Amazing X7– P839V56
Amazing_X3s_16G – Amazing_X3s
Andromax G46D1Z– Andromax_G46D1Z
B860AV2– p200_2G
Blade A465– ZTE_Blade_A465
Blade A475– ZTE_Blade_A475
BLADE A510 – P635A50
Blade A511– ZTE_Blade_A511
Blade L2 Plus– ZTE_Blade_L2_PLUS
Blade L3 Plus– Blade_L3_Plus
Blade L5– P172A40
Blade Q2– P172A12
Blade V+– P816A12
Blade V6– P635A20
Chapel– chapel
Grand X Max 2– jerry
Infinity X^2 mini– msm8226
K83– K83

K85– K85

K88– jasmine

LS-5008– P839F30

LS-5503– P839F50

MO-01J – MO-01J

N817– wellington

N9101– apollo

N9130– speed

N9132– cinco

N9180– N9180

N918St– N918St

N940Sc– N940Sc

N9510– warplte

N9515– warp4

N9516– eridani

N9518– warp6

N9520– stormer

N9521– max

N958St– N958St

NX403A– NX403A

NX406E– NX406E

NX40X– NX402

NX505J– NX505J

NX506J– NX506J

NX507J– NX507J

NX508J– NX508J

NX510J– NX510J

NX511J_V3– NX511J_V3

NX511J– NX511J

NX512J– NX512J

NX513J– NX513J

NX521J– NX521J

NX523J_V1– NX523J_V1

NX527J_V1 – NX527J_V1

NX529J– NX529J

NX531J – NX531J

NX535J – NX535J

NX541J – NX541J

NX601J– NX601J
Orange Dive 71– Orange_Dive_71
Orange Hi 4G– Orange_Hi_4G
Orange Neva 80– Orange_Neva_80
Orange Rono– Vec4G
SoshPhone 3– SoshPhone_3
Spro 2– msm8974
Tempo– xray45
Turk Telekom TT175– ZTE_Blade_V580
TURKCELL T60– P839T60
TURKCELL T70– P809T70
Uhura– noah
V55– V55
V8285– MT8382
V8514– P821E10
V9180 – V9180
VFD 200– P731V35
VFD 600– P809V50
Vodafone Smart ultra 6– P839V55
X9180– X9180
Z353VL– oldman
Z667– demi
Z667T– bonnie
Z716BL– baffin
Z717VL– lavender
Z752C– eros
Z753G– faerie
Z755– iris
Z787– apus
Z792– giant
Z793C– hera
Z813– xuantan
Z818L– sunny
Z819L– sungod
Z820– P675T07
Z826– herculis
Z828– achill
Z830– gruis

Z832– mimir
Z850– sif
Z861BL– benz
Z862VL– captain
Z936L– gift
Z958– lol
Z959– abby
Z962BL– tom
Z963U– lily
Z963VL– nancy
Z970– draconis
Z987– cygni
Z998– coeus
Zmax Pro– urd
ZTE A2015– msm8994
ZTE A2017G – ailsa_ii
ZTE A880– ZTE-A880
ZTE B2016 – msm8916_64
ZTE B2017G – msm8952_64
ZTE B880– P635N30
ZTE B880– S_P635N30
ZTE BA510– P635T39
ZTE BA601– ZTE_BA601
ZTE BA610C– P635N36
ZTE BA610T – P635T36
ZTE BA610T – V_P635T36
ZTE BA910 – V_P653N31
ZTE BA910– P653N31
ZTE BA910T – T_P653N31
ZTE BLADE A110– ZTE_BLADE_A110
ZTE Blade A210– ZTE_Blade_A210
ZTE BLADE A310– P809A50
ZTE Blade A315– ZTE_Blade_A315
ZTE Blade A410– P635E40
ZTE Blade A452– P635F33
ZTE Blade A460– P809A20
ZTE Blade A470– P809A40
ZTE Blade A476– ZTE_Blade_A476

ZTE BLADE A506 – P809F52
ZTE BLADE A512 – P817E52
ZTE BLADE A601 – ZTE_BLADE_A601
ZTE BLADE A610 – ZTE_BLADE_A610
ZTE BLADE A910 – P635A31
ZTE BLADE B112 – P635A60
ZTE Blade C312– P715A20
ZTE Blade C370– ZTE_Blade_C370
ZTE Blade D6 Lite 3G– P658A10
ZTE Blade D6 Lite 4G– P635A30
ZTE Blade G Lux– P172F10
ZTE Blade HN– ZTE_Blade_HN
ZTE BLADE L110 – ZTE_BLADE_L110
ZTE Blade L2– P182A10
ZTE Blade L3 Apex– ZTE_Blade_L3_Apex
ZTE Blade L3 Lite– P172A50
ZTE Blade L3 Plus– ZTE_Blade_L3_Plus
ZTE Blade L3– P182A20
ZTE Blade L315– ZTE_Blade_L315
ZTE Blade L5 Plus– P680A20
ZTE Blade L6– P680A10
ZTE Blade Q Lux– P632A10
ZTE BLADE V0710 – ZTE_BLADE_V0710
ZTE BLADE V0720 – ZTE_BLADE_V0720
ZTE Blade V220– msm8916_32
ZTE BLADE V7 – P653A10
ZTE Blade V770– P852F52
ZTE Blade Vec Pro– P692S20_M92
ZTE Blade Vec– P692S20_Q82
ZTE BV0701 – P653N11
ZTE BV0710T – P655A30
ZTE BV0720 – P650A30
ZTE C2016– orchid
ZTE C880– P635N32
ZTE C880A– P635B32
ZTE C880D– P635D32
ZTE C880S– P635N34
ZTE C880S– S_P635N34

ZTE C880S– T_P635N34
ZTE C880S– V_P635N34
ZTE C880U– P635V32
ZTE Fanfare 2– sheen
ZTE G717C– P692N30
ZTE G718C– ZTE-G718C
ZTE G719C– ZTE-G719C
ZTE G720C– ZTE-G720C
ZTE G720T– P839T30
ZTE G720T– V_P839T30
ZTE Kis 3– ZTE-P821E10
ZTE N928Dt– N928Dt
ZTE P_C880S– P_P635N34
ZTE Q2S-C– P826N50
ZTE Q2S-T– P826T50
ZTE Q302C– P809N20
ZTE Q5-C– P816N34
ZTE Q5-T– CU_P816T32
ZTE Q5-T– P816T32
ZTE Q507T– P682T20
ZTE Q508U– P816V50
ZTE Q509T– P632T31
ZTE Q519T– ZTE_Q519T
ZTE Q529C– P635N33
ZTE Q529C– V_P635N33
ZTE Q529E– P635T35
ZTE Q529T– P635T33
ZTE Q7-C– P839N50
ZTE Q7– CMCC_P839V50
ZTE Q7– CU_P839V50
ZTE Q7– P839V50
ZTE Q802C– ZTE-Q802C
ZTE Q802D– ZTE-Q802D
ZTE Q806T– V_P635T30
ZTE S2010– P_P653S10
ZTE S2010– P653S10
ZTE S2010– V_P653S10
ZTE S2010– ZTE_S2010

ZTE S2014– ZTE-S2014
ZTE S2015– ZTE-S2015
ZTE T325– ZTE_T325
ZTE T617– ZTE_T617
ZTE T620– ZTE_T620
ZTE T630– P635T30
ZTE T792– ZTE-T792
ZTE T84– P816A20
ZTE T920– ZTE_T920
ZTE V7073– V7073
ZTE V779M– ZTEV779M
ZTE V811– ZTE-V811
ZTE V811C– P810E01
ZTE V813W– P172B20
ZTE V815W– P172R10
ZTE V831W– P731A10
ZTE V9820– ZTE-V9820
ZTE V993W– ZTE_V993W
ZTE Warp 7– beam

IRIVER

Insignia Flex 8"– ns_15at08

UNKNOWN

250
870
7021
7252
8675
109v82_gq3016_reeder
109v82_gq3016_syh
109v82_gq3016_zuum
111wv82_ht_fwvga
111wv82_jbaol1_fwvga_Huella C50S
111wv82_zxdg503qhd_cube
111wv82_zxdg503qhd_primux
2111wv82_zxdg452qhd_primux

325Style
326C2
326D
4Good S450m 4G
4Good S502m 4G_4Good_S502m_4G
5.5W
6S
6S Plus
7 Plus
700v82_gq_p60
709v82_jbla118
709v82_jbla828
77X
8312D
8675-W00
86v_sd
8x-1000
8X-1020
A01B_S10A
A1+ Champ
A1+ Super
A1+Champ_3G
A1000s
A1000s_Lite
A1010
A102
a102_42_ax_dh_w401a_simlock
A110
A119
A18
A180
A19
A19 Plus
A1X PLUS
a20_324_lj_t66_aplus_fw
A2010-I
a20e_ax_lj_t66_aplus
a20e_ax_tianmao_i7_twz

a20e_ax_youshi_s018_inovo
a20e_ax_youshi_s018_skg
A28
a2e_ae_qy_a14
a2e_aw_a11_star
a2e_aw_a12_star
a2e_ax_qy_a5s_uk
a3_324_xhd_m6_syh
a30e_ax_tianmao_q30_myphone_m10
a3465
a350n_ae_a51_plus
a350n_af_utl_a55i
a3565
a3e_ax_hengda_k7w_taiguo2
a3e_ax_tianmao_q6
a3e_ax_tianmao_q6_b2b5_gigo
a3e_ax_tianmao_q6_myphone
a3e_ax_tianmao_q6_zx
a3e_ax_tianmao_q7
a3e_ax_xhd_k10_multilang
a3se_af_licheng_st06_gr
A408
A42
A48
A500 Club
A55
A5EI
A5s
A6 Turbo
A600
A66A*
a6e_ax_jhy_zyq_q668
a6e_ax_tianmao_p800_twz
a6e_ax_youshi_s002_dopod
A6Turbo3G
a7237
A74B
A76

A7E

a7e_ax_huge_502_rivo_rx40

A7X_PTAB735X

a825_324_ax_aplus_a700

a825_324_ax_xhd_k18_tg

a825_324_ax_xz_k1_i6s

a831_324_ax_jh_k8_vc

a831_324_ax_ys_s028_icherry_1

a831e_ax_ys_s028_inovo

a831e_ax_ys_s028_skg

a831e_ax_ys_s029_icherry

a832_324_ax_prx_s4_twz

a832_324_ax_prx_s4_winds

a880e_ae_qy_a40

a880e_ax_qy_a40plus

ac45bti

AC5EI

ac70plv2

ACCENT

ACCENT Fast7 4G

ACCESSGO 4E

acer_fossilhd

acer_longines

ADMIRAL410

ADMIRAL513

ADVAN

ADVAN S5E Pro

advan8321_9709

advan8321_9709b

advan8321_9719e

advan8735m_9706

advan8735m_9706c

advan8735m_9710

advan89_6833

advan92_6922

advan92_6925

aegir

aeon6580_we_l

aeon6735_65c_s_l1
aeon6735m_65c_l
aeon6735m_65u_l
aeon6752_lwt_cu
AF9899
AG CHROME MINI
AG Chrome Selfie
AG CHROME SWIFT
AG CHROME ULTRA
AG Chrome Vibe
AG Ultra 2
AG7
ai_f3_lca
ai_qhd55_kk
AIR A6
AKAI_NEO
Alfa 8
Alfa_5
ALLVIEW
ALLVIEW_A4You
ALLVIEW_A5Smiley
Allview_AX4Nano_ICS
Allview_AX5NanoQ_KK
ALLVIEW_E2_Living
ALLVIEW_P5Life
Allview_P6Life
alps
amami
Andi
Andi_3.5KKe_winner+
Andi3.5F_Grabit
Andi4_Arc
Andi4F_Waves-
Andi4U Frisbee
Andi5_Stallion
Andi5_Stallion+
Andi5M_Xotic_2GB
android

Android TV 550D
android_4x_wet_kk
ANDY_4EI2
Andy_5EI
Andy35E2I
Andy35EI
ANDY45EL
Andy4E2I
ANDY4EI2
ANDY4EL2_LTE
ANDY5EI
ANDY5EL
AndyAC4EI
anzhen4_mrd7
AppPlayer
AppPlayer-5f8e44f4-9745-11e5-8ac5-d8cb8a4027ee
AppPlayer-686a8211-5434-11e5-b08a-cf2cffb5bd79
Aqua 5X
Aqua Ace II
Aqua Ace Mini
Aqua Air
Aqua Air II
Aqua Craze
Aqua I3 K
Aqua Lite
Aqua Raze
Aqua Strong 5.1
Aqua Super
Aqua T2
Aqua Twist
Aqua Wing
Aqua X
Aqua Y2
Aqua_3G
Aqua_3G_Mini
Aqua_4G_Strong
Aqua_4G+
Aqua_A1

Aqua_Ace
Aqua_Amaze
Aqua_Desire_HD
Aqua_Eco_3G
Aqua_Freedom
Aqua_HD_5.0
Aqua_HD_Power
Aqua_i5_HD
Aqua_LifeIII
Aqua_Power
Aqua_Power_HD
Aqua_Power_HD-4G
Aqua_Power+
Aqua_Pro_4G
Aqua_Q7
Aqua_Q7_Pro
Aqua_Secure
Aqua_Sense_5_1
Aqua_Shine_4G
Aqua_Slice_II
Aqua_Speed
Aqua_Speed_HD
Aqua_Star
Aqua_Star_5.0
Aqua_Star_HD
Aqua_Style_Mini
Aqua_Style_Pro
Aqua_T4
Aqua_Trend
Aqua_Turbo_4G
Aqua_Xtreme
Aqua_Xtreme_II
Aqua_Y2_Pro
Aqua_Y2_Remote
Aqua_Y3
Aqua_Y4
Aqua_Young
Aqua4.53G

Aqual5Octa
AquaS7
AquaStyle4.0
AquaStyleX
ARGOM_E400
ARGOM_E500
ariel
ARK
ARK_Benefit_M4
Art-PCB-V116
ASM-500
astar-86vvq0
astar-d88
astar-ibt
astar-ibt-8723bs
astar-mq88HD
astar-q81led
astar-rtl8703
astar-uarmmid
ASUS
AT101-014-HW
AT101T-114-HW
AT1A*
AT1G*
AT7S
Atom_2
Atom_2X
Avvio 750
Avvio 768
AVVIO 777
AVVIO 787
Avvio_489
Avvio_750
Avvio_751
Avvio_753
Avvio_779
Avvio_793
Avvio_794Q

Avvio_795
Avvio_L600
Avvio_L630
Avvio_Q797
Avvio774
Avvio786
AW268P
AX1050
AX51
AX600
AZUMI A50
B3
b3458
b3465
b3469
b3475
b3476
b807_emmc_72_kk
b808_meibang_qhd
B8408
B8410
B8504
B8602
Basco L3
Basco S2
Basco XS1
bcm4335
bd6735m_35gc_c_l1
Bee-PCB-V216
Beeline Smart 4
Beeline Tab Fast
Benefit_S401
bf168
BIRD-W9
bird6580_weg_b_l
Bitel
BITEL B8409
Bitel B8601

Bitel B8603
Bitel_B8502
Bitel_B8503
BLACK
BLACK-1X
BlackBerry Z10
BLU
blu
BLU ADVANCE 4.0 L
BLU DASH 3.5 II
BLU Dash 4.0 Ce
BLU DASH J
BLU DASH L
BLU DASH MUSIC 4.5
BLU STUDIO 5.0 C
BLU STUDIO 5.0 C HD
BLU STUDIO 5.0 Ce
BLU STUDIO C MINI
BLU TOUCHBOOK G7
BLU_ADVANCE_4.0_L2
BLU_Advance_5.0
BLU_ADVANCE_5.0_HD
BLU_DASH_M
BLU_GRAND_5.5_HD
BLU_GRAND_HD
BLU_LIFE_ONE
BLU_LIFE_ONE_XL
BLU_LIFE_X_LTE
BLU_STUDIO_C_5_5_LTE
BLU_STUDIO_X8_HD
BLU_VIVO_AIR_LTE
BLUBOO
Bmobile_AX1070
Bmobile_AX605
Bmobile_AX620
Bmobile_AX675
Bmobile_AX705
Bmobile_AX710

Bmobile_AX920
Bmobile.AX605.TEM.GT
Bmobile.AX605.TEM.MX
Bmobile.AX670.TEM.MX
Bmobile.AX670.TEM.NI
Bmobile.AX675
Bmobile.AX680.GT
Bmobile.AX680.HN
Bmobile.AX800
BNT-71
bqaquaris5
bqaquaris57
bqAquaris5HD
BQS_5505
BQS-4001
BQS-4555
BQS-5020
BRAVIS_OMEGA
Brio S430
Budget X410
C1
c101v82_gq3017hd_u5_nofinger
c101v82_jbaol_akai
c201v92ds_jbaol1_3m_ouya
c211_gq3019_3m_hd_extamp
c218v13_gq3022_fhd_3m_ulefone
c218v13_jbaol_3m_fhd_elephone
c218v13_jbl_hd_3m_mstar_p
c220v53_hhwy
C630Lw
c701
c706
camellia
CASPER_VIA_E1
CASPER_VIA_M1
Casper_VIA_V10
Casper_VIA_V3
Casper_VIA_V5

Casper_VIA_V6
Casper_VIA_V6X
Casper_VIA_V8
Casper_VIA_V9
CB514
CB515
CB615
Celkon
Celkon A15K
Celkon Q4GPlus
cellprime92_3923
cenon72_w_kk
cenon82_wet_kk
Cheer
Cherry Spin
CherryMobile
CITI I
citizenm
CLARESTA
CLARO
Cloud Breeze
Cloud Gem+
Cloud Jewel
Cloud_4G_Star
Cloud_Cube
Cloud_Flash
Cloud_Pace
Cloud_Power+
Cloud_Swift
Cloudfone_Excite_504d
Cloudfone_GEO_402q
CloudPad_700qtv
Cocodrilo Z501
Colors_X21
Colors_X32
condor
Connect 501
Coolpad7620L-W00

CoolpadA118
CoolpadSmart4
CoolpadY76_I01
Cosmos_One
Coto_W418
cp706_xinbn
CP8298_I00
CP8676_I02
CPH1607
cpkmini_g00
cross72_3725
cross82_3821
cross89_8401
cross92_3923
Crown
cs_kk_c25
cs1
CTAB0714
ctepos
cube_5_0_2GB
CUBOT
CUBOT GT72+
CUBOT GT95
Cumulus_1
CW-Vi8-super
cwminit
CXQ
Cynus E4
Cynus_E5
Cynus_F8
D-Optima
d10f
d209_maximus
d209_QMobile
D305
D306
D340
d3456

d3466
D350
d3558
D402
D45Z
D5
D501
d5020_gigabyte_82
d5020_symphony_82
d5066_indonesia
d5110_qmobile
d5780_qmobile
D7061
d801
d802
d8058
d818
d850
d851
d855
D870
D890
d918
d930
d958
d960_lca
d9831_m5
DAGGER-DG550
DASH
DASH 3.5 II
DASH C MUSIC
DASH MUSIC JR
DASH X PLUS
Dash_3.5_Ce
Dash_4.0_C
DASH_JR_3G
DASH5_OPLUS
DASHJRTV

DEXP

DEXP Ixion ES2 4.5

DEXP Ixion ML 4.5"

dexp_ixion_ml25

dg_a42_gmo

DG750

Digital2 Platinum

DJ

DNS S4705

dolphin-fvd-p1

dolphin-smart85

DOOGEE

DPG500

Dream

DREAMPLUS02A-S10A

dtacPhoneS2

dx01

Dynamic Jump

Dynamic JumpL

E12

E240

E25

E3

e3465

e3467

E40_CherryMobile

E4004

E435

E45

E4503

E4i

E50

E5001

E61

E61S

E7

E71

E78

E79
E8QP
e970
e975
e980
EAGLE
EASY
EBM865FD
Econnect BH71
EL150
EL250
Elephone
elink8312c_tb_s_l
Elite9Q
ELUGA_Icon
ELUGA_L2
ELUGA_Mark
ELUGA_Switch
em_t8990_nand
eMAX
Emerald
emporia S1
Energy Phone Colors
Energy_Phone_Max
Energy_Phone_Pro
Energy_Phone_Pro_HD
ENERGY_X
EPIC
era1X
err_value
ES160
esky72_w_lca
esky82_tb_kk
Essence
Essence_4
etab5
EVERCOSS
EVERCOSS A7B

EVERCOSS A7V
EVERCOSS_A7A
EVERCOSS_A7A*
EVERCOSS-A75L
Everfancy
EverGlory II
EverGlow D35
EverGlow D40
EverMiracle_Nano
EverStar D40
EverStar Nano
EverStar Pro
EverStar Q50
EverStarQ40
EverTrendy+2G
EverTrendy+3G
EVERY 40
EVOLVEO
Excite_452q
ExciteC
ExcitePrime
F09_32v4
F1s
F2
f3458
f3466
f3467
f3469
f3476
f45_russion
FarEastone
Fenix
fiber-ibts-8723bs
fiber-ibts-ap6210
financier
Fire
Fire_Plus_3G
Fire_Plus_LTE

Fire_Pro
FIREFLY_S160
Flair P2
Flair S1
Flair_P8
Flame
Flare S Play
Flare S3
Flare S3 Power
Flare S4 lite
Flare XL Plus
FLARE_J1_PLUS
FLARE_J2
Flare_Lite
Flare_S2
Flare_S3_Power
Flare_S4
Flare_S4_lite
Flare_S4_Max
Flare_S4_Plus
FlareS3
FlareXL
florido
ford
Free_Link
FreeMeX47HD
FT142A
FT151A
FUEGO 4.0D
Furious 6S
G-TiDE_S4
G'FIVE_A5
g+
G10+
g130_base
g150_e
g150_g
g220

g220_b
g220_y3
g220_y3_aiji
g220_y3_single
g220_y3_tigo
g220_y3_tigo_unlock
g223
g223_cf_pd507_30k
g223_cts
g223_lca
g230_chile_z401
g255_e
G31
g315_a1_tecno_custom
g320_a_et
g320_b
g320_e
g325_a1_tecno_custom
g325_a1_tecno_custom_sd_share
g325_a1_tecno_custom_sml
g325_a1_tz_normal
G33
g335_a1
g345_a1
g345_a1_r6
G7
g808_l
g808_x551_28a
g808_x551_b1_30a
g808_x551_b1_in_30a
g808_x551_c1_30a
Galaxy A56
Galaxy A9
Galaxy J1 ace
Galaxy J7
Galaxy S6
Galaxy-J2
gce_x86

GENERAL_MOBILE

Genius TABLET

GFIVE_President_Smart_1

ghost_retail

GIONEE

GiONEE

giza

GK716

GLXSpiderI

GM

gm5_sprout

Go series 2

GO400

GO779

GO984

gp920_a1_ifive_mx100

Grand2

Grand2c

GT-T140

GT100_S

GTEL

GW502S

gwin71_e_kk_a711_v1d0

gxq6580_weg_I

gxt_dongle_3188

gxt_stb_3188

H120

H150

H175

H1S

H200

H250

H3

h3466

h351_a1

H50

H520

h532_a1

h533_a1
h533_b1
H55
H560
H60
h721_a2
h721_a2_et
h721_a2_tigo
h721_a2_tigo_unlock
h721_b2
h721_d1
H860
haida
Haier
Halona
Halotel H8401
hammer_S
hct6580_weg_a_l
hct6580_weg_c_m
hct6735_35gu_l1
hct6735m_35gu_l
hct6735m_35gu_l1
hct6735m_35gu_m0
hct6753_35gu_l1
hct6753_65u_m0
hct71_cwet_lca
hct72_cwet_kk
hct72_cwet_lca
hct82_cwet_kk
Helio_S1
HELLO
Hercules
hexing6572_wet_l
hexing71_cwet_lca
hexing72_cwet_kk
hexing72_cwet_lca
hexing82_a801
hexing82_cwet_kk

hexing92_cwet_kk
hi6210sft
HighScreen
highscreen-Zera-S-Power
HIMAX_PURE_3S
HK7
HL-L51
hltexx
HM 2LTE-SA*
Hologram HI 4934
honami
hongyu71_cwet_71_lca
hongyu72_cwet_71_kk
hqunited72_cwet_lca
HS_9DTB39
HSG1279
HT-704
HT17
HT3
HT3 Pro
HT7
HT7 Pro
HT7070MG
HT7071MG
HTC_D816W
htc_m7
huashan
HUAWEI Y625-U32
huaying72_cwet_kk
hwH60-L01
hwp6s-U06
hwSCL-U31
hy805a_symphony
HYUNDAI
i_mobile
i_style_221
i-mobile
i-mobile i-STYLE 210

i-mobile i-STYLE 8.5
i-mobile IQ BIG
i-mobile IQ X zeen
i-mobile_i-STYLE_8.5
i-mobile_IQ_XPRO
i-style216
I100
i12
i1k
i1s
i2
i2s
i3465
i3479
i3s
i4
i4D
i502
i5C
I62T_KM
i722
i9100
i9300
I9405_IPRO
iBall
iBall Slide 3G 7271-HD70
iBall Slide 3G Q7271-IPS20
iBall Slide 3G6095-D20
iBall Slide 3G6095Q-700
iBall Slide 7236 2G
iball72_3729
iball72_452_3729
iball72_452b_3729
iball82_3821
iball8735m_9706
iball8735m_9706b
iball89_6833b
Ice2

IcePlus2
Icon
ICRAIG_CMP_770_OD
IEOS_QUAD_W
ILIUM L820
ILIUM_S106
ILIUM_S130
ILIUM_S520
Ilium_X110
imobile_i_STYLE_8_6_DTV
imobile_IQ_1_5_DTV
Impress Open
Impress U Too
Inco Flex 2
INCO_Plain
Inco_Sphere
inet_alc5651
inet_w
INEW
Infinit 2
Infinix_X506
Infinix_X507
InfinixPure
INGO_TAB_FRU019D
INGO_TAB_INU019D
InnJoo
INTENSE_METAL
intex
Intex_Aqua_Play
IntexAqua4.5E
IntexAquaN11
IntexAquaT5
IntexCloudFame4G
IntexCloudGlory4G
IPRO
ipro71_e_lca
ipro72_w_kk
ipro82_wet_kk

IQ_13DTV
IQ_512DTV
iq1010
iQ1040
iQ1055
IQ1450
iQ1551
iQ1809
IRBIS
IRIS
iris 352Flair
iris 404Flair
iris 810
iris X8q
iris X8s
iris310s
iris353
iris360
iris400c
iris405+
iris410
iris460
iris465
iris500
iris504Q+
iris510
iris560
iris565
iris700
iris702
iris708
iris755
iris800
iris810
iris820
iris870
irisFuel20
irisFuel50

IrisFuelF1
irisX1+
irisX8
itel-it1512
Ivory
iX
IX1S
Ixion
Ixion E145
Ixion E2 5"
Ixion ES 5
Ixion X140
Ixion_M_4
Ixion_P4
J220_QMobile
J503_82_BLU
J505_QMobile
J511_BLU
J511_QMobile
j5800_symphony
j6010_blu_82
J608_PUBLIC
jactiveltexx
java_fortune_nw466a
java_fortune_nw466h
java_fortune_p6069a
java_gfive_wg5003
java_gilda_wg4030g
java_great_a900
java_great_a900m
java_kingtech_wg5501
jfltexx
JOY
JS 300
JUMP_Max
JuniorT8Pro
jxd_t8000l_w
JY-G5S+

K-series_K451
k002_gfen
k004
k01q_h
k01ts_a
k05ts_a
k06td_a
K10000
k15tb_a
k200
k200C
K3501H
K50-T5
k570w
k600_ylf01
k7_wsvga_3g_port_jhsm13
K9 Smart 1GB
K9Smart
Karbonn A1 Plus Champ
Karbonn A101
Karbonn A93
Karbonn_TITANIUM_S20
Karbonn_Titanium_S25
kc707
kenbo72_3722
keytak72_cwet_lca
kltexx
km71_jsa_gprs
kodiak
Konnnect 4 NEO
kst72_cwet_kk
kst72_cwet_lca
kt07_3g_hengbd
kt07_jty_hspa
kt07b_tefa_wvga
kt07c_nomi
kumquat
kylin-mb976a9

kylin-wt097
KYT31
L-EMENT 350
L-EMENT 550
L-EMENT500
L-ITE502
l1ats_lj3_mul
l1ats_lj3_mul2
L2
L30
l4020ap_c
L505
L50t
L800
l900
Lanix_X250
lava
lava35_sp31_lte
lava35_sp31_lte_thai
lava35m_sp45
lava35m_sp461
lava35m_sp48
lava35p_sp31_lte_thai
lava6580_sp46
lava6735p_sp31_lte
lava6753_star_lite
lava72_sp49th
lava72_sp51
lava82w_grand_i
lava82w_grand_t
lcsh82_cwet_kk
Lead_2S
Lead_3i
Lead6
LEAGOO
LEAGOO_Lead5
LEAGOO_Lead6
leatek72_cwet_kk

lenovo
Lenovo
LETO_C1
LIFE
LIFE_PLAY_MINI
LIFE_X8
LIFE8XL
LIFEPURE8
LINQ_L10
LiteIC
LIV I
LP_DAISSY
LS-5015
LS-5505
LT_M5_lite
LT50
LT500
Lumitel_L8501
LUX
Lynx
M-Pro_TV
M1
M150
M1E
m1metal
m1note
m2
m201d
M250
m2note
m3465
m3469
m3note
M402
M450
M501
M7-3G
m706_2g

m706t_3g_wsvga_port
M7S_Quad_Core
M7sQuadCore
m8
M8
m802_mito
m874v20
m874v3
m8s+
MACHFIVE
MACHONE
MACHONEPLUS
magc6580_we_l
magc6580_we_m
magcomm72_cwet_kk
magcomm72_cwet_lca
magcomm82_cwet_kk
MALATA
malata
mars-A31
masscom72_3729
masscom72_3729v
masscom72_452_3729
masscom72_452_3729v
Masstel Tab 840
Masstel Tab 850
Masstel_Tab_720
Masstel_Tab_720i
Masstel_Tab_740
MATE8
mbk82_tb_kk
Me_Vibe
MEGAEXIT
MEO_Tablet_2
MF0MCB3B1-1
Mi-431
MID-750
MID4X10

MID4X10PJ
mid713l_lp
Midi
MinionTab
mirage01a_msm8939_64
mismart_Wave4
miTab_CLEVELAND
MITO A260
MITO T55
MITO_A60
MITO_T77
ML145
ML150
MLS
mobeemsm8939_64
mobeepplus00b_msm8939_64
MOBICEL HERO X
mobiistar BUDDY
mobiistar LAI 504K
mobiistar LAI Yuki
mobiistar LAI Z1
mobiistar_BEAN_414
mobiistar_KOOL
mobiistar_LAI_504c
mobiistar_LAI_Y
mobiistar_LAI_YOLLO
Mobiistar_LAI_Yuna_C
mobiistar_LAI_ZORO_2
mobiistar_PRIME_508
mobiistar_PRIME_X
Mobistel
moto_msm8960dt
MOVIC
movistar
MOX A32
MP-S168
mr100
mr101

mr590
mr706
MS150
MS350
MS5.V2
msm8909
msm8974sfo
MT8312
Multilaser
Multilaser MSX
MX-S55026W1
mx1059c_jhggq45_gps_k_band15_release_turbo_32_8_4m
mx1059w_jhggq45_gps_k_band18_release_effire
mx2
mx3
mx4
mx4pro
mx5
MX6
MY PHONE M10
MY15Q2P
myPhone
MyPhone Agua Rio Fun
MyPhone MY32
MyPhone MY32L
MyPhone Rio 2 Craze
MyPhone_Agua_Rio
MyPhone_Agua_Rio_Lite
myPhone_AXE_LTE_PL_OPM
MyPhone_Infinity_Lite
MyPhone_MY33
MyPhone_MY36
MyPhone_myT1_DTV
MyPhone_Rio_2
MyPhone_Rio_2_Fun
MyPhone_Rio_2_Lite
MyPhone_Rio_Craze
MyPhone_Rio_Craze_3G

MyPhone_Rio_Fun_3G
MyPhone_Rio_Junior
MyPhone_Rio_Junior_TV
MyPhoneMY27
MyPhoneMY28
MyPhoneMY28S
MyPhoneMY31
MyWigo Magnum
mz706
n200
n200C
N401
N451
N501
n7000
N907
Natcom
NATCOM
NB1022
NBX-T7A3I
NBX-T7A3IP
NBX208HQCG
NEO-U1
NEO-X8H-PLUS
Neo4_5
NETWORK
NEX SMILE3
Nexttel N8502
NGM Spirit
NGM Time
NH001
NIM-500Q
NIM-600Q
NIPDA
NIU_ANDY_5.5E2I
Niu4D2
Niu5D
Nomi i504

Note

Note Pro

Note_E

Nova3.5

nozomi

O+ Grande

O+_360

O+_360_Alpha

O+_8.38z_Android

O+_Ultra

O+_Ultra_2.0

O+8.93Android

O100G

O6

Obi_S551

Octa

octopus-ibt

odroidxu3

Omega_5_0

Omega_5_5

on7ltechn

ONE_3G_HD

OnePlus3T

Onyx_QS

Oplus

Opus3

OrangeFova

Orbis

orbis

ORION

ORRO

otd_myleagoo

OUKITEL

OUKITEL_K4000

OWNS3045

Oysters T72MR 3G

Oysters_T72HRi_3G

Oysters_T72X_3G

P1+
p100
p15
P1923
P1ma40
P2000
p201_8188
p201_tn2
p3469
p3479
P4502
P50
P5Life_TM
P6_Life
P65
P6i
P709M
P7plus
P80 3G四核 (B1KC)
p880
p893g_d1h8
p908
p908_emmc
P909D_32v4
p983g_a3hy
p983g_a4hy
PAC25
PALADIN_PLUS
PAM412
Paris
PC-TE510BAL
PD6D1J
Penta_WS704D
Philips W3500
Philips_S388
PhonePad Duo
PhonePad_Duo
PhonePad-Duo

PhonePadDuo
Pixi343GEVDO
Pixi3454GSPR
Pixi445TFVZW
PKT411
PLAY_Club
PLAY-5
Play6X-1000
Play8X-1100
PLOYER
PlusIC
PMP7070C3G
PN70A01G
polaris-ibt
polaris-ibt-8723bs
polaris-p2
polaris-uarmmid
Polaroid
Polaroid PSPC505
POLYMER_X
Posh
POSH
Premium
prime
Primo GF2
Primo GF3
Primo HM2
Primo_C3_3G
Primo_D5
Primo_E4
Primo_E4+
Primo_E7
Primo_E7_Plus
Primo_EF2
Primo_F5
Primo_F6
Primo_GF4
Primo_GH6

Primo_GM
Primo_GM_mini
Primo_H4
Primo_N2
Primo_NF+
Primo_NF2
Primo_NH_Lite
Primo_RH
Primo_RM
Primo_RM2
Primo_RX2
Primo_RX4
Primo_S4
PRIXTON
PRO4544PWE01
PRO5
PRO6
PSPC550
PSPT401
PULSARE 777
PULSARE 777S
PULSARE 794S
Pure F
q
Q-Smart QS470
Q-SmartQS558
Q1000 Opus
Q1000 Opus HD
Q1001
Q1010i
Q1200
q200
Q2000L
q220
q223
Q3000
Q323
Q352

Q4 Androidl10

Q414

Q415

Q424

Q461

Q4868

Q500s_IPS

Q510s

Q600s

Q610s

Q700_Club

Q700S_Plus

Q710s

q72

Q800

Q900S_Plus

q901

QILIVE

QL861

Qmobile

QMobile

QMobile A290

QMobile i10

QMobile i5

QMobile i5i

QMobile i7

QMobile i9

QMobile M350

QMobile S9

QMobile V2

QMobile W20

QMobile X150

QMobile X30

QMobile X500

QMobile X6

QMobile_i1

QMobile_i2

QMobile_i7i

QMobile_LT500
QMobile_S3
QMobile_W15
QMobile_W35
QS18
QS500
QTab
QTab V6
QTASUN1
QUANTUM_400_Lite
QUASAR
Quatro
QUBE B1
R504
R50B
rabbit-p1
ratech72_we_72_rlk_kk
ratech82_cwet_rlk_kk
ratech92_cwet_rlk_kk
RCT6513W87
reallytek82_tb_kk
reederA7iC
rgk6753_65u_l1
RHYTHM_RX45
RHYTHM_RX60
RHYTHM_RX65
RHYTHM_RX75
RIVO_phantom_PZ8
rk292x
rk292x_esp8089
rk3028
rk3066
rk31_872xu
rk312x
rk312x_esp8089
rk312x_pos_7001
rk312x_rtl8723bu
rk31sdk

rk322x
rk322x_box
rk3368_box
rk86vhdsy_quicktab
rk86vhdsy_quicktab_fx
rkm7108_3126_rtl8703as
rkr760
rks753
rlk6580_we_c_m
rlk6580_we_l
rlk6753_65u_m0
rmt27_tb_c_mlc_kk
ROAR
Roar V25
Rocket
Rome
ROME_X
Roverphone
ROVI_V8108
rtd298x_tv038
rtech72_we_72_kk
RX80
S02
S100Q
S168
S2
S200
s2609_dg_a40_aejly
s2609_jk_bv2000s
s302_ld_s69a_t5
S3030
S3030D
S340
s3501
s3510ap
s3512ap
s3576
S360

s4002
S4010
s4040ap
s4800
S4H
S4Q
S4S4IN3G
S4T
s5015
s5612_otd_aziz_k551
S5E New
S5J
s620_f_h1_trx_j401_ec
S7200
s8_v50_jb3_w_sudy72_kk
s803
s813_lca
s815_a
S8401
s8813a
S90
S90_Q
Samsung G530H(GALAXY Grand Prime)
Samsung GT-I9060I
Samsung J500H/DS
Samsung SM-G355H
scx35_it1408
scx35_it1506
scx35_it1507
scx35_s7358_qhd
scx35_sp7731gea
scx35_sp7731gea_fs031
scx35_sp7731gea_hdr
scx35_sp7731gea_lm_fs031
SD6D1U
SELFIE
selfie50
Sendtel

SENSEIT_E400
SENSEIT_E500
SENWA
SERA_S828
serrano3gxx
serranoltexx
SF1
Sf3g_mrd5_p1_v2
Sf3g_mrd5_p1_v2_512m
Sf3g_mrd5_p1_v2_ux
Sf3g_mrd5_p1_v2_w
SGT-Z500T
Shark4
signal82_wet_kk
sirius
Sirius_QS
SJ1.5
SK412
SKY
SKY 4.0D
SKY 4.0LM
Sky 5.0Q
Sky 5.0S
Sky 5.5Q
Sky 6.0Q
SKY_Devices
SKY_Pro
SLAY
SLFQPLUS13A_S10A
SLFQPLUS13C_S10A
SLFQPLUS13C_S11A
SLFQPLUS13C_S15A
SLFQPLUS13C_S17A
SLFQPLUS14A_S12A
SLFQPLUS15A_S10A
SLFQPLUS15A_S12A
SLFQPLUS15A_S16A
SM-G360H

SM-G530H
SM-G9006V
SM-G900F
SM-G930F
SM-J700F
SM-N920F
sm618_w_ztc_72lca
Smart
SMART
Smart_1
SMART_4G_Plus
SMART_4G_Speedy_4inch
SMART_4G_Speedy_4inch_Plus
SMART_4G_Speedy_5inch
SMART_4G_Speedy_5inch_Plus
smart_grand
smart_speed
SMART_Surf_4G
SMART-E5
SMART4G4inch
SmartA35
SmartPad
SmartPadGo
SmartPadi2
SmartPadIseries
SmartPadS2
Smartphone_6.1
SmartPlusII
SMILE
sofia3gr
SOLO
SOLONE A47
SOLONE S4001
SOLONE SL-K40
SP-5050
SP6040 TITAN
sp7731c_fs259
SP7731G

sp9830aef_5m_volte
sp9832a_2h11_volte
sp9832a_3h10_volte
Spade
SPC
SpiceMi-503
SpiceMi-508
SpiceMi359
SpiceMi507
SPIN 3G+
Spin3G
Springboks
SS70
ST-PAD2
ST10408-5
Star
Star_Power
Starmobile
Starmobile_Jump_Neo
START-Mingalaba2
STARTRAIL7
STARXTREM3
STARXTREM5
Studio 50
STUDIO XL
STUDIO_6_0_HD
STUDIO_C
STUDIO_SELFIE
STUDIO_XL
STUDIO6_0HD
stvm8
SUNNY
SUNNY S52D
SUNSET2
suntory
SUPER
SUPRA_M727G
surnia

SWAN_X
Swipe_Konnect4E
SYH WP700
SYH WP930
SYH WP930+
SYMPHONY
symphony_V80
SYX-T101
T18
T1880R
T1J+
T1M
T45_4G
T5
T50
T700i_3G
T7012
T72ER3G
T86V_INGO_INU07QC
T950S
ta0708g
Tab_8
tangxun6572_we_l
taoshan
TBT5755A4
TBT5755B1
TBT5755B2
TBW5770A2
TC
TCV-101G
TD612
techain72_w_kk
techain82_wet_kk
techain92_wet_kk
TECNO 7C
TECNO 7CS
TECNO 8H
TECNO DP8D

TECNO F6
TECNO L6
TECNO L7
TECNO R5
TECNO_N2
TECNO_P9
TECNO-A7
TECNO-C5S
TECNO-L8Plus
TECNO-M6S
telacom72_w_kk
Tele2_Midi_1.1
TELEGO-W503
Telemor T8404
tenglongyu_fwvga_lca
TERRA_PAD
Tesla
TFX-708G
TGW-706
thebes
THL
Thrill_Boost
Thrill_Lite
ThrillHD
tianyu72_w_hz_kk
tianyu82_wet_b3_kk
tianyu92_wet_kk
TIMMY
Timmy E86
Titanium K9 Smart 1GB
Titanium_S12_Delite
Titanium_S2_Plus
Titanium_S204
Titanium_S99
TitaniumK9Smart
TM-4082R/X-driver
TM101AM
TM785CH_1

tm9767
togari
TONE_m15
Touch_XL_2
TOUCHBOOK7.0 3G
tp716j
TPS
TR10CS1_19
TR10CS1_IUSA3
TR10RS1_1
trx_w506
ts5001
TT7007MG
TT7025MG
TT7042MG
TT7071MG
TT7078MG
TU-7981B
TurboPhone4G 05
TurboPhone4G 2209
TZ42
TZ43
TZ48
TZ49
TZ70
TZ707
U10
u1555
U20
U25GT-C4WB
U402
U513
U51GT-C4BD
U610E_3
U65GT
udon02a_s10a
udon04a_s19a
ULTRA

Ultra-Tab
UMI
UMI_HAMMER
UMI_London
UMI_TOUCH
Uniden Prime 500
unknown
UTOK
UTOK 500D
UTOK D35
V_TAB_7_ECO_III
V_TAB_7_LITE_III
V-Gen
V.45S
V10
V11
v120_ttc_2h1
v126_fng_021
v13
v130_trx_2b2
V15
v151_fng_228
V16
v160_tsl_126
v173_tm_k_0d1
v173_trx_241
V19
V1Max
V2
v2006mt82_gfive
v211_hqd_181
V3+
V30
V32
V40
V400414
V45
V46

V49
v500
V502015
V552015
V60
v605_tsl_311
V8
V8409
V8417A
Valencia2_Y100
vanzo72_cwet_kk
vanzo95_lwt_ds_kk
VergeM
Vertis_4010_You
verykool
verykool Dorado s5017Q
verykool Leo 3G Jr s4005
verykool Lotus s5001
verykool s4006
verykool s5511
verykool SL4050
verykool Sol Quatro s5016
verykool__Atlas__s5014
verykool_Cyprus_s6001
verykool_Giant_s5020
verykool_Lynx_II_s3502
verykool_S354
verykool_S401
verykool_Sol_Jr_s5002
verykool_Sol_s5013
VerykoolS5017Q
verykoolSL4050
vh2005b_72m_w_emmc_gps_coclock_a4001_b18_i401
vh2005c_72_w_nand_a3505_b1_maximus
vh2005c_72m_w_emmc_gps_coclock_ax710_band25
vh2005c_72m_w_emmc_gps_coclock_zhouyi_e710mex_b25
vh2005c_72m_w_emmc_gps_coclock_zhuoyi_g5003_it
VH2005C_E710MEX

vh2005d_72_w_nand_a3505_b18_bird_i4
vh2005d_72m_w_emmc_a3505_band1_gtide_a1_e
vh2807_w_emmc_zhuoyi_g5001_it
VIA_A1
VIA_T8B
VIA_V8C
Vida
VIDO-M80
Viettel
VIVO
Vodafone890N
VodafoneSmart4max
VOX4+
VOYAGER2_DG310
vs980
vs985
w1401_jmp
w1401_q_mobile
W15i
w20be_aw_lj_ak47_twz
W3T61
w5_global_com
W68Q
W816
w825_12864_advan_fl_e740
w825_648_aw_loq_oukitel
w825_648_aw_ys_u16_rus
w825_648_ax_sstx_s23_reach
w825_648_ax_xs_t35_daimon5
w825_648_ax_xzx_k2_n6
W826
W90918A1_infinix_HOT_3
W90918A2 Infinix HOT 3
W91
WALTON
WALTON Primo HMmini
wetekcore
WIAM #23

wiko
WING
WINGTECH
Winmax_XC7
Woxter_Zielo_Z400
WP800
wt6582_wt_sz_l
wt88047
wt97055
wt97057
wt97601
wt98005_82
wt98006
X_10
X-square
X-VIEW_ZEN
X1 Grand
X140
X145
X15
X16
X1A
X1B
X1C
X1D
X1ST8865
X25
x2605_dh_l401
x2605_jk_bv2000
X325
x3356
X350
X360
X401
X401A
X45
X5001
X5004

X500A
x5601_otd_elite_5365u
x5602_f_otd_elite
x5602_fxkj_k20
x5602_jk_acteck_alive
x5607_dg_a32
X5max
X5max_PRO
X6
x604
X8 Pro
X800
X8417
x86
X8610
x902
X903S
x98air3g_c6j6
xd605_mrd5_cf_v2
xd607_mrd5_cf_HS011_512m_v1
xd607_mrd5_trx_v2_512m
XGODY
xiaoxin
xiaoxing
Xirius 5
Xirius 5.5
XL140
XL145
XL240
Xlife-512
Xlife-M5+
XOLO_One
XONPHONE_5(A25CL)
Xplorer_ZV
XTOUCH X4
Y100_Plus
Y100pro
Y12

Y27L
Y35
Y51L
Y635-L21
y72530_kk
Y76_U00
y8206
Yeah-Plus
yuga
Z25
z3
Z3
z3368
Z35
Z35C
z3c
Z4
Z403-T
Z404
Z45_Nova
Z5
Z5 Premium
Z50_Nova
Z702
Z909
ZA990
zaw1500_imobile
zaw1500_kenbo
ZAW268
zechin6735m_35u_l
zechin72_w_kk
zechin82_we_kk
zenlteusc
Zera F
Zera S
Zera_F
ZERO
Zeta

Zielo Q23
ZP951
ZP952
ZTE_E10Q
ZUUM
ZUUM_M50
ZVI
zx55q05_64
zyt71_cwet_lca
zyt72_cwet_kk
zyt72_cwet_lca

TRUE
TRUE